

BARMAC

ROCK-ON-ROCK VSI CRUSHER

Manufacture and design of the Barmac crusher is carried out under quality control systems certified in ISO 9001 by Svedala Barmac Product Group. Distributed worldwide under the following granted and pending patents and design applications:

New Zealand 498007, 301150, 313513, 217762, 217751, 250027, 22924, 22927,
22929, 23549, 25473, 25474, 233457, 245954, 246955, 246952, 249953,
250134, 227492, 238349

Australia 557186, 562254, 594367, 623636, 640710

U.S.A. 4562571, 4565663, 4921173, 4949138

Canada 1189045, 1229823, 1265772, 130135

Japan 554366, 162026, 217853/66, 32286/88

South Africa 82/6374, 83/5817, 86/8902, 86/5063, 85/8062,

82/9125, 83/9145

United Kingdom 6074771, 6101277, 236592, 2214867,
2246410

France 0074771, 0101277, 216592, 88-17023

Italy 0074771, 0101277, 216592

Sweden 8230465/29, 0101277, 236592

Austria 216592

Federal Republic of Germany 5275505.8, 0101277, 216592

Europe 0074771, 0101277, 0012563.5

Mexico 844123

BARMAC, ROTOPACTOR and DUOPACTOR are trade marks owned by SVEDALA BARMAC LIMITED and registered in many countries in the world. BARMAC and BARMAC DUOPACTOR trade marks are registered in the United States in the name of SVEDALA INDUSTRIES INC. Due to a policy of continuous development, the right is reserved to make change without notice in specifications and designs. Springs are nominal and may vary more or less with operating conditions.

AFTER SALES CONTACTS (PLEASE QUOTE MACHINE REF. NO.)

Spare Parts		Service	
Technical		Crusher Sales	
Telephone		Fax	

SVEDALA



Svedala Chile

Av. Los Conquistadores 2758, Providencia, Santiago, Chile.

Tel. +56 2 360 5500. Fax: 56 2 360 5555.

Dealer:

BARMAC PRODUCT STANDARD LIMITED WARRANTY

SVEDALA NEW ZEALAND LIMITED (hereinafter Svedala NZ) warrants its products to its authorized Distributors and Dealers, and Distributors and Dealers agree to extend the same warranty and its other to each purchaser of the Barmac products at the time of sale, and to notify such purchaser of the terms and conditions of this warranty. Distributors and Dealers are not authorized by Svedala NZ to make any other, different, or additional warranty on behalf of Svedala NZ, and any such warranty given by Distributor and Dealer is not binding on Svedala NZ. Distributors and Dealers shall hold Svedala NZ harmless from any loss and/or costs (including attorney's fees) arising from failure to observe these conditions. Svedala NZ extends this same warranty to those, in addition to its authorized Distributors and Dealers, who buy the Barmac products directly from it rather than purchasing them from an authorized Distributor or Dealer.

Svedala NZ warrants, commencing with the date of shipment of goods by Svedala NZ to Distributor or Dealer or end user and for a period of one hundred and eighty (180) days thereafter or the date of signing of the Owner Registration Form (M7413) (which must be signed by Owner Representative and Dealer/Distributor Representative at completion of machine commissioning) and for a period of one hundred and eighty (180) days thereafter, whichever period has a later expiry date, all machinery and parts manufactured by Svedala NZ to be free from defects in workmanship and material. If, within such warranty period, any machinery or parts shall be proved to the satisfaction of Svedala NZ to be defective, they shall be replaced or, at the option of Svedala NZ, repaired at its nearest Distributorship or Dealership at no charge providing the defective machinery or parts are returned to Svedala NZ or its Distributor or Dealer, freight prepaid. At its option, Svedala NZ may repair, or arrange to have repaired, any defective machinery or parts, at the location of the Distributor and/or Dealer, or at the location of the operating site of the first end-user, or any other suitable location at no charge to first end-user and at no charge to Distributor and Dealer other than those agreed to by its Distributor and Dealer Agreement. The right to have defective machinery or parts replaced shall constitute Distributors, Dealers and first end-user's sole and exclusive remedy.

Svedala NZ may, at its sole discretion, refund the purchase price of defective machinery or parts in lieu of repairing or replacing them providing the defective machinery or parts are returned to Svedala NZ or its nominee, freight prepaid and providing such return is authorized by it.

Svedala NZ may, at its sole discretion, waive the requirement that defective machinery or parts be returned to its factory in connection with a warranty claim.

The obligation of Svedala NZ under the terms of this warranty, is limited to the described repair of or replacement of defective machinery and parts and does not include charges, direct or indirect, by Distributor and Dealer, or end-user for field labor, field expenses or equipment used in removing or replacing defective machinery or parts.

With regard to machinery, parts or accessories which are furnished by Svedala NZ, but not manufactured by it, the warranty obligation of Svedala NZ shall be limited to that of its supplier. No warranty shall apply to any used machinery or parts. No warranty shall apply to the Barmac products which, in its opinion, have been adversely affected by the use, on or with its products, of parts, attachments, equipment or lubricants not either manufactured, sold or authorized by it.

No warranty shall apply to machinery, parts or accessories which have been furnished, repaired or altered by others so as, in the opinion of Svedala NZ, to have affected the same adversely. No warranty shall apply to machinery, parts or accessories which, in the opinion of Svedala NZ, have been subject to accident or negligence; or improper operation, installation, maintenance, storage, care, or other than normal use during and after shipment.

Svedala NZ warrants that field services conducted by Svedala NZ itself in connection with any warranty repairs of machinery and parts will be performed in a good and workmanlike manner. The obligation and liability of Svedala NZ connected with field services performed by others on its behalf shall be limited to a refund of the amount charged for such services, if any.

Inasmuch as the work to be performed by the buyer or end-user with the machinery or parts furnished by Svedala NZ will vary according to the materials used, local conditions and the results required and that such variation will continue throughout the use of such machinery or parts, it is not possible to and Svedala NZ does not warrant or represent that machinery and parts furnished by it will handle specific materials nor will they produce specific results from such materials.

Svedala NZ is to be wholly discharged of liability under the foregoing warranties in cases where the purchaser of the machinery or parts fails to settle and pay for the goods promptly and in accordance with the terms of the purchase agreement.

Svedala NZ's liability hereunder is conditional upon Distributor and Dealer (or in the event of a direct sale to a first end-user, then first end-user) giving notice in writing to Svedala NZ of any alleged defect, and such notice must be given immediately upon the discovery of such alleged defect; but, in any event, such notice must be received by Svedala NZ not later than thirty (30) days after the expiration of the warranty period.

Svedala NZ does not warrant or represent that any machinery, parts, or accessories furnished by it meet any Federal, State, or local statutes, codes, ordinances, rules, standards or other regulations covering safety, pollution, electrical wiring and so forth.

The foregoing warranties are in lieu of all other warranties express or implied except of title including but not limited to any warranty of merchantability and Svedala NZ and its Distributors and Dealers shall not be subject to any other obligations or liabilities whatsoever with respect to machinery, parts, accessories or services manufactured or furnished by it or any undertakings, acts or omissions relating thereto. Under no circumstances shall Svedala NZ and its Distributors and Dealers be liable for any consequential damages, expenses, losses or delays howsoever caused. There are no warranties which extend beyond the description of the facts hereto.

SVEDALA NEW ZEALAND LIMITED, Mangawhero Road, Private Bag 4074, Motamata, NEW ZEALAND.

MACHINE DATA FORM

Machine Ref. No.: TM241

Date: 5/93

Model: B7000 DUALACTOR

Please record Cycle and Serial numbers for all components as listed below.

Hoppers: 100699

Cascade: 100280

Roof: 100720

Cavity Ring: 100264

Crushing Chamber: _____ (9000 & 8000 models only)


Motor Mount: 1 100926 2

Transmission: 1 100296 2

Base Serial No.: 100340

Dual Drive Only	

BELT DRIVE:



Belt Length: 4250



Belt Section: SPCK

Number of Belts: 6

Barmac Sheave a: 395 No. Grooves: 6C

Motor Sheave a: 375 No. Grooves: 6C

MOTOR:



Motor 1: Brand: _____
 Serial No.: _____
 Rated Power: _____
 Volts: _____ Amps: _____
 Hz: _____ RPM: _____

Motor 2: (Dual Drive Only)
 Serial No.: _____
 Rated Power: _____

(For motor details see manufacturer's information included in this manual).



MOTOR STARTER:

Start Method: _____
 Manufacturer: _____
 Serial No.: _____


(For motor starter details see manufacturer's information included in this manual).

SAFETY INTERLOCK:

Shutout Key (at Starter Panel)

Key Code: TIL 327


Key Serial No.: 361082



Access Key (at Timer Box)

Key Code: TIL 327A

Key Serial No.: 361182



VIBRATION SWITCH:

Switch Brand: FURST INERTIA

Model: 3171, 2.0A SURESTOP RESET

Serial No.: 425290

CASCADE CONTROL:

Method: HYDRAULIC CHECKS ADJUSTED

Details: HYDRAULIC HAND PUMP SIGN.



ROTOR PARTS LIST

Name:

Machine Ref No.: **TM241**

Date: **5/98**

Rotor 1: Size: **Ø760**

Rotor 2: Size: **Ø760**

Type: **Open Sided**


Type: **Open Sided**

Serial No.: **100328-19**

Serial No.: **100328-18**

Taper Lock No.: **101204-11**

Taper Lock No.: **101204-45**





ROTOR PARTS LIST

Name:

Machine Ref No.: **TM241**

Date: **5/98**

Rotor 1: Size: **Ø760**

Rotor 2: Size: **Ø760**

Type: **Open Sided**


Type: **Open Sided**

Serial No.: **100328-19**

Serial No.: **100328-18**

Taper Lock No.: **101204-41**

Taper Lock No.: **101204-45**







Check list BARMAC

Número Equipo

NOTA : El check list debe ser realizado (o supervisado) por un Técnico de Servicio Barmac autorizado. En cada etapa, la casilla de verificación debe ser llenada, a fin de evitar saltar alguna etapa.

Instalación

- 1.** Verificar si el equipo ha sido instalado de acuerdo con las dimensiones y accesos recomendados en la Sección Instalación.
- 2.** Verificar la correcta operación de la traba de seguridad de la puerta y del procedimiento de cierre por parte del Cliente.

Montaje

- 1.** Verificar si el número de ciclos ha sido registrado en el formulario de Datos del equipo
- 2.** Verificar si el equipo ha sido montado de acuerdo a las instrucciones que se indican en la Sección Instalación
- 3.** Verificar el ajuste de todos los tornillos de acuerdo a lo especificado en el Manual de Operación y Mantenimiento
- 4.** Verificar el montaje del centrado de cascada como se indica en el Manual de Operación y Mantenimiento
- 5.** Verificar el montaje del rotor

Correas de accionamiento

- 1.** Confirmar que las especificaciones de las correas y poleas son correctas
- 2.** Verificar alineamiento (Ver Manual de Operación y Mantenimiento)
- 3.** Verificar la tensión de las correas (Ver Manual de Operación y Mantenimiento)
- 4.** Verificar si las protecciones de las correas fueron fijadas correctamente
- 5.** Verificar la instalación del motor

Sistema eléctrico

1. Verificar si el switch de vibración esta instalado y conectado
2. Verificar que el cableado ha sido realizado en forma correcta
3. Verificar la dirección de rotación del rotor (debe ser antihoraria mirando desde arriba)
4. Calibrar y chequear el funcionamiento del switch de vibración (Ver detalles en el Manual de Servicio del Sistema de Control de Vibración)
5. Verificar el funcionamiento del corte térmico, si esta instalado

Encendido del equipo

1. Encendido del equipo siguiendo las instrucciones de encendido del Manual de Operación Y Mantenimiento

Tiempo de parada del rotor

 minutos

Entrenamiento del operador

1. El Técnico de Servicio de Barmac explico adecuadamente la operación del equipo, incluso los efectos de alterar el volumen de alimentación, el tamaño de alimentación, velocidad del rotor y el flujo de cascada
2. Explicó adecuadamente las características del rotor y como ajustarlo para un rendimiento Óptimo
3. Entrenó al personal de operación y mantenimiento en procedimientos para solucionar Problemas específicos
4. Verificó si el personal de operación y mantenimiento esta compenetrado con el Manual de Operación y Mantenimiento y si tienen una copia del mismo
5. Verificar si el Formulario de Registro del propietario ha sido firmado.

OWNER REGISTRATION

Machine Ref. No.: TM 241

Date: 5/98

OWNER DETAIL:

Company: _____ Tel: _____

Address: _____ Fax: _____

_____ Telex: _____

Contact Person: _____ Tel. A/H: _____

DEALER DETAIL:

Company: _____ Tel: _____

Address: _____ Fax: _____

_____ Telex: _____

Contact Person: _____ Tel. A/H: _____

MACHINE DETAIL:

Model: _____ Serial No.: _____

INSTALLATION TYPE: TRUCK MOUNTED Mobile HOVER MOUNTED Skid Mounted Fixed

APPLICATION DETAIL:

Rock Type: _____ Duty: _____

1. This machine has been commissioned in accordance with commissioning procedures contained in this manual.
2. Warranty commences from: 12/15/98

Owner Representative:

Name: _____

Signature: _____

Date: _____

Dealer/Distributor Representative:

Name: _____

Signature: _____

Date: _____

OWNER COPY

safety

BARMAC™

SAFETY

GENERAL

During the design and manufacture of the equipment, a lot of effort is put into the avoidance of health and safety risks.

In a crushing and screening plant there are many potential risks and to avoid these it is important that:

- The recommendations in instruction manuals are studied and followed.
- Personnel are regularly given training on maintenance and safety.
- General and official safety regulations are followed.
- Dangerous areas are marked with warning signs.
- The appropriate equipment and tools are available.
- The owner and management live up to their responsibility to make sure that effective safety programmes and regulations are worked out and are followed by all personnel.

EXTRA SAFETY PRECAUTIONS

Our instruction manuals and other documentation contain important information which must be read and understood by all users before they operate the equipment. To make it easier to notice information in our instruction manuals directly concerning user safety and the avoidance of problems with the equipment, we use the terms shown below:

CAUTION: Important information which describes how you avoid damage to a machine and its systems or how you avoid a situation which could cause personal injury.

NOTE: Advice about operation, inspection and maintenance of a machine and its systems.

GENERAL SAFETY PRECAUTIONS

The following list of general safety precautions should be considered as a guide only. There may be other conditions and variations in the operation of this equipment that are not covered in these general safety precautions. The purpose of the general safety precautions is to make all personnel aware of the general hazards and dangerous situations that exists around the equipment and the work area.

Personnel Safety

1. Read and understand each of the warnings, cautions and instructions in the instruction manual and on all signs and information plates on and around the equipment.
2. Report all accidents immediately to your supervisor. Consult a doctor or medical personnel as soon as possible if personnel injury is involved.
3. Keep a list of emergency telephone numbers close to the telephone and inform all work area personnel about the location of the list.
4. Do not operate or work equipment while under the influence of alcohol, medicines, tranquillisers or other drugs that can make you less alert or affect your judgement.
5. Use hand grips, ladders, guard rails and other safety devices when getting on or off equipment and when moving around while on the equipment. Use a safety harness when necessary.
6. Take precautions to keep hair and loose fitting clothing from being caught on moving parts or controls.
7. Wear safety glasses whenever there is danger of flying debris, chips, objects or dust that could enter the eyes, and when required by operating regulations. Be extra safe — always wear eye protection. Look after your eyes!
8. Wear gloves whenever possible to protect hands and fingers from cuts, scrapes, burns and solvents.
9. Always wear a hard hat and safety shoes when appropriate for the work being done and always when required by local or national regulations.
10. Remove rings, watches, necklaces and bracelets before working in the plant.
11. In areas where noise levels are high, wear hearing protection devices.
12. Wear a breathing apparatus mask or whenever appropriate, i.e. when painting or working with chemicals, solvents and other substances that may be hazardous to your health. Remember that there is a risk of silicosis when there is siliceous dust in the air.
13. Do not take chances with your back. Use lifting and moving devices to help you with your work. Always lift with your legs, not with your back.

WORK AREA SAFETY

1. Keep the general work area clean and free of debris. Avoid stone or other material build-ups on walkways, platforms, ladders and under conveyors.
2. Do not allow unauthorised personnel in or around the work area. Keep a check on who is in your work area at all the times. If necessary, keep a list.
3. Keep equipment surfaces that will be touched by hands and feet clean, dry and free of oil or grease.
4. Keep hand grips, guard rails, ladders and platforms clean, dry and free of oil or grease. Store parts and tools in the designated places when not in use.
5. Keep safety equipment in a designated place and ensure that work area personnel know the location and the proper use of the safety equipment.
6. Make a daily check of starting alarms and warning devices in the work area, and ensure that each device is working properly before starting or operating the equipment.
7. Do not stand under or allow anyone else to stand under equipment that is being hoisted or suspended. Use a safety hook or hook with a safety latch when hoisting equipment and use spreader bars when necessary.
8. Learn the weight limitations and clearances in and around your work area and for the equipment in use.
9. Do not overload walkways. They are intended for personnel, not for storing parts or tools!
10. Be alert to conditions that may obscure vision in and around your work area.

EQUIPMENT SAFETY

1. Do not alter, deface or remove warning and information signs.
2. Before setting up portable equipment, be sure that the ground surface is firm and level. Make sure that all supporting and locking devices are securely in place. Follow manufacturers' recommended procedures for supporting and locking the equipment when applicable.
3. Before moving portable equipment, check that the brakes and running lights operate properly. Ensure that supporting legs are raised high enough off the ground to provide sufficient clearance for safe transport. Check that there are no loose items that could fall off during transport.

4. Never climb aboard equipment while it is in transit or being hoisted, or allow anyone else to do so.
5. Inspect all equipment components before each operating shift to ensure that no parts are damaged or suspected of being damaged. Repair or replace damaged parts before starting or operating the equipment. Use only original parts.
6. Before starting or operating equipment, walk around the work area and the equipment to check that no personnel, animals, tools, parts or foreign objects are in, on, under or around equipment. Make sure that all guards and safety devices are properly installed and in good working condition.
7. Before starting equipment, make sure that all work area personnel and visitors know the equipment is going to be started. Use appropriate devices such as sirens or flashing lights to warn personnel and visitors.
8. When starting equipment, follow the manufacturer's recommended starting sequence. Do not allow unskilled persons to start or operate any equipment without the proper supervision of a skilled operator.
9. Never leave equipment controls unattended. Always have a qualified operator relieve you if you must leave.
10. During start-up and while equipment is operating be alert for improper readings, visual defects, odours or unusual sounds that could be a warning of a potential hazard. Shut down equipment immediately, following established shutdown procedures, if any unsafe condition should arise.
11. Use extreme caution whenever any equipment is required to be operating during an inspection, maintenance, lubrication or adjustment procedure. This may only be permitted if it is absolutely essential. Under normal circumstances the machine must be stopped and safety switches locked out before any work is carried out.
12. Perform all inspections, maintenance, lubrication and adjustment procedures with caution and in accordance with the manufacturer's recommended procedures.

ELECTRICAL SAFETY

1. Permit only trained and competent personnel to work on electrical components in the plant or on any equipment.
2. Always assume that an electrical circuit is live until it is proven dead by proper testing procedures.

3. Lock out and tag electrical controls before performing any inspection, maintenance, lubrication or adjustment procedure.
4. Repair or replace electrical wires, cables and connectors that are broken or damaged in any way.
5. Check the electrical ground wires, motor plugs and power cable connections are properly and securely connected before starting any equipment.
6. Know the location of all power lines and underground cables. Use extreme caution when working around these areas. Know the location of all main electrical isolating switches.
7. Never work on electrical equipment while it is raining or while standing in water or on wet surfaces unless you know the power is disconnected.
8. Be alert when working around or with electricity. Report any electrical hazard immediately to your supervisor.

FLAMMABLE & HAZARDOUS MATERIALS SAFETY

1. Store flammable, combustible or hazardous materials in a safe place and in containers specifically designed for the purpose and clearly marked in accordance with relevant the regulations.
2. Store used and oily cleaning rags in a properly designed container as required by national or local rules and regulations, and away from flammable and combustible materials.
3. Do not store flammable or combustible materials in, or around the equipment, electrical installations or personnel facilities.
4. Do not permit smoking or an open flame around fuel tanks or other storage facilities for combustible materials.
5. Keep several fully charged fire extinguishers located throughout the work area. Make sure that all personnel know their location and how to operate them. Have them readily available during fuelling operations or when other fire hazards are present. Check the charge on each fire extinguisher at least one a month or when otherwise specified.
6. Shut down all engines and motors when fuelling or transferring flammable, combustible or hazardous materials. Follow the recommended fuelling and transfer procedures for the substance or material being worked with.

7. Fill fuel storage tanks and other combustible materials storage facilities in a well ventilated area, well away from equipment which can cause sparks and thus ignite flammable materials.
8. When refueling or transferring flammable or combustible materials, ground the nozzle or spout to prevent sparks caused by static electricity.
9. Never start a diesel or gasoline engine in an enclosed area unless there is adequate ventilation.
10. Do not use flammable or combustible substances such as gasoline, kerosene or diesel fuel for cleaning parts. Always use a nonflammable solvent for cleaning.
11. When using epoxy-resin based materials, follow the manufacturer's recommended procedures and precautions. Mix and pour epoxy materials in an open or well ventilated area. Do not burn cured resin without adequate ventilation. Avoid skin contact with uncured epoxy-resin materials.
12. Always inspect and charge batteries in an open or well ventilated area. Do not permit smoking or open flames near batteries. Remember that batteries can contain explosive gas.
13. Properly dispose of waste, drain fluids and hazardous materials with due regard to and in full accordance with all national and local environmental, safety, transportation, and other regulations and ordinances. Make sure that all personnel are familiar with these regulations.
14. Wear the appropriate clothing and protection devices, and follow the recommended procedures when working with hazardous, flammable and combustible materials.

PRESSURISED SYSTEMS SAFETY (AIR & HYDRAULIC)

1. Do not perform maintenance on pressurised system components without first relieving all pressure in the system.
2. Do not make internal checks on pressurised oil or fluid systems reservoir or levels until all pressure in the system has been relieved. Pressurised oil and air are dangerous if released incorrectly. Oil and air pressure can get very hot; use extreme caution and allow the system to cool before working on it.
3. Do not attempt to remove an air line or hydraulic line from a cylinder or other component unless all pressure to the system has been relieved.

4. Do not attempt to remove an air or hydraulic cylinder clevis from its attachment unless all pressure in the system has been relieved.
5. Do not operate pressurised systems with worn or damaged hoses, valves or fittings. Replace defective components before pressurising the system.
6. Do not attempt to disassemble air or hydraulic cylinders unless you have been trained and authorised for such maintenance.
7. Never adjust pressure relief valves beyond the recommended values.
8. Follow the manufacturer's recommended inspection and maintenance procedures for pressurised systems to ensure the safe operating conditions exist at all times.
9. Take extreme care when working with hydraulic accumulators. They must never be heated or subjected to welding or mechanical damage.

WELDING SAFETY

1. All welding or cutting operations should only be performed by experienced welders who are familiar with the welding equipment and the material to be welded.
2. Take all necessary precautions to avoid dropping sparks or welding splatter on belts, hoses, tanks or other parts of equipment, or on personnel in the work area. Always keep the risk of fire in mind.
3. Attach the welding ground cable as close as possible to the piece being welded to avoid damage to the equipment and potential injury to personnel.
4. Always consult with the manufacturer's of the equipment to be welded before any welding operation.
5. Never weld vessels or pipework which is pressurised.

TEN COMMANDMENTS OF SAFETY

1. Support all efforts to make your workplace safe and healthful.
2. Act responsibly and with concern for the safety of others, as well as yourself.
3. Check all tools and protective equipment frequently, to make sure they are in safe working order.
4. Educate yourself and others in the hazards associated with your job so that they can be avoided in a safe manner.
5. To avoid injury and damage, familiarise yourself in advance with the risk and safety aspects of procedures which are new to you.
6. Think over accident and injury possibilities before starting on any project. Take appropriate precautions to protect yourself and others. Revise and improve working procedures regularly.
7. Warn others of the possibility of accidents and injuries if you see them working unsafely or creating potential hazards.
8. Stay alert for changes in work conditions and the work process.
9. Report unsafe acts and conditions immediately to your supervisor. Don't assume that someone else will do it.
10. Keep your work area and your tools clean. Pick up tools and materials after use and return to the appropriate storage place.

installation


BARMAC™

BARMAC B7000 DUOPACTOR INSTALLATION

Single Feed (Hydrascascade)

CONTENTS :

PAGE 2 - GENERAL ARRANGEMENT A general arrangement of the crusher giving overall reference dimensions. Feed and discharge details are also detailed here.	(04.102020-07/97)
PAGE 3 - CRUSHER SUPPORT OPTIONS Details of acceptable support arrangements in various configurations. Dynamic force data also included for your reference.	(04.102021-05/97)
PAGE 4 - CRUSHER COMPONENT WEIGHTS Total operating weight and individual heights of main crusher components. Also included are internal component fill out heights for service reference.	(04.102024-10/97)
PAGE 5 - CRUSHER SERVICE CONSIDERATIONS It is important that when installed there is adequate access for service. This page contains details of all aspects of the installation that affect the ability to service the crusher.	(04.102023-05/97)
PAGE 6 - CRUSHER ON-SITE ASSEMBLY Final assembly of the crusher is carried out on site. This page gives assembly instructions and bolt torques.	(04.102026-02/97)
PAGE 7 - CRUSHER DRIVE DETAILS Fitting dimensions for pulleys (showers) and minimum power and speed ratings.	(04.102020-10/97)
PAGE 8 - SAFETY INTERLOCK AND STARTER The safety interlock system must be incorporated into the electrical starter of the crusher. Included are basic starter requirements, an explanation of the interlock system and fitting instructions for the interlock.	(04.102025-10/97)
PAGE 9 - VIBRATION CONTROL The Barmac warranty is contingent on this control switch being installed and operating correctly.	(04.102028-03/97)
PAGE 10 - HYDRASCASCADE CONTROL A variety of options are given for controlling the cascade ratio. These range from a manual hand pump or in smaller models hydraulic rod adjustment to remote control or interfacing with external control devices.	(04.102022-05/97)



Congratulations...

on your purchase of a Svedala Barmac Rock-on-Rock VSI crusher. The Svedala Barmac VSI is the leader in Rock-on-Rock technology and will if installed correctly, be the easiest crusher in your plant to operate and service.

READ THIS BOOK PRIOR TO PREPARATION OF THE SITE and installation of the unit.

This book contains specific information on installation dimensions, SERVICE CONSIDERATIONS and technical specifications. **THIS BOOK HAS BEEN PRODUCED TO SUPPLY THE NEW OWNER OF THE BARMAC WITH ALL OF THE INFORMATION** required to install a Barmac to ensure that it will operate correctly and will be accessible to service.

If you consider the information is unclear or insufficient please contact your Barmac Representative.

NOTE: NOT ALL COMPONENTS DEPICTED IN THIS BOOKLET ARE SUPPLIED WITH THE STANDARD BARMAC - CHECK WITH YOUR BARMAC REPRESENTATIVE FOR DETAILS



Svedala Barmac Limited
Svedala Rock Facility Bm 102, Svedala, Box 20204
Finland tel 1 020297 Fax 010 21 222074

CONFIDENTIAL © COPYRIGHT 1997
Copyright in this drawing resides in Svedala Barmac Limited
Unauthorized use may result in legal action.
The subject of this drawing may be patented by Svedala Barmac Limited and every application of printed matter and design, trademark, trade name or otherwise in this product shall be the property of Svedala Barmac Limited.

BARMAC B7000 DUOPACTOR
SINGLE FEED / SINGLE DRIVE INSTALLATION
INTRODUCTION AND CONTENTS

DRAWN JANARO MURGARD

CHECKED *F. L.*

ISSUES PAGE 1 OF 10
REV [REV] 8 / 5 / 97




CRUSHING NUMBER
INS 70SFSD1

BEARING CARTRIDGE 150 (600)
 MOTOR 780 ROTOR = 471 (1853)
 DEEP 650 ROTOR = 353 (1405)

CASCADE 305 (670)


HYDRASCALDIE 286 (640)



RIFFLE 250 (515)


BASE 2035 (6405)

CAVITY RING 316 (750)




4200 (10.66)

41050 (22.23)



MOTOR MOUNT 310 (785)



FRAME MOUNTED (OPTIONAL) 410 (100)

WITHOUT PERMISSIBLE WEIGHT IS ALWAYS TO BE ATTACHED TO SUPPORT FRAME IS 1800 (4000) 3700 (112.7) x 12700 (3180)



DRIVE KIT 100 (400) UVA

LEG MOUNTED (OPTIONAL) 900 (1005)



CRUSHER WEIGHTS

kg (lb)

TOTAL HEIGHT

TOTAL CRUSHER WEIGHT = 7251 (15968)
 RETAINED ROCK = 2000 (4400) APPROX
 TOTAL OPERATING WEIGHT = 5251 (11568)
 4000 (8800) EXCLUDE SUPPORT STRUCTURE

CLIMBERS 35 (105)



SKID MOUNTED (OPTIONAL) 1715 (3795)



Svedala New Zealand Limited
 Svedala Road, P.O. Box 4011, Invercargill, New Zealand
 Telephone: 057 349499 Fax: 057 880514

CONFIDENTIAL © COPYRIGHT 1995
 Concept in the design under license to Svedala New Zealand Limited
 The machine will only be used in legal action
 The subject of the drawing may be protected by patent
 please read usage instructions in general manual and
 design regulations. Unauthorised construction of the
 product will incur a heavy penalty

BARMAC 87000 DUOPACTOR
 SINGLE FEED / SINGLE DRIVE INSTALLATION
 CRUSHER COMPONENT WEIGHTS

DRAWN BY GARTH TAYLOR
 CHECKED Z. C. C.
 DRAWING NO. 10 / 6 / 98
 PROJECT 4 or 10




DRIVING SALES
 10 / 6 / 98
 DRAWING NUMBER
 INS 70SFSD 4

ADJUSTABLE HANDLE SHOWN AT 30 (MIN) DEG.
WHICH MAY BE CHG TO DESIRED LENGTH.

OPTION 2 HANDPUMP CONTROL

HANDPUMP CAN BE ADJUSTED BY ANY LOCATION.
USE 1/4" HOSE WITH 2500 PSI MAXIMUM PRESSURE RANGE.





1/8" HOSE FITTINGS
1/8" HOSE OR 7/16" AC WALE

1/4" HOSE, STANDARD LENGTH 450mm (17.7")
WAL. STANDARD LENGTHS CAN BE
ORDERED ON SPECIAL ORDER.

2 PLYWOOD HOLES IN UNDERSIDE FOR MOUNTING
AND > 15 DEEP AT 75 CDS

OPTION 3 AUTOMATED CONTROL

CONTROL & PUMP UNITS CAN BE ADJUSTED BY ANY LOCATION.
USE 3/4" HOSE WITH 2500 PSI MAXIMUM PRESSURE RATING.



OPTION 1 CUSTOMER SUPPLIED HYDRAULIC CONTROL

PROVIDE ANY TYPE OF HYDRAULIC PUMP TO ACTIVATE A USUALLY ACTING VALVE OF
2" BORE & 2" STROKE & 4" STROKE
PUMP MUST HAVE PRESSURE RATED SET TO 2500 PSI
LOCATION OF PUMP SHOULD BE NO MORE THAN 0.75" / SEC IN (NEAREST DIRECTION)



Svedala Barmac Limited
Svedala, Sweden
Tel: +46 40 400000 Fax: +46 40 400001

COMPONENTS © COPYRIGHT 1987

Copyright in the drawings remains the
property of Svedala Barmac Limited
No part of this drawing may be reproduced
without the written permission of Svedala Barmac Limited
in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of Svedala Barmac Limited.



BARMAC B7D30 DUCPACTOR
SINGLE FEED / SINGLE DRIVE INSTALLATION
HYDRACASCADE CONTROL

IRVING JERRARD MUFFORD
CHECKED
DATE: 10/05/97
PAGE 10 OF 10




IRVING JERRARD MUFFORD


DRAWING NUMBER
INS 70SFD10



ALARM SIREN
 LOCATE WITHIN ALARMS RANGE
 OF THE BARMAC OPERATOR
 (MAX 50 M AT 300 (100) HX500 ALARMS)



ROTOR ALARM CONTROL
 LOCATE IN CLOSE PROXIMITY TO STARTER



1. POWER SUPPLY FOR THE ROTOR ALARM (3.8VDC). THIS VOLTAGE CAN BE THE 24V OR 420 VDC AT 50 OR 60 Hz.
2. RESET PROVIDE A BUTTON FOR RESET OF THE ROTOR ALARM CONTROL. IT SHOULD BE ELECTRICALLY CLEAN AND NORMALLY CLOSED WITH A VIBRABLE BARRING OF 24VDC / 3.8A.
3. ALARM INDICATOR PROVIDE AN INDICATOR LIGHT OR OTHER SIGNAL DEVICE IN ACCORDANCE TO THE ALARMS SIREN. PROVIDE A CIRCUIT WITHIN THE STARTER OF MAX. 40VDC / 3.8A, 24VDC / 10A OR 50VDC / 10A. MOTOR CABLES ARE ALARMS SIGNAL WHICH THE CIRCUIT IS DESIGNED TO BE CONNECTED TO THE RELAY CONTROL WITHIN ROTOR ALARM CONTROL.
4. SHUTDOWN PROVIDE A CIRCUIT WITHIN THE STARTER OF MAX. 40VDC / 3.8A, 24VDC / 3A OR 50VDC / 3A. WHICH WILL SHUT THE BARMAC DOWN WHEN THE CIRCUIT IS OPENED. (CONNECTED TO THE RELAY CONTROL WITHIN ROTOR ALARM CONTROL).
5. EARTH (EARTH) CARRY THE ROTOR ALARM CONTROL TO THE SPEAKER CABLE.

OPERATION

WHEN A VIBRATION CONDITION EXISTS, THE ALARMS SIREN WILL SOUND IMMEDIATELY.
 IF THE VIBRATION EXCESSES BEHIND THE TANK SETTING (0 - 2 MINUTE), THE ALARMS SIREN.
 IF THE VIBRATION CONTINUES FOR LONGER THAN THIS SETTING, THE ROTOR ALARMS CONTROL SOUNDS DOWN THE OVERSEER AND THE ALARMS SIREN CONTINUES TO SOUND.
 WHEN CRUISER SHUTS DOWN, PRESS THE "RESET" BUTTON TO RESET THE ROTOR ALARMS CONTROL AND SILENCE THE ALARMS SIREN. RESTARTING AND RESOUNDING THE CAUSE OF THE VIBRATION CONDITION BEFORE RESTARTING THE BARMAC IN THE HOSPITAL WARD.

SVEDALA
 Svedala New Zealand Limited
 14-15-16-17-18-19-20-21-22-23-24-25-26-27-28-29-30-31-32-33-34-35-36-37-38-39-40-41-42-43-44-45-46-47-48-49-50-51-52-53-54-55-56-57-58-59-60-61-62-63-64-65-66-67-68-69-70-71-72-73-74-75-76-77-78-79-80-81-82-83-84-85-86-87-88-89-90-91-92-93-94-95-96-97-98-99-100-101-102-103-104-105-106-107-108-109-110-111-112-113-114-115-116-117-118-119-120-121-122-123-124-125-126-127-128-129-130-131-132-133-134-135-136-137-138-139-140-141-142-143-144-145-146-147-148-149-150-151-152-153-154-155-156-157-158-159-160-161-162-163-164-165-166-167-168-169-170-171-172-173-174-175-176-177-178-179-180-181-182-183-184-185-186-187-188-189-190-191-192-193-194-195-196-197-198-199-200-201-202-203-204-205-206-207-208-209-210-211-212-213-214-215-216-217-218-219-220-221-222-223-224-225-226-227-228-229-230-231-232-233-234-235-236-237-238-239-240-241-242-243-244-245-246-247-248-249-250-251-252-253-254-255-256-257-258-259-260-261-262-263-264-265-266-267-268-269-270-271-272-273-274-275-276-277-278-279-280-281-282-283-284-285-286-287-288-289-290-291-292-293-294-295-296-297-298-299-300-301-302-303-304-305-306-307-308-309-310-311-312-313-314-315-316-317-318-319-320-321-322-323-324-325-326-327-328-329-330-331-332-333-334-335-336-337-338-339-340-341-342-343-344-345-346-347-348-349-350-351-352-353-354-355-356-357-358-359-360-361-362-363-364-365-366-367-368-369-370-371-372-373-374-375-376-377-378-379-380-381-382-383-384-385-386-387-388-389-390-391-392-393-394-395-396-397-398-399-400-401-402-403-404-405-406-407-408-409-410-411-412-413-414-415-416-417-418-419-420-421-422-423-424-425-426-427-428-429-430-431-432-433-434-435-436-437-438-439-440-441-442-443-444-445-446-447-448-449-450-451-452-453-454-455-456-457-458-459-460-461-462-463-464-465-466-467-468-469-470-471-472-473-474-475-476-477-478-479-480-481-482-483-484-485-486-487-488-489-490-491-492-493-494-495-496-497-498-499-500-501-502-503-504-505-506-507-508-509-510-511-512-513-514-515-516-517-518-519-520-521-522-523-524-525-526-527-528-529-530-531-532-533-534-535-536-537-538-539-540-541-542-543-544-545-546-547-548-549-550-551-552-553-554-555-556-557-558-559-560-561-562-563-564-565-566-567-568-569-570-571-572-573-574-575-576-577-578-579-580-581-582-583-584-585-586-587-588-589-590-591-592-593-594-595-596-597-598-599-600-601-602-603-604-605-606-607-608-609-610-611-612-613-614-615-616-617-618-619-620-621-622-623-624-625-626-627-628-629-630-631-632-633-634-635-636-637-638-639-640-641-642-643-644-645-646-647-648-649-650-651-652-653-654-655-656-657-658-659-660-661-662-663-664-665-666-667-668-669-670-671-672-673-674-675-676-677-678-679-680-681-682-683-684-685-686-687-688-689-690-691-692-693-694-695-696-697-698-699-700-701-702-703-704-705-706-707-708-709-710-711-712-713-714-715-716-717-718-719-720-721-722-723-724-725-726-727-728-729-730-731-732-733-734-735-736-737-738-739-740-741-742-743-744-745-746-747-748-749-750-751-752-753-754-755-756-757-758-759-760-761-762-763-764-765-766-767-768-769-770-771-772-773-774-775-776-777-778-779-780-781-782-783-784-785-786-787-788-789-790-791-792-793-794-795-796-797-798-799-800-801-802-803-804-805-806-807-808-809-810-811-812-813-814-815-816-817-818-819-820-821-822-823-824-825-826-827-828-829-830-831-832-833-834-835-836-837-838-839-840-841-842-843-844-845-846-847-848-849-850-851-852-853-854-855-856-857-858-859-860-861-862-863-864-865-866-867-868-869-870-871-872-873-874-875-876-877-878-879-880-881-882-883-884-885-886-887-888-889-890-891-892-893-894-895-896-897-898-899-900-901-902-903-904-905-906-907-908-909-910-911-912-913-914-915-916-917-918-919-920-921-922-923-924-925-926-927-928-929-930-931-932-933-934-935-936-937-938-939-940-941-942-943-944-945-946-947-948-949-950-951-952-953-954-955-956-957-958-959-960-961-962-963-964-965-966-967-968-969-970-971-972-973-974-975-976-977-978-979-980-981-982-983-984-985-986-987-988-989-990-991-992-993-994-995-996-997-998-999-1000

COOPERATIVE COMPANY LIMITED
 Svedala New Zealand Limited
 14-15-16-17-18-19-20-21-22-23-24-25-26-27-28-29-30-31-32-33-34-35-36-37-38-39-40-41-42-43-44-45-46-47-48-49-50-51-52-53-54-55-56-57-58-59-60-61-62-63-64-65-66-67-68-69-70-71-72-73-74-75-76-77-78-79-80-81-82-83-84-85-86-87-88-89-90-91-92-93-94-95-96-97-98-99-100-101-102-103-104-105-106-107-108-109-110-111-112-113-114-115-116-117-118-119-120-121-122-123-124-125-126-127-128-129-130-131-132-133-134-135-136-137-138-139-140-141-142-143-144-145-146-147-148-149-150-151-152-153-154-155-156-157-158-159-160-161-162-163-164-165-166-167-168-169-170-171-172-173-174-175-176-177-178-179-180-181-182-183-184-185-186-187-188-189-190-191-192-193-194-195-196-197-198-199-200-201-202-203-204-205-206-207-208-209-210-211-212-213-214-215-216-217-218-219-220-221-222-223-224-225-226-227-228-229-230-231-232-233-234-235-236-237-238-239-240-241-242-243-244-245-246-247-248-249-250-251-252-253-254-255-256-257-258-259-260-261-262-263-264-265-266-267-268-269-270-271-272-273-274-275-276-277-278-279-280-281-282-283-284-285-286-287-288-289-290-291-292-293-294-295-296-297-298-299-300-301-302-303-304-305-306-307-308-309-310-311-312-313-314-315-316-317-318-319-320-321-322-323-324-325-326-327-328-329-330-331-332-333-334-335-336-337-338-339-340-341-342-343-344-345-346-347-348-349-350-351-352-353-354-355-356-357-358-359-360-361-362-363-364-365-366-367-368-369-370-371-372-373-374-375-376-377-378-379-380-381-382-383-384-385-386-387-388-389-390-391-392-393-394-395-396-397-398-399-400-401-402-403-404-405-406-407-408-409-410-411-412-413-414-415-416-417-418-419-420-421-422-423-424-425-426-427-428-429-430-431-432-433-434-435-436-437-438-439-440-441-442-443-444-445-446-447-448-449-450-451-452-453-454-455-456-457-458-459-460-461-462-463-464-465-466-467-468-469-470-471-472-473-474-475-476-477-478-479-480-481-482-483-484-485-486-487-488-489-490-491-492-493-494-495-496-497-498-499-500-501-502-503-504-505-506-507-508-509-510-511-512-513-514-515-516-517-518-519-520-521-522-523-524-525-526-527-528-529-530-531-532-533-534-535-536-537-538-539-540-541-542-543-544-545-546-547-548-549-550-551-552-553-554-555-556-557-558-559-560-561-562-563-564-565-566-567-568-569-570-571-572-573-574-575-576-577-578-579-580-581-582-583-584-585-586-587-588-589-590-591-592-593-594-595-596-597-598-599-600-601-602-603-604-605-606-607-608-609-610-611-612-613-614-615-616-617-618-619-620-621-622-623-624-625-626-627-628-629-630-631-632-633-634-635-636-637-638-639-640-641-642-643-644-645-646-647-648-649-650-651-652-653-654-655-656-657-658-659-660-661-662-663-664-665-666-667-668-669-670-671-672-673-674-675-676-677-678-679-680-681-682-683-684-685-686-687-688-689-690-691-692-693-694-695-696-697-698-699-700-701-702-703-704-705-706-707-708-709-710-711-712-713-714-715-716-717-718-719-720-721-722-723-724-725-726-727-728-729-730-731-732-733-734-735-736-737-738-739-740-741-742-743-744-745-746-747-748-749-750-751-752-753-754-755-756-757-758-759-760-761-762-763-764-765-766-767-768-769-770-771-772-773-774-775-776-777-778-779-780-781-782-783-784-785-786-787-788-789-790-791-792-793-794-795-796-797-798-799-800-801-802-803-804-805-806-807-808-809-810-811-812-813-814-815-816-817-818-819-820-821-822-823-824-825-826-827-828-829-830-831-832-833-834-835-836-837-838-839-840-841-842-843-844-845-846-847-848-849-850-851-852-853-854-855-856-857-858-859-860-861-862-863-864-865-866-867-868-869-870-871-872-873-874-875-876-877-878-879-880-881-882-883-884-885-886-887-888-889-890-891-892-893-894-895-896-897-898-899-900-901-902-903-904-905-906-907-908-909-910-911-912-913-914-915-916-917-918-919-920-921-922-923-924-925-926-927-928-929-930-931-932-933-934-935-936-937-938-939-940-941-942-943-944-945-946-947-948-949-950-951-952-953-954-955-956-957-958-959-960-961-962-963-964-965-966-967-968-969-970-971-972-973-974-975-976-977-978-979-980-981-982-983-984-985-986-987-988-989-990-991-992-993-994-995-996-997-998-999-1000

BARMAC B7000 DUOPACTOR
 SINGLE FEED / SINGLE DRIVE INSTALLATION
 VIBRATION CONTROL

DESIGNER: GUSTIN READ
 CHECKED: T.H.A.
 DRAWING NO: PAGE 9 OF 10

BARMAC
 DRAWING NO: INS 70SFSD9

BEARING CARTRIDGE FITTING

This form to stay with the base until stage 12 of Bearing Cartridge Fitting EDS13

Im 041

Base Number
100340

Base Type
7000

Bottom Taper Ring Outer

973342-09

Bottom Taper Ring Inner

973342-05

Unit Number

114

Bearing Cartridge


973350-08

Top Taper Ring

973341-19


Minimum Dimension "B"

MkII/9000	47
MkI/6000/7000/8000/MkII	47 mm
1800/5000	24
2400/3000	24



Minimum Dimension "A"

MkII/9000	102
MkI/6000/7000/8000/MkII	72 mm
1800/5000	48
2400/3000	38




Signed

Assembled By: *[Signature]*

Date: 97-3-95

EQPT. PART	DESCRIPTION	QTY.	ITEM
87025000	7000 DUOPACTOR (CONTINUED)	1	ASSY
87025000	3WAY POSITION ASSEMBLY (CONTINUED)	1	ASSY
10625000	DECAL "BELL TOWER"	1	1
81025000	DECAL "WARNING - DO NOT OPEN"	2	2
87025000	CHARGER SWICH ASSEMBLY (CONTINUED)	1	ASSY
10625000	HAZE MAINTENANCE	1	3
81025000	DECAL "WARNING - DO NOT OPEN"	4	4
81025000	DECAL "WARNING"	2	5
81025000	DECAL "7000 DUOPACTOR"	2	6
81025000	DECAL "DANGER - DO NOT OPEN"	2	7
81025000	NAMEPLATE PARTS	1	8
81025000	DECAL "BELL TOWER SWICH"	1	9
81025000	CHARGER SWICH ASSEMBLY (CONTINUED)	1	ASSY
81025000	DECAL "DIRECTION OF FORCE"	1	11
81025000	HEAVYWEIGHT HORIZONTAL ASSEMBLY (CONTINUED)	1	ASSY
81025000	DECAL "SYEDALA"	2	12
81025000	DECAL "DO NOT OPEN"	3	13
81025000	DECAL "DANGER"	2	14
81025000	DECAL "DANGER - DO NOT OPEN"	2	15
81025000	DECAL "WARNING"	2	16
81025000	DECAL "7000 DUOPACTOR"	2	17
81025000	DECAL "BELL TOWER SWICH"	2	18
81025000	DECAL "DIRECTION OF FORCE"	2	19
81025000	DECAL "SYEDALA"	2	20
81025000	DECAL "DO NOT OPEN"	2	21
81025000	DECAL "DANGER"	2	22
81025000	DECAL "WARNING"	2	23
81025000	DECAL "7000 DUOPACTOR"	2	24
81025000	DECAL "BELL TOWER SWICH"	2	25
81025000	DECAL "DIRECTION OF FORCE"	2	26
81025000	DECAL "SYEDALA"	2	27
81025000	DECAL "DO NOT OPEN"	2	28
81025000	DECAL "DANGER"	2	29
81025000	DECAL "WARNING"	2	30
81025000	DECAL "7000 DUOPACTOR"	2	31
81025000	DECAL "BELL TOWER SWICH"	2	32
81025000	DECAL "DIRECTION OF FORCE"	2	33
81025000	DECAL "SYEDALA"	2	34
81025000	DECAL "DO NOT OPEN"	2	35
81025000	DECAL "DANGER"	2	36
81025000	DECAL "WARNING"	2	37
81025000	DECAL "7000 DUOPACTOR"	2	38
81025000	DECAL "BELL TOWER SWICH"	2	39
81025000	DECAL "DIRECTION OF FORCE"	2	40
81025000	DECAL "SYEDALA"	2	41
81025000	DECAL "DO NOT OPEN"	2	42
81025000	DECAL "DANGER"	2	43
81025000	DECAL "WARNING"	2	44
81025000	DECAL "7000 DUOPACTOR"	2	45
81025000	DECAL "BELL TOWER SWICH"	2	46
81025000	DECAL "DIRECTION OF FORCE"	2	47
81025000	DECAL "SYEDALA"	2	48
81025000	DECAL "DO NOT OPEN"	2	49
81025000	DECAL "DANGER"	2	50
81025000	DECAL "WARNING"	2	51
81025000	DECAL "7000 DUOPACTOR"	2	52
81025000	DECAL "BELL TOWER SWICH"	2	53
81025000	DECAL "DIRECTION OF FORCE"	2	54
81025000	DECAL "SYEDALA"	2	55
81025000	DECAL "DO NOT OPEN"	2	56
81025000	DECAL "DANGER"	2	57
81025000	DECAL "WARNING"	2	58
81025000	DECAL "7000 DUOPACTOR"	2	59
81025000	DECAL "BELL TOWER SWICH"	2	60
81025000	DECAL "DIRECTION OF FORCE"	2	61
81025000	DECAL "SYEDALA"	2	62
81025000	DECAL "DO NOT OPEN"	2	63
81025000	DECAL "DANGER"	2	64
81025000	DECAL "WARNING"	2	65
81025000	DECAL "7000 DUOPACTOR"	2	66
81025000	DECAL "BELL TOWER SWICH"	2	67
81025000	DECAL "DIRECTION OF FORCE"	2	68
81025000	DECAL "SYEDALA"	2	69
81025000	DECAL "DO NOT OPEN"	2	70
81025000	DECAL "DANGER"	2	71
81025000	DECAL "WARNING"	2	72
81025000	DECAL "7000 DUOPACTOR"	2	73
81025000	DECAL "BELL TOWER SWICH"	2	74
81025000	DECAL "DIRECTION OF FORCE"	2	75
81025000	DECAL "SYEDALA"	2	76
81025000	DECAL "DO NOT OPEN"	2	77
81025000	DECAL "DANGER"	2	78
81025000	DECAL "WARNING"	2	79
81025000	DECAL "7000 DUOPACTOR"	2	80
81025000	DECAL "BELL TOWER SWICH"	2	81
81025000	DECAL "DIRECTION OF FORCE"	2	82
81025000	DECAL "SYEDALA"	2	83
81025000	DECAL "DO NOT OPEN"	2	84
81025000	DECAL "DANGER"	2	85
81025000	DECAL "WARNING"	2	86
81025000	DECAL "7000 DUOPACTOR"	2	87
81025000	DECAL "BELL TOWER SWICH"	2	88
81025000	DECAL "DIRECTION OF FORCE"	2	89
81025000	DECAL "SYEDALA"	2	90
81025000	DECAL "DO NOT OPEN"	2	91
81025000	DECAL "DANGER"	2	92
81025000	DECAL "WARNING"	2	93
81025000	DECAL "7000 DUOPACTOR"	2	94
81025000	DECAL "BELL TOWER SWICH"	2	95
81025000	DECAL "DIRECTION OF FORCE"	2	96
81025000	DECAL "SYEDALA"	2	97
81025000	DECAL "DO NOT OPEN"	2	98
81025000	DECAL "DANGER"	2	99
81025000	DECAL "WARNING"	2	100



7000 DUOPACTOR
B70250CA

11	1171 DECAL OBTAINED	1/80	51 734
12	1171 DECAL OF CHARGE	DATE	REF.
INDEXES DIVERGENT SPECIFIED: <input type="checkbox"/> NONE <input type="checkbox"/> 1/2 <input type="checkbox"/> 3/4			
BEAUCOUPLIS - ALL BEAUCOUPLIS ARE TO BE KEPT WITH PARTS BEAUCOUPLIS			
13	13	13	13
14	14	14	14
15	15	15	15
16	16	16	16
17	17	17	17
18	18	18	18
19	19	19	19
20	20	20	20
21	21	21	21
22	22	22	22
23	23	23	23
24	24	24	24
25	25	25	25
26	26	26	26
27	27	27	27
28	28	28	28
29	29	29	29
30	30	30	30
31	31	31	31
32	32	32	32
33	33	33	33
34	34	34	34
35	35	35	35
36	36	36	36
37	37	37	37
38	38	38	38
39	39	39	39
40	40	40	40
41	41	41	41
42	42	42	42
43	43	43	43
44	44	44	44
45	45	45	45
46	46	46	46
47	47	47	47
48	48	48	48
49	49	49	49
50	50	50	50
51	51	51	51
52	52	52	52
53	53	53	53
54	54	54	54
55	55	55	55
56	56	56	56
57	57	57	57
58	58	58	58
59	59	59	59
60	60	60	60
61	61	61	61
62	62	62	62
63	63	63	63
64	64	64	64
65	65	65	65
66	66	66	66
67	67	67	67
68	68	68	68
69	69	69	69
70	70	70	70
71	71	71	71
72	72	72	72
73	73	73	73
74	74	74	74
75	75	75	75
76	76	76	76
77	77	77	77
78	78	78	78
79	79	79	79
80	80	80	80
81	81	81	81
82	82	82	82
83	83	83	83
84	84	84	84
85	85	85	85
86	86	86	86
87	87	87	87
88	88	88	88
89	89	89	89
90	90	90	90
91	91	91	91
92	92	92	92
93	93	93	93
94	94	94	94
95	95	95	95
96	96	96	96
97	97	97	97
98	98	98	98
99	99	99	99
100	100	100	100

SVEDALA
 Svedala Zepmax Limited
 Magnetics Unit, Fleet Rd, 4011, Lymington, Hampshire, UK PO15 1JH

CONFIDENTIAL © COPYRIGHT 1988
 Copyright in this drawing, including:
 Svedala Zepmax Limited
 Svedala Zepmax Limited
 The design of the drawing and the method of producing it, and all other rights reserved by patent, design, copyright, or otherwise, are the property of Svedala Zepmax Limited. Unauthorised distribution of this product is strictly prohibited.

BARRAC 7000 DUOPACTOR ASSEMBLY
DECAL / NAMEPLATE POSITIONS

DESIGNED: *G. Taylor*
 DRAWN: GARTIE TAYLOR





ISSUED: *G. Taylor*
 PART: Aug 0 or 0
 ISSUE: *G. Taylor*

DATE: 15 / 1 / 95
 DRAWING NUMBER: B70250CA

TAZA1

DESCRIPTION	QTY	UNIT
SAFETY INTERLOCK KIT	1	KIT
DEADBOLT CAM	1	UNIT
DOOR LOCK, TIMER BOX & DEADBOLT	1	UNIT
REAR MOUNT CAM	1	UNIT
KEYS	2	PAIRS
DOOR INTERLOCK BOLT SET	1	SET
BOLT SET 1/2" x 25 GRADE 8	2	PCS
NUTS 1/2"	4	PCS
WASHERS 1/2"	4	PCS
DRUMS 1/2" x 15 GRADE 8	2	PCS
4mm POST ALLEN KEY	1	PCS
DOOR SAFETY INTERLOCK MANUAL	1	BOOK

DOOR LOCK, TIMER BOX & DEADBOLT
B96A111B



SAFETY INTERLOCK KIT
B96A110B

DEADBOLT CAM
B96A114A



2	ASSEMBLY DRAWING	10/97	ES 317
1	INTERLOCK UNIT CHANGED	4/93	ES 178
REV.	DETAIL OF CHANGE	DATE	BY:

CONTRACTOR'S COPY/PRINT 1997
Copyright © 1997
Svedala Garmaac Limited
Unauthorized use and/or modification is prohibited. Any use without the written consent of Svedala Garmaac Limited is prohibited.

SVEDALA
Svedala Garmaac Limited
Magnusson Blvd, P.O. Box 401, Birmans, Wis. 53001
Telephone: 414 7 833331 Fax: 414 7 833332

BARMAC 9600 DUOPACTOR
SAFETY INTERLOCK KIT


DRAWN	J. J. J. J.	M. J. J. J.
CHECKED	J. J. J. J.	
DRAWING PART NO.	1	OF 1
ISSUE NO.		OF

ISSUE REFERENCE
101165
ISSUE DATE
22 / 10 / 97
ISSUE NUMBER
B96 A110B

UNLESS OTHERWISE SPECIFIED:	STANDARD	34
REVISIONS		
- ALL DIMENSIONS ARE TO BE KEPT UNLESS OTHERWISE SPECIFIED		
NO.	DATE	BY
1	10/97	ES 317
2	4/93	ES 178
3	10/97	ES 317
4	10/97	ES 317
5	10/97	ES 317
6	10/97	ES 317
7	10/97	ES 317
8	10/97	ES 317
9	10/97	ES 317
10	10/97	ES 317
11	10/97	ES 317
12	10/97	ES 317
13	10/97	ES 317
14	10/97	ES 317
15	10/97	ES 317
16	10/97	ES 317
17	10/97	ES 317
18	10/97	ES 317
19	10/97	ES 317
20	10/97	ES 317
21	10/97	ES 317
22	10/97	ES 317
23	10/97	ES 317
24	10/97	ES 317
25	10/97	ES 317
26	10/97	ES 317
27	10/97	ES 317
28	10/97	ES 317
29	10/97	ES 317
30	10/97	ES 317
31	10/97	ES 317
32	10/97	ES 317
33	10/97	ES 317
34	10/97	ES 317
35	10/97	ES 317
36	10/97	ES 317
37	10/97	ES 317
38	10/97	ES 317
39	10/97	ES 317
40	10/97	ES 317
41	10/97	ES 317
42	10/97	ES 317
43	10/97	ES 317
44	10/97	ES 317
45	10/97	ES 317
46	10/97	ES 317
47	10/97	ES 317
48	10/97	ES 317
49	10/97	ES 317
50	10/97	ES 317
51	10/97	ES 317
52	10/97	ES 317
53	10/97	ES 317
54	10/97	ES 317
55	10/97	ES 317
56	10/97	ES 317
57	10/97	ES 317
58	10/97	ES 317
59	10/97	ES 317
60	10/97	ES 317
61	10/97	ES 317
62	10/97	ES 317
63	10/97	ES 317
64	10/97	ES 317
65	10/97	ES 317
66	10/97	ES 317
67	10/97	ES 317
68	10/97	ES 317
69	10/97	ES 317
70	10/97	ES 317
71	10/97	ES 317
72	10/97	ES 317
73	10/97	ES 317
74	10/97	ES 317
75	10/97	ES 317
76	10/97	ES 317
77	10/97	ES 317
78	10/97	ES 317
79	10/97	ES 317
80	10/97	ES 317
81	10/97	ES 317
82	10/97	ES 317
83	10/97	ES 317
84	10/97	ES 317
85	10/97	ES 317
86	10/97	ES 317
87	10/97	ES 317
88	10/97	ES 317
89	10/97	ES 317
90	10/97	ES 317
91	10/97	ES 317
92	10/97	ES 317
93	10/97	ES 317
94	10/97	ES 317
95	10/97	ES 317
96	10/97	ES 317
97	10/97	ES 317
98	10/97	ES 317
99	10/97	ES 317
100	10/97	ES 317

TM 291

COMPONENT	DESCRIPTION	QTY.	QTY.
668AS20	ROTOR BALANCE MACHIN	1-ASSEMBLY	1
558AS21	ROTOR BALANCE SIDE FRAME	2	2
108AS22	ROTOR BALANCE OIL SPRAYER	2	2
038AS23	ROTOR BALANCE 15 mm	4	4
038AS24	ROTOR BALANCE SHAFT	1	1
668AS25	ROTOR BALANCE SHIRT WASHER	1	1
883AS26	ROTOR BALANCE ASSEMBLY	2	2
884AS27	ROTOR BALANCE AIR TUBE	1 SET	1
727 AS 28	ROTOR BALANCE AIR TUBE	0	0
WASHER 120	ROTOR BALANCE LOCKWASH	1	1
108AS22	ROTOR BALANCE LOCKWASH	1	1




1	ASSEMBLY DRAWING	12/97	CS 710
REV.	DETAIL OF CHANGE	DATE	REF.
UNLESS OTHERWISE SPECIFIED:		PROJECTION	3rd ANGLE
INCLUDES: SIZES			
- ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED ARE IN MILLIMETERS			
25	25 mm	
32	32 mm	
40	40 mm	
50	50 mm	
63	63 mm	
80	80 mm	
100	100 mm	
125	125 mm	
160	160 mm	
200	200 mm	
- ALL DIMENSIONS TO BE SHOWN UNLESS OTHERWISE SPECIFIED			

 Svedala	Svedala Machine Limited Svedala 654 020, Sweden, Tel: 0422 4000 Fax: 0422 4001	COPYRIGHT © COPYRIGHT 1997 Svedala Machine Limited	
		No part of this drawing may be reproduced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of Svedala Machine Limited.	
BARMAC 690 ROTOR ROTOR BALANCE MACHINE		DRAWN: GARTH TAYLOR CHECKED: <i>[Signature]</i> NUMBER OF PARTS: 1 ISSUE NO: 1	DATE RECEIVED: 10/17/97 REQUISITION NUMBER: 1001161-1 DRAWING NUMBER: 669 AS20

(M24)

QTY	DESCRIPTION	UNIT	ITEM
1	SKID FRAME KIT	SET	1
1	SKID FRAME KIT	SET	1
1	SKID FRAME KIT	SET	1
1	SKID FRAME KIT	SET	1
1	SKID FRAME KIT	SET	1
1	SKID FRAME KIT	SET	1
1	SKID FRAME KIT	SET	1
1	SKID FRAME KIT	SET	1
1	SKID FRAME KIT	SET	1
1	SKID FRAME KIT	SET	1



SKID FRAME KIT
B90AP208

UNLESS OTHERWISE SPECIFIED:	FULL SIZE	3:1 SCALE
DIMENSIONS		
- ALL DIMENSIONS UNLESS NOTED OTHERWISE ARE IN MILLIMETERS		
WEIGHT	8 kg	
LENGTH	2200 mm	
WIDTH	440 mm	
HEIGHT	220 mm	
DEPTH	100 mm	
AREA	270 mm	
VOLUME	610 mm	
MAX. WEIGHT	14 kg	
MAX. HEIGHT	14 mm	
- ALL DIMENSIONS TO BE TAKEN TO CENTRE UNLESS NOTED OTHERWISE		

1	ASSEMBLY INSTRUCTIONS	14/97	CS 737
2	EXPLODED VIEW	5/97	CS 650
REV. DETAIL OF CHANGE		DATE	REV.
DRAWN: GARTH TAYLOR			
CHECKED: <i>L. S. Scott</i>			
DESIGNER:	DATE:	REV.:	
ISSUE:	NO.:	OF:	

BARRHAC 9000 DUOPACTOR
SKID FRAME KIT

Copyright © Copyright 1997
Svedala Barrhac Limited
Barrhac is a registered trade mark
of Svedala Barrhac Limited
The subject of this drawing may be protected by patents
and other intellectual property rights in certain countries.
Unauthorized reproduction of this
drawing is strictly prohibited.

SVEDALA
Svedala Barrhac Limited
Lindbergs Park, P.O. Box 481, Halmstad, SE-301 21
Tel: +46 41 68828 Fax: +46 41 68814

ISSUE REFERENCE	REVISION NUMBER
16077/100161-1	
DRAWING DATE	DEPARTING NUMBER
12 / 31 / 97	B90 AP208

T M 241


CONFIDENTIAL	DESCRIPTION	QTY.	ITEM
	SUPPORT LEG SET - LONG	1	896AP15
	SUPPORT LEG - LONG	2	
	LEG FOOT SET	1	SET
	WASHER 1/2" X 1/4" X 1/4" GRACE B.6	8	2
	NUT / NUT 1/2" X 1/4" X 1/4" GRACE B.6	12	3
	WASHER 1/2" X 1/4" X 1/4"	12	4
	NUTS 1/2" X 1/4" X 1/4"	17	5



NOTE: 470 X 65 BOLTS NOT TO BE USED ON CRUISE DRIVE ASSEMBLY

SUPPORT LEG SET - LONG
896AP15

2 LEGS EACH LEFT AND RIGHT HAND



Svecala Baromatic Limited
Preston Road, Walsby, York, YO21 2JF, England
Telephone: 447 8252296 Facsimile: 447 8252294

CONFIDENTIAL © COPYRIGHT 1987
Copyright in this design belongs to
Svecala Baromatic Limited
Unauthorized use may result in legal action.
The design of this assembly may be protected by patent,
design and design registration or other intellectual property
rights. Where any such rights exist, they are hereby asserted.

BAROMATIC 9600 DUOPACTOR
SUPPORT LEG SET - LONG

DRAWN: GARTH TAYLOR
CHECKED: *J. Lee*
DATE: 12 / 11 / 97
ISSUE: 1
REV: 1

ISSUE REFERENCE: 101175
ISSUE DATE: 12 / 11 / 97
ISSUE NUMBER: 1001161-1
DRAWING NUMBER: 896 AP15


1	ASSEMBLY (UPDATED)	11/97	CS 710
	REV. DETAIL OF CHANGE	DATE	REV.
UNLESS OTHERWISE SPECIFIED:			
DIMENSIONS IN MILLIMETERS			

DESIGNED BY: [Signature]
- ALL DIMENSIONS IN MILLIMETERS UNLESS OTHERWISE SPECIFIED -
SCALE: 1:1

14 8 mm
15 10 mm
16 12 mm
17 14 mm
18 16 mm
19 18 mm
20 20 mm
21 22 mm
22 24 mm
23 26 mm
24 28 mm
25 30 mm
26 32 mm
27 34 mm
28 36 mm
29 38 mm
30 40 mm
31 42 mm
32 44 mm
33 46 mm
34 48 mm
35 50 mm
36 52 mm
37 54 mm
38 56 mm
39 58 mm
40 60 mm
41 62 mm
42 64 mm
43 66 mm
44 68 mm
45 70 mm
46 72 mm
47 74 mm
48 76 mm
49 78 mm
50 80 mm
51 82 mm
52 84 mm
53 86 mm
54 88 mm
55 90 mm
56 92 mm
57 94 mm
58 96 mm
59 98 mm
60 100 mm

T M 241

BARMAC™ VSI CRUSHER DOOR SAFETY INTERLOCK



Installation, Operation and Service Manual

SVEDALA



CONTENTS

INTRODUCTION	Section 1
INSTALLATION	Section 2
OPERATION	Section 3
PARTS REPLACEMENT	Section 4

Manufacture and design of the Barpac cracker is carried out under quality control systems certified to ISO 9001 by Svedala Barpac Product Group. Distributed worldwide under the following granted and pending patents and design applications: New Zealand 149307, 101150, 215110, 212752, 212753, 250027, 22225, 21927, 22829, 23360, 23471, 25474, 251457, 248114, 248955, 248952, 250134, 237492, 218110; Australia 357148, 462254, 394387, 623114, 646713; USA 4662571, 453664, 4924173, 4940194; Canada 1179945, 1229633, 1263722, 1101135; Japan 1544266, 1620260, 15786086, 37281202; South Africa 326574, 3273113, 3473802, 3611041, 3578662, 3639325, 3879433; United Kingdom 0074771, 0191277, 226492, 2284107, 2246110, 216392; France 0074771, 0101277, 216392, 88-17029; Italy 0074771, 0101277, 216392; Sweden 2194652, 2101277, 216392; Austria 216392; Federal Republic of Germany 3273526.1, 0101277, 216392; Europe 0074771, 0101277, 216392; Mexico 154315. BARPAC, ROTOPACTOR and DUOPACTOR are trade marks owned by SVEDALA BARPAC LIMITED and registered in many countries in the world. BARSLAG and BARSLAG DUOPACTOR trade marks are registered in the United States in the name of SVEDALA INDUSTRIES INC. Due to a policy of continuous development the right is reserved to make changes in specifications and design. Drawings are nominal and may vary more or less with operating conditions.

Introduction

The safety interlock device fitted to your Barnac Duopactor crusher is designed to restrict access to the crushing chamber while the rotor is in motion.

This system has been incorporated in the Barnac crusher in the interests of operator safety, and once installed and set, should not be tampered with or any attempt to bypass it be made.

This manual contains instructions on the installation and operation, which when followed should provide trouble-free operation.

In the event of breakage there is a list of replacement parts available from your local Barnac crusher dealer.




Installation


DOOR LOCK

Bolt the door lock components to the Barmac as shown.

1. For 2400/B3000



2. For 4800/B5000




Continued ►

2

INSTALLATION

3. For B6000 and larger machines



Continued ►

INSTALLATION

TIMER BOX (Serial Nos. TIL 001 - TIL 182)

1. **INSTALLATION** — See schematic section 2-5.
 - (a) Mount the unit to a convenient vertical surface, using the four fixing holes provided. The unit should be mounted in a position where it will not be subjected to vibration, water splash or excessive dust.
 - (b) Open hinged doors to expose internals of timer box. Unscrew plastic grommet and drill to suit cable entry. Ensure cable fits snugly in plastic grommet. After all connections have been made seal around cable entry with sealant.

2. **CONTROL SUPPLY CONNECTIONS (TERMINALS 7 & 8)**

Before connecting the incoming cables it must be ascertained what the control supply voltage is, i.e. 440/240/110V 50/60 Hz.

All H31ET units are supplied for use with 440V control supply.

For use on a 240V or 110V control supply, the flying lead voltage tapping on the printed circuit board assembly must be re-connected to the appropriate voltage connection (Faston tags marked with voltage).

- (a) 440V/380V (2 PHASE & EARTH)

Connect the incoming 440/380V supply through a two pole isolator and two 2 amp fuse links to terminals 7 and 8, also connect the earth (terminal 13/Yellow) to the factory earth.

- (b) 240V (SINGLE PHASE L, N & EARTH)

Connect the line and neutral supply via a single pole and neutral isolator, with a 2A fuse link in the circuit, to terminals 7 and 8 (live to terminal 8, neutral to terminal 7 and earth to terminal 13 Green/Yellow).

Note 1

Reconnect the control supply flying lead on the printed circuit board assembly from the 440V terminal lug to the 240V terminal lug (as advised 1b).

Note 2

Ensure that the earthed (neutral) side of the supply is connected to terminal 7.

- (c) 110V (SINGLE PHASE L, N & EARTH)

Connect the live and neutral supply via a single pole and neutral isolator, with a 2A fuse link in the circuit, to terminals 7 and 8 (live to terminal 8, neutral to terminal 7 and earth to terminal 13 Green/Yellow).

Continued ►

INSTALLATION

Note 1

Reconnect the control supply flying lead on the printed circuit board assembly, for the 440V terminal lug to the 110V terminal lug (as advised 1b).

Note 2

Ensure that at the earthed (Neutral) side of the supply is connected to terminal 7.

- (d) It should be noted that a 110V supply derived from a centre tapped isolating transformer is not recommended (see BS5304 [1975] Fig. 85).

3. EARTH CONNECTION

Earth the H31ET using the earth terminal and replace the side cover plate.

4. SETTING UP AND TESTING

- (a) With the shutout key (isolator key) removed from the unit, switch on all supplies. Check that the access key (guard key) cannot be removed at this stage.
- (b) Switch off all supplies. Carefully open the front cover and set the internal timer to approximately 10 seconds delay. Reclose the front cover and switch the incoming supplies on.

Do not start the machine.

Insert the shutout key (isolator key) and turn to the trapped position. Check that the access key (guard key) can be removed after about 10 seconds and that the 'Key Free' lamp illuminates.

Note

The access key (guard key) will not release and the 'Key Free' lamp will not illuminate if any of the following conditions exist:

1. The timer is incorrectly set.
2. The internal 500 mA fuse has blown.

- (c) Check that when the access key (guard key) is removed, the shutout key (isolator key) is trapped.
- (d) Finally set the internal timer to give a safe run-down time of the rotor such that the access key (guard key) will never be released until the rotor is safely at rest.

5. MAINTENANCE

- (a) Periodically check that the unit functions correctly and that the time delay is still correct.
- (b) If internal fuse blows, replace with a 20mm quick blow, 500mA type, e.g. R.S. Components 412-122.

Continued ►

INSTALLATION

TIMER BOX - 24V to 415V (Serial Nos. TIL 183 - TIL 279)

1. **INSTALLATION** — See schematic section 2-8.

- (a) Mount the unit to a convenient vertical surface, using the four fixing holes provided. The unit should be mounted in a position where it will not be subjected to vibration, water splash or excessive dust.
- (b) Open hinged doors to expose internals of timer box. Unscrew plastic grommet and drill to suit cable entry. Ensure cable fits snugly in plastic grommet. After all connections have been made seal around cable entry with sealant.

2. **CONTROL SUPPLY CONNECTIONS (TERMINALS 7 & 8)**

Before connecting the incoming cables it must be ascertained what the control supply voltage is, i.e. 440/240/110/24V 50/60 Hz.

All H31ET units are supplied for use with 440V control supply.

For use on a 240V, 110V or 24V control supply, the flying lead voltage tapping on the printed circuit board assembly must be re-connected to the appropriate voltage connection (Faston tags marked with voltage).

(a) 440V/380V (2 PHASE & EARTH)

Connect the incoming 440/380V supply through a two pole isolator and two 2 amp fuse links to terminals 7 and 8, also connect the earth (terminal 13/Yellow) to the factory earth.

(b) 240V (SINGLE PHASE L, N & EARTH)

Connect the line and neutral supply via a single pole and neutral isolator, with a 2A fuse link in the circuit, to terminals 7 and 8 (live to terminal 8, neutral to terminal 7 and earth to terminal 13 Green/Yellow).

Note 1

Reconnect the control supply flying lead on the printed circuit board assembly from the 440V terminal lug to the 240V terminal lug (as advised 1b).

Note 2

Ensure that the earthed (neutral) side of the supply is connected to terminal 7.

(c) 110v (SINGLE PHASE L, N & EARTH)

Connect the live and neutral supply via a single pole and neutral isolator, with a 2A fuse link in the circuit, to terminals 7 and 8 (live to terminal 8, neutral to terminal 7 and earth to terminal 13 Green/Yellow).

Note 1

Reconnect the control supply flying lead on the printed circuit board assembly, for the 440V terminal lug to the 110V terminal lug (as advised 1b).

Continued ►

INSTALLATION

Note 2

Ensure that the earthed (Neutral) side of the supply is connected to terminal 7.

Note 3

It should be noted that a 110V supply derived from a centre tapped isolating transformer is not recommended (see BS5304 [1975] Fig. 85).

- (d) 24V (DIRECT CURRENT L, N)

Connect the positive and negative supply to terminals 7 (live, positive) and 8 (neutral, negative) and the earth to terminal 13 (earth, green/yellow).

3. EARTH CONNECTION

Earth the H31ET using the earth terminal and replace the side cover plate.

4. SETTING UP AND TESTING

- (a) With the shutout key (isolator key) removed from the unit, switch on all supplies. Check that the access key (guard key) cannot be removed at this stage.
- (b) Switch off all supplies. Carefully open the front cover and set the internal timer to approximately 10 seconds delay. Reclose the front cover and switch the incoming supplies on.

Do not start the machine.

Insert the shutout key (isolator key) and turn to the trapped position. Check that the access key (guard key) can be removed after about 10 seconds and that the 'Key Free' lamp illuminates.

Note

The access key (guard key) will not release and the 'Key Free' lamp will not illuminate if any of the following conditions exist:


1. The timer is incorrectly set.
 2. The internal 500 mA fuse has blown.
- (c) Check that when the access key (guard key) is removed, the shutout key (isolator key) is trapped.
- (d) Finally set the internal timer to give a safe run-down time of the rotor such that the access key (guard key) will never be released until the rotor is safely at rest.

5. MAINTENANCE

- (a) Periodically check that the unit functions correctly and that the time delay is still correct.
- (b) If internal fuse blows, replace with a 20mm quick blow, 500mA type, e.g. R.S. Components 412-122.

Continued ►

INSTALLATION



TIME DELAY INTERLOCK H31ET CIRCUIT DIAGRAM

Continued ▶

DIAPHRAGM

INSTALLATION

TIMER BOX – 24V to 415V (Serial Nos. TIL 280 -)

1. **INSTALLATION** — See schematic diagram section 2-11.
 - (a) Mount the unit to a convenient vertical surface, using the four fixing holes provided. The unit should be mounted in a position where it will not be subjected to vibration, water splash or excessive dust.
 - (b) Remove screws from the corners of the unit and remove lid slowly from base. Drill hole to suit cable entry and fit grommet. After all connections have been made seal around cable entry with sealant.

2. **CONTROL SUPPLY CONNECTIONS (TERMINALS L, N & E)**

Before connecting the incoming cables it must be ascertained what the control supply voltage is, i.e. 440/240/110/24V 50/60 Hz.

All H31ET units are supplied for use with 440V control supply.

For use on a 240V, 110V or 24V control supply, the flying lead voltage tapping on the printed circuit board assembly must be re-connected to the appropriate voltage connection (Faston tags marked with voltage).

(a) 440V/380V (2 PHASE & EARTH)

Connect the incoming 440/380V supply through a two pole isolator and two 2 amp fuse links to terminals L and N, also connect the earth (terminal E) to the factory earth.

(b) 240V (SINGLE PHASE L, N & EARTH)

Connect the line and neutral supply via a single pole and neutral isolator, with a 2A fuse link in the circuit, to terminals L (live) and N (neutral). Connect earth to terminal E (earth).

Note 1

Reconnect the control supply flying lead on the printed circuit board assembly from the 440V terminal lug to the 240V terminal lug (as advised. 1b).

Note 2

Ensure that the earthed (neutral) side of the supply is connected to terminal N.

(c) 110V (SINGLE PHASE L, N & EARTH)

Connect the live and neutral supply via a single pole and neutral isolator, with a 2A fuse link in the circuit, to terminals L (live) and N (neutral). Connect earth to terminal E (earth).

Note 1

Reconnect the control supply flying lead on the printed circuit board assembly from the 440V terminal lug to the 220V terminal lug (as advised 1b).

Continued ►

INSTALLATION

Note 2

Ensure that the earthed (neutral) side of the supply is connected to terminal N.

Note 3

It should be noted that a 110V supply derived from a centre tapped isolating transformer is not recommended (see BS5304 [1975] Fig. 85).

(d) 24V (DIRECT CURRENT L, N)

Connect the positive and negative supply to terminals L (live, positive) and N (neutral, negative). Connect earth to terminal E (earth).

Note 1

Reconnect the control supply flying lead on the printed circuit board assembly from the 440V terminal lug to the 24V terminal lug (as advised 1b).

3. EARTH CONNECTION

Earth the H31ET using the earth terminal and replace lid.

4. SETTING UP AND TESTING

(a) With the shutout key (isolator key) removed from the unit, switch on all supplies. Check that the access key (guard key) cannot be removed at this stage.

(b) Switch off all supplies. Carefully open the front cover and set the internal timer to five minutes (minimum delay time). Reclose the front cover and switch the incoming supplies on.

Do not start the machine.

Insert the shutout key (isolator key) and turn to the trapped position. Check that the access key (guard key) can be removed after five minutes (minimum delay time) and that the 'Key Free' lamp illuminates.

Note

The access key (guard key) will not release and the 'Key Free' lamp will not illuminate if any of the following conditions exist:

1. The timer is incorrectly set.
2. The internal 500 mA fuse has blown.

(c) Check that when the access key (guard key) is removed, the shutout key (isolator key) is trapped.

(d) Finally set the internal timer to give a safe run-down time of the rotor such that the access key (guard key) will never be released until the rotor is safely at rest. The timer can be set from a minimum of 5 minutes to a maximum of 15 minutes.


5. MAINTENANCE

(a) Periodically check that the unit functions correctly and that the time delay is still correct.

(b) If internal fuse blows, replace with a 20mm quick blow, 500mA type, e.g. R.S. Components 412-122.

Continued ►

INSTALLATION



TIME DELAY INTERLOCK H31ET CIRCUIT DIAGRAM

Continued ►




INSTALLATION

DEAD LOCK AND CAM

The dead lock and cam are installed behind the front panel of the starter and work in conjunction to provide the isolating switch with lockout protection.


Install the dead lock and cam as pictured below.




1. Install on starter front panel so that extended pin prevents starting of the Barmac crusher.
2. The Barmac crusher power supply must be isolated before the pin is able to be extended.

Continued ►

INSTALLATION




BARMAC CRUSHER STARTER PANEL



This dead lock cam is supplied with the interlock kit and can be used in conjunction with the dead lock to provide the isolator with lockout protection. The cam will suit any rotating isolator switch with 90° turn operation and 6, 8 or 12mm shank (1/4", 5/16" or 15/32").

If this is unsuitable, your Barmac crusher dealer will be able to advise on a suitable alternative.




Operation

This Safety Interlock System is designed to prevent the crushing chamber service door from being opened while the machine is in operation or on shut-down before sufficient time has elapsed to allow the rotor to stop rotating.

The interlock also prevents accidental start-up while the crusher is being serviced, or when the door is left open.

SEQUENCE OF OPERATION



Isolate Barmac crusher power supply then:

- ① Turn Shutout Key in Deadlock and remove key.
- ② Put Shutout Key in Shutout Lock and turn.
- ③ After time delay has elapsed, turn and remove Access Key.
- ④ Put Access Key in Access Lock and turn.
- ⑤ Release Bolt and open door.

To close door, engage bolt and transfer keys through reverse sequence.
(Time delay will not activate in reverse sequence).



Parts Replacement

Replacement parts can be obtained from either your local Barmac crusher representative or direct from a Fortress Security distributor.

If ordering from a Barmac crusher dealer, please quote description and Barmac crusher part number.

If ordering from a Fortress Security dealer, quote only the description.

FORTRESS OUTLETS:

Australia: Fortress Security Pty Ltd
No. 4 Jarrah Street, Braeside, Victoria, Australia.
Tel: 3-9587 4099. Fax: 3-9587 4130.

United Kingdom: Fortress UK
148 Birmingham New Road, Wolverhampton. WV4 6NT.
Tel: (0902) 403546. Fax: (0902) 353003.

United States: Castell Safety Incorporated
Erlager, Kent. J
Tel: 606 3413075.

When repairs have been completed, it is important to test the total operation of the safety interlock system. (Refer to installation section, instruction number 4).

IT IS NOT SAFE TO RESTART THE CRUSHER UNTIL THE SAFETY INTERLOCK SYSTEM IS FUNCTIONING CORRECTLY.

IMPORTANT NOTE
WARRANTY CLAIMS

Fortress Security Pty Ltd (manufacturer) and Svedala Barmac Ltd (supplier) will not be held liable for any injury or warranty claims resulting from substandard repair work.

If you do not feel competent to carry out the repair work yourself, refer to your local Barmac crusher dealer or Fortress agent for further instruction.

Continued ►



PARTS REPLACEMENT

BARMAC PART NUMBER


B24A11A/100

DOOR LOCK H31CN/RE

(Barmac 2400/3000 Duopactors Only)

Standard Construction

Stainless Steel Internals



When ordering individual replacement components, quote the description below. If ordering from your Barmac crusher dealer, quote the Barmac part number also.

- ❶ Stainless Steel Self Aligning Bolt Assembly to suit H31CN/RE (Type H31C-19)
- ❷ Rubber Seal to suit Stainless Steel Cap
- ❸ Stainless Steel Cap (including spring and grub screws)
- ❹ Basic Lock with Stainless Steel internals. Type H31LH to suit H31CN/RE
- ❺ Internal Cam to suit H31CN/RE

BARMAC PART NUMBER

B24A11A/101

B96A11B/102

B96A11B/103

B24A11A/104

B24A11A/105

NOTE: When ordering a replacement lock (item 4), or complete unit, also quote the code and differ numbers, as these are unique to your installation. These code and differ numbers can be found on the key or the face of the lock and lock cover.

Continued ►

PARTS REPLACEMENT

DOOR LOCK H31CN/LE


(All models except Barmac 2400/3000 Duopactors)

Standard Construction

Stainless Steel Internals

BARMAC PART NUMBER

B96A11B/100



When ordering individual replacement components, quote the description below. If ordering from your Barmac crusher dealer, quote the Barmac part number also.

- ① Stainless Steel Self Aligning Bolt Assembly to suit H31CN/LE (Type H31C-29)
- ② Rubber Seal to suit Stainless Steel Cap
- ③ Stainless Steel Cap (including spring and grub screws)
- ④ Basic Lock with Stainless Steel internals.
Type H31RH to suit H31CN/LE.
- ⑤ Internal Cam to suit H31CN/LE

BARMAC PART NUMBER

B96A11B/101

B96A11B/102

B96A11B/103

B96A11B/104

B96A11B/105

NOTE: When ordering a replacement lock (item 4), or complete unit, also quote the code and differ numbers, as these are unique to your installation. These code and differ numbers can be found on the key or the face of the lock and lock cover.

Continued ►



BARMAC


PARTS REPLACEMENT

TIMER BOX H31ET1
(Serial Nos. TIL 001 - TIL 279)

Standard Construction
Stainless Steel Internals
Rating IP55

BARMAC PART NUMBER

B96A111B/200



When ordering individual replacement components, quote the description below. If ordering from your Barmac crusher dealer, quote the Barmac part number also.

- ❶ Basic Lock to suit H31ET1
- ❷ Fuse 500 mA

BARMAC PART NUMBER

B96A111B/201

B96A111B/202

NOTE: When ordering a replacement lock (item 1), or complete unit, also quote the code and differ numbers, as these are unique to your installation. These code and differ numbers can be found on the keys or the faces of the locks and lock covers.

NOTE: Early models of the timer box were rated to IP42. These units utilise the same replacement components as the IP55 rated box described above.

Continued ►

BARMAC

PARTS REPLACEMENT


TIMER BOX H31ET1

(Serial Nos. TIL 280 -)

Standard Construction
Stainless Steel Internals
Rating IP55

BARMAC PART NUMBER

B96A111B/200



When ordering individual replacement components, quote the description below. If ordering from your Barmac crusher dealer, quote the Barmac part number also.

- ① Fuse 500mA
- ② Basic Lock with Stainless Steel internals.
Type H31RH to suit IP55 Timer Unit
- ③ Stainless Steel Cap (including spring and grub screws)
- ④ Rubber Seal to suit Stainless Steel Cap
- ⑤ 4mm Post Allen Key

BARMAC PART NUMBER

B96A111B/202

B96A111B/104

B96A111B/103

B96A111B/102

B96A1164A

NOTE: When ordering a replacement lock (item 2), or complete unit, also quote the code and differ numbers, as these are unique to your installation. These code and differ numbers can be found on the keys or the faces of the locks and lock covers.

Continued ►


PARTS REPLACEMENT

DEADLOCK H31QDS - SHOT (All Models)

Standard Construction
Stainless Steel Internals

BARMAC PART NUMBER

B96A111B/300



When ordering individual replacement components, quote the description below. If ordering from your Barmac crusher dealer, quote the Barmac part number also.

- ① Earless Basic Lock with Stainless Steel internals to suit H31QDS
- ② 3mm Roll Pin (3 off) and 4mm Roll Pin (3 off)

BARMAC PART NUMBER

B96A111B/301

B96A111B/302

To remove earless basic lock, drill out 3 roll pins (carefully) with 3mm ($\frac{1}{8}$ ") drill.

To replace, position bolt in housing and place drive block in slot in bolt.

Ensure orientation of drive block is such that pin is closest to right hand side of drive block when viewed with the bolt down.

Insert new lock (lid hinge up) and drill holes for roll pins.

Check function of lock and then fit replacement roll pins.

If the holes in the housing were damaged whilst drilling out the original roll pins, it may be necessary to drill the new lock with a 4mm ($\frac{1}{4}$ ") drill and fit 4mm roll pins.


NOTE: When ordering a replacement lock (item 1), or complete unit, quote the code and differ numbers also as these are unique to your installation. These code and differ numbers can be found on the key or the face of the lock and lock cover.

Continued ►

BARMAC

PARTS REPLACEMENT

KEYS (All Models)




When ordering replacement keys, quote the following:

- Description as listed below;
- Code and differ number found on the existing key (as these are unique to your installation); and
- Barmac crusher part number (if ordering from your Barmac crusher dealer).

- Key (Stainless Steel) - H31
- Danger - Spare Key (Brass) - H31

BARMAC PART NUMBER
B96A111B/401
B96A111B/402




IMPORTANT: The spare key has been supplied for use in an emergency. If circumstances arise that this key needs to be used, a replacement for the original must be ordered immediately. The brass key has a shorter life expectancy than the original stainless steel key.

When the replacement key arrives, return the spare key to its original package and store in a secure place.

SVEDALA CRUSHING & SCREENING

BARMAC™ VSI CRUSHER VIBRATION CONTROL KIT



**Installation, Operation and
Service Manual**

SVEDALA



CONTENTS

1 INTRODUCTION

2 INTEGRATED ELECTRONIC VIBRATION CONTROL KIT

(Solenoid Reset Vibration Switch)

Layout	1
Circuit Diagram	2-3
Mounting Details	4-7
Wiring Instructions	8-10
Operation	11-12
Adjustment/Calibration	13
Servicing	14
Parts Replacement	15-16

3 BASIC VIBRATION CONTROL KIT

(Manual Reset Vibration Switch)

Layout	1
Circuit Diagram	2
Mounting Details	3-4
Wiring Instructions	5-6
Operation	7
Adjustment/Calibration	8
Servicing	9
Parts Replacement	10

Manufacture and design of the Barmac member is carried out under quality control systems certified to ISO 9001 by Svedala Barmac Product Group. Distributed world-wide under the name printed and pending patents and design applications: New Zealand 198107, 201390, 213510, 217712, 217753, 218027, 219028, 21927, 21929, 21967, 21473, 21474, 21457, 218954, 953, 248952, 250144, 227492, 238248; Australia 557168, 552251, 334367, 623618, 640713; USA 4662573, 4838663, 4923177, 4940188; Canada 1189045, 1121933, 1265772; Japan 43264, 1620042, 25786356, 32246493; South Africa 825374, 8205817, 8407002, 3529045, 8473561, 8579124, 8579482; United Kingdom 0074771, 0101277, 216492, 2174107, 2168410; France 43264, 1620042, 25786356, 32246493; Italy 0074771, 0101277, 216492; Sweden 8259452.9, 0101277, 216492; Austria 216492; Federal Republic of Germany 216492 R, 0101277, 216492; 4271, 0101277, 216492, 48-17503; Mexico 164329. BARMAC, ROTOPACTOR and DUOPACTOR are trademarks owned by BARSLAG ASSOCIATES LIMITED and registered in many countries in the world. BARMAC and BARSLAG DUOPACTOR trade marks are registered in the United States in the name of SVEDALA INDUSTRIES INC. True to a policy of continuous development the right is reserved to make changes in specifications and design. Ratings are nominal and may vary more or less with operating conditions.

Introduction

The vibration control device fitted to your Barmac Duopactor crusher is designed to protect your machine from the effects of severe vibration.

This manual contains instructions on the installation, operation and service of the vibration control device, which when followed, should provide trouble-free operation.

The Barmac crusher warranty is contingent on this cut-out switch being installed and operating correctly.




Integrated Electronic Vibration Control Kit


(SOLENOID RESET VIBRATION SWITCH)

LAYOUT

Serial Number C001 to C197




Serial Number from RA001



COMPLETE SYSTEM CIRCUIT DIAGRAM

For Serial Numbers RA001 and above




MOUNTING DETAILS


VIBRATION SWITCH

The unit should be mounted on a vertical face with the reset mechanism at the bottom using the two fixing holes on the outside of the unit. (See below for fixing detail).

The switch will respond to vibrations in any axis and should be fitted on the structure so that good transmission is ensured from the source of excess vibrations.



Recommended mounting position B9000, B8000, B7000 and B6000 machines.




Recommended mounting position B5000 and B3000 machines.

Continued ►

MOUNTING DETAILS

VIBRATION SWITCH



ELECTRICAL CONNECTIONS

Standard cable entry tapped to M20 x 1.5, I.S.O.

Maximum connector core size - 2.5mm²

Internal earth connection - 2.5mm² maximum core diameter

Ensure cables are correctly fitted into terminal block and earth terminals comply to relevant code of practice.

STORAGE

If switches are fitted to machinery without electrical connections being made, ensure that the cable entry is sealed to prevent moisture entering the switch.

Continued ►

MOUNTING DETAILS


ROTOR ALARM CONTROL

The rotor alarm control unit is suitable for mounting adjacent to, or as part of the main motor starter. See distance between Vibration Switch and Rotor Alarm Control 2-10.


Remove cover and mount unit using the four fixing holes in each corner of the enclosure.

For mounting as part of the starter, the gear plate may be removed from the enclosure if this is more convenient.

Serial Numbers C001 to C197



From Serial Number RA001



Cable entry into unit to be made to suit cable size.

Ensure cables are correctly fitted into terminal block and sealed at entry into unit.

Continued ▶





MOUNTING DETAILS



SIREN ALARM

Mount the siren in a suitable position within audible range of the Barmac operator and within 25m of the rotor alarm control.

Serial Numbers C001 to C197




From Serial Number RA001




WIRING INSTRUCTIONS

Serial Numbers C001 to C197



From Serial Number RA001



ROTOR ALARM CONTROL

ROTOR ALARM SUPPLY CONNECTIONS (TERMINALS 1 - 4)

The Rotor Alarm Control is suitable for use with the following supply voltage:


110 - 125v	50/60 Hz	Connect between terminals 1 (neutral wire) and 2 (live wire)
220 - 240v	50/60 Hz	Connect between terminals 1 (neutral wire) and 3 (live wire)
400 - 440v	50/60 Hz	Connect between terminals 1 (neutral wire) and 4 (live wire)

SIREN CONNECTIONS (TERMINALS 5 - 6 IN ROTOR ALARM CONTROL)

These terminals are connected to the siren speaker and supply 12 VDC at 300mA when an alarm condition exists. Terminal 5 is positive (+) and should be connected to the speaker red wire, and terminal 6 is negative (-) and should be connected to the speaker black or black/red striped wire. Neither terminal should be earthed.

Continued ►

WIRING INSTRUCTIONS



VIBRATION SWITCH CONNECTIONS (TERMINALS 7 - 9 IN ROTOR ALARM CONTROL)

Terminals 7 and 9 of the rotor alarm control are connected to the "normally open" contact in the Inertia Vibration Switch (which are terminals 3 and 4 of the terminal strip within the switch, counting from the top). The voltage present at these terminals is 12 VDC. Use a short length of wire to link terminals 4 and 5 together in the vibration switch. Terminal 8 of the rotor alarm control is connected to terminal 6 in the vibration switch.

ALARM RESET (TERMINALS 10 - 11 IN ROTOR ALARM CONTROL)

These terminals should be connected to a separate push button with a clean set of normally-closed contacts. The push button should be labelled "Alarm Reset". The voltage present at these terminals is 12 VDC.

SHUTDOWN (TERMINALS 12 - 13 IN ROTOR ALARM CONTROL)

These terminals are electrically clean and should be connected to the Barmac starter or starting system in such a way that when no continuity exists between terminals, the starter will stop.

OPTIONAL ALARM (TERMINALS 14 - 15 IN ROTOR ALARM CONTROL)

These terminals may be connected to an alternative alarm if so desired. They are electrically clean.

Continued ►

WIRING INSTRUCTIONS

EARTH

Earth the Rotor Alarm Control (green wire) to the starter earth.

DISTANCE BETWEEN VIBRATION SWITCH AND ROTOR ALARM CONTROL

Care should be exercised in the selection of cable size when connecting the Vibration Switch to the Alarm Unit.

Following are the recommended minimum cable sizes for a given length of cable run.

METRIC


Vibration Switch/Rotor Alarm Control Distance (m)	Minimum Wire Size (mm ²)
50	0.75
65	1.0
120	2.0
150	2.5
250	4.0

U.S.

Vibration Switch/Rotor Alarm Control Distance (ft)	Minimum Wire Size (AWG)
150	18
250	16
400	14
600	12
800	10

OPERATION

Serial Numbers C001 to C196



The Timing Setting in the Rotor Alarm Control can be adjusted from 0 - 3 minutes to suit plant operation.

When a vibration condition exists, the alarm siren will sound immediately.


If the vibration ceases within the vibration switch setting (0 - 3 minutes for serial numbers C001 to C197) or (0 - 2 minutes for serial numbers RA001 and above), the alarm stops.

If the vibration continues for longer than this setting, the vibration alarm unit shuts down the crusher and the alarm siren continues to sound.

When the crusher shuts down, press the "Reset" button to reset the vibration alarm unit and silence the alarm siren. Investigate and remedy the cause of the vibration condition before restarting the crusher in the normal manner.

OPERATION

From Serial Number RA001



The Barmac rotor alarm unit has two adjustment settings controlled by way of a bank of of eight DIP switches; the sensitivity adjustment and the delay adjustment.

SENSITIVITY ADJUSTMENT: Switches #1, #2 and #3 control the sensitivity. This is set at 2 Hz (switch 2 on, 1 and 3 off) and should never need to be changed.

DELAY ADJUSTMENT: The delay adjustment is controlled by switches #4 - #8. This determines the time delay before the Barmac is shut down in an excessive vibration condition. The delay is adjustable from 2 seconds (all switches OFF) to 124 seconds (all switches ON), by combination of the eight switches.

The individual settings are as follows:

#4	#5	#6	#7	#8
4 sec	8 sec	16 sec	32 sec	64 sec

e.g. 44 second delay = #7 (32 sec) + #5 (8 sec) + #4 (4 sec) = 44 seconds

ADJUSTMENT AND CALIBRATION OF VIBRATION SWITCH

1. Remove cover of switch and grommit from adjuster.
2. With small screwdriver rotate set level screw (see Fig. 1) until magnet can be seen to be in contact with metal ball (metal ball will start to rotate with set level screw when in contact).
3. Remove one cavity wear plate (open sided rotor) or tip carrier wear plate (enclosed rotor) from rotor and close door.
4. Start Barnac. **WARNING:** The removal of the cavity wear plate/tip carrier wear plate will create the "maximum allowable vibration level" that will allow adjustment of the switch.
5. With the machine running at the "maximum allowable vibration level", readjust the vibration switch set level screw anti-clockwise (slowly) until the ball drops onto the micro-switch. Then, continue to screw anti-clockwise one half turn beyond this point. See notes (a) and (b) below.
6. Replace the cavity wear plate/tip carrier wear plate and run machine to test that, under no vibration conditions, the vibration switch will not activate.
7. Repeat 3 above, to test vibration switch, and then repeat 6 once again.
 - (a) With Manual Reset Switch the crusher will shut down immediately.
 - (b) With Vibration Control Unit the solenoid will continually reset the Vibration Switch for the pre-set time. The alarm should sound throughout this period. Note: If the above does not occur, check wiring. (See wiring diagram section 2 p. 2-3).

TYPICAL CALIBRATION CURVE






FIG. 1



SERVICING

A periodic service functional check is recommended by reducing the vibration switch setting (screw set level screw towards flush) until switch is activated. This should cause the alarm siren to sound and after the pre-set time delay, the crusher should shut down.

VIBRATION SWITCH




PARTS REPLACEMENT

ROTOR ALARM CONTROL B96AV14A

(Includes both Siren and Vibration Alarm Unit)


A. SIREN B96AV14A/100

TYPE: 12 vdc, 8 ohms, 10 watts
Serial Number C001 - C197




SIREN B96AV14A/100B

TYPE: 12 vdc, 120 dB
Serial Numbers from RA001




B. VIBRATION ALARM UNIT B96AV14A/200

TYPE: Dawson Control
TIDCO MK IV
Serial Numbers C001 to C197



VIBRATION ALARM UNIT B96AV14A/200B


TYPE: Aucom Rotor Alarm Control
Serial Numbers from RA001



Continued ►

PARTS REPLACEMENT

VIBRATION SWITCH KIT B96AV11A



When ordering individual components quote part number and descriptions below:

B96AV12A Vibration Switch, type 3171, 12 vdc Solenoid.


B96AV13A Vibration Switch Screw Set.




Basic Vibration Control Kit

(MANUAL RESET VIBRATION SWITCH)

LAYOUT



COMPLETE SYSTEM CIRCUIT DIAGRAM




MOUNTING DETAILS


VIBRATION SWITCH

The unit should be mounted on a vertical face with the reset mechanism at the bottom using the two fixing holes on the outside of the unit). See distance between Vibration Switch and Barmac Starter 3-6.

The switch will respond to vibrations in any axis and should be fitted on the structure so that good transmission is ensured from the source of excess vibrations.



Recommended mounting position 5000 and 3000 machines.




Recommended mounting position 9000, 8000, 7000 and 6000 machines.

Continued ►

MOUNTING DETAILS

VIBRATION SWITCH



ELECTRICAL CONNECTIONS

Standard cable entry tapped to M20 x 1.5, I.S.O.

Max connector core size - 2.5mm²

Internal earth connection - 2.5mm² max. core diameter


Ensure cables are correctly fitted into terminal block and earth terminals comply to relevant code of practice.

Refer to page 3-6 for maximum distance between Vibration Switch and Barmac Starter.

STORAGE

If switches are fitted to machinery without electrical connections being made, ensure that the cable entry is sealed to prevent moisture entering the switch.

WIRING INSTRUCTIONS



Terminals 1, 2, and 3 (Motor Starter Connections)

For a "normally open" circuit where the starter will stop when the circuit is closed, connect the motor starter to terminals 1 and 2 of the terminal strip, counting from the top.

For a "normally closed" circuit where the starter will stop when the circuit is opened, connect the motor starter to terminals 1 and 3 of the terminal strip.

Note: Operating voltage of the Vibration Switch is 12 vdc.

Terminals 4, 5 and 6 (Optional Alarm)

These terminals may be connected to an alternative alarm if so desired. A connection between terminals 4 and 5 will give a "normally open" circuit and between terminals 4 and 6 will give a "normally closed" circuit. The voltage present at these terminals is 12 vdc.

Continued ►

WIRING INSTRUCTIONS

DISTANCE BETWEEN VIBRATION SWITCH AND BARMAC STARTER

Care should be exercised in the selection of cable size when connecting the Vibration Switch to the Barmac crusher starter.

Following are the recommended minimum cable sizes for a given length of cable run.

METRIC

Vibration Switch/Barmac Starter	Minimum Wire Size (mm ²)
50	0.75
65	1.0
120	2.0
150	2.5
250	4.0

U.S.

Vibration Switch/Barmac Starter	Minimum Wire Size (AWG)
150	18
250	16
400	14
600	12
800	10



OPERATION

When a vibration condition exists, the Barmac crusher will shut down. Investigate and remedy the cause of the vibration condition before restarting the crusher in the normal manner.

ADJUSTMENT AND CALIBRATION OF VIBRATION SWITCH

- 1. Remove cover of switch and grommit from adjuster.
- 2. With small screwdriver rotate set level screw (see Fig. 1) until magnet can be seen to be in contact with metal ball (metal ball will start to rotate with set level screw when in contact).
- 3. Remove one cavity wear plate (open sided rotor) or tip carrier wear plate (enclosed rotor) from rotor and close door.
- 4. Start Barmac. **WARNING:** The removal of the cavity wear plate/tip carrier wear plate will create the "maximum allowable vibration level" that will allow adjustment of the switch.
- 5. With the machine running at the "maximum allowable vibration level", readjust the vibration switch set level screw anti-clockwise (slowly) until the ball drops onto the micro-switch. Then, continue to screw anti-clockwise one half turn beyond this point. See notes (a) and (b) below.
- 6. Replace the cavity wear plate/tip carrier wear plate and run machine to test that, under no vibration conditions, the vibration switch will not activate.
- 7. Repeat 3 above, to test vibration switch and then repeat 6 once again.
 - (a) With Manual Reset Switch the crusher will shut down immediately.
 - (b) With Vibration Control Unit the solenoid will continually reset the Vibration Switch for the pre-set time. The alarm should sound throughout this period. **Note:** If the above does not occur, check wiring. (See wiring diagram section 3 p. 2).

TYPICAL CALIBRATION CURVE






FIG. 1



SERVICING


A periodic service functional check is recommended by reducing the vibration switch setting (screw set level screw towards flush) until switch is activated. This should cause the crusher to shut down.

VIBRATION SWITCH



PARTS REPLACEMENT

BASIC VIBRATION SWITCH KIT B48AV11A



When ordering individual components quote part number and descriptions below:

B48AV12A Vibration Switch, type 3171, Manual Reset.

B96AV13A Vibration Switch Screw Set.



spare parts & accessories

BARMAC™

operation & maintenance

BARMAC[®]

BARMAC ROCK-ON-ROCK VSI CRUSHER

Manufacture and design of the Barmac crusher is carried out under quality control systems certified to ISO 9001 by Svedala Barmac Product Group. Distributed worldwide under the following named and pending patents and design applications:

New Zealand 199307, 201193, 211510, 217752, 217753, 250037, 21928, 21927,
22929, 23568, 25473, 25474, 231457, 248954, 248955, 248952, 248953,
250154, 227492, 218749

Australia 557166, 562251, 594367, 620616, 640710

U.S.A. 4662571, 4586663, 4921175, 4940183

Canada 1189045, 1209813, 1263772, 130135

Japan 2564066, 1620260, 217861/86, 32286/88

South Africa 82/6374, 82/5817, 86/8502, 86/8061, 86/8062,
90/9325, 88/9485

United Kingdom 0274771, 0101277, 216592, 2214107, 2218410

France 0274771, 0101277, 216592, 83-1702

Italy 0074771, 0101277, 216592

Sweden 8230462.9, 0101277, 216592

Austria 216592

Federal Republic of Germany 3273506.8, 0101277, 216592

Europe 0274771, 0101277, 90312663.9

Mexico 164323

BARMAC, ROTOPACTOR and DUOPACTOR are trade marks owned by SVEDALA BARMAC LIMITED and registered in many countries in the world. BARMAC and BARMAC DUOPACTOR trade marks are registered in the United States in the name of SVEDALA INDUSTRIES INC. Due to a policy of continuous development the right is reserved to make change without notice in specifications and designs. Ratings are nominal and may vary more or less with operating conditions.

AFTER SALES CONTACTS (PLEASE QUOTE MACHINE REF. NO.)

Spare Parts		Service	
Technical		Crusher Sales	
Telephone		Fax	

Dealer:

CONTENTS

SECTION 1 — SAFETY	1-4
General Safety Precautions	5
Door Safety Interlock System	6
Vibration Protection	
SECTION 2 — PRINCIPLES OF OPERATION	1
Crusher Operating Principles	2
Control of Crushed Product Sizes	
SECTION 3 — KNOW YOUR BARMAC	2
Exterior of Crusher	3
Interior of Crusher	4
Rotor and Wear Parts	
SECTION 4 — START-UP PROCEDURE	1
Before Start-Up	1-3
Initial Start-Up	
SECTION 5 — OPERATION	1
Crusher Operation	2
Feed Control	3
Dust Control	4
Crusher Shut-down Procedure	
SECTION 6 — INSPECTION AND SERVICING	2-5
Greasing Bearing Cartridge	
Rotor Inspection/Serviceing	6-11
Rotor Tip Assembly	12-15
Upper and Lower Wear Plates	16-17
Distributor Plate	18-19
Feed Eye Ring	20-21
Feed Tube	22-23
Trail Plates	24-25
Rotor Body	26
Top Wear Plate	26
Cavity Wear Plate	27
Rotor Build-up	28-30
Rotor Tuning	31
Rotor Rebuilding	32
Rotor Removal	33-35
Rotor Installation	36-42
Rotor Balancing	
Crusher Inspection/Serviceing	43
Crushing Chamber	44
Cavity Ring	45-47
Cascade Choke	48
Air Transfer	48
Cascade Centralisation	49
Cascade Wear Skirt	50
Feed Hopper	50
Feed Spreader Plate	50
Cascade Ports	50
Swing Bolts	50
Inspection Doors and Hatches	50
Door Safety Interlock	50
Vibration Switch	51
Crusher Base	51
Discharge Chutes	52
Base Stay Castings	52
Grease Discharge Chute	52
Belt Guards	52
Motors	53-59
Bearing Cartridge	60-63
Belt Tensioning	

Safety

GENERAL

During the design and manufacture of the equipment, a lot of effort is put into the avoidance of health and safety risks.

In a crushing and screening plant there are many potential risks and to avoid these it is important that:

- The recommendations in instruction manuals are studied and followed.
- Personnel are regularly given training on maintenance and safety.
- General and official safety regulations are followed.
- Dangerous areas are marked with warning signs.
- The appropriate equipment and tools are available.
- The owner and management live up to their responsibility to make sure that effective safety programmes and regulations are worked out and are followed by all personnel.

EXTRA SAFETY PRECAUTIONS

Our instruction manuals and other documentation contain important information which must be read and understood by all users before they operate the equipment. To make it easier to notice information in our instruction manuals directly concerning user safety and the avoidance of problems with the equipment, we use the terms shown below:



WARNING: Important information which describes how you avoid damage to a machine and its systems or how you avoid a situation which could cause personal injury.

NOTE: Advice about operation, inspection and maintenance of a machine and its systems.

GENERAL SAFETY PRECAUTIONS

The following list of general safety precautions should be considered as a guide only. There may be other conditions and variations in the operation of this equipment that are not covered in these general safety precautions. The purpose of the general safety precautions is to make all personnel aware of the general hazards and dangerous situations that exists around the equipment and the work area.

Personnel Safety

1. Read and understand each of the warnings, cautions and instructions in the instruction manual and on all signs and information plates on and around the equipment.
2. Report all accidents immediately to your supervisor. Consult a doctor or medical personnel as soon as possible if personal injury is involved.

3. Keep a list of emergency telephone numbers close to the telephone and inform all work area personnel about the location of the list.
4. Do not operate or work equipment while under the influence of alcohol, medicines, tranquillisers or other drugs that can make you less alert or affect your judgement.
5. Use hand grips, ladders, guard rails and other safety devices when getting on or off equipment and when moving around while on the equipment. Use a safety harness when necessary.
6. Take precautions to keep hair and loose fitting clothing from being caught on moving parts or controls.
7. Wear safety glasses whenever there is danger of flying debris, chips, objects or dust that could enter the eyes, and when required by operating regulations. Be extra safe — always wear eye protection. Look after your eyes!
8. Wear gloves whenever possible to protect hands and fingers from cuts, scrapes, burns and solvents.
9. Always wear a hard hat and safety shoes when appropriate for the work being done and always when required by local or national regulations.
10. Remove rings, watches, necklaces and bracelets before working in the plant.
11. In areas where noise levels are high, wear hearing protection devices.

Continued ►

SAFETY

GENERAL SAFETY PRECAUTIONS

12. Wear breathing apparatus or a mask whenever appropriate, i.e. when painting or working with chemicals, solvents and other substances that may be hazardous to your health. Remember that there is a risk of silicosis when there is siliceous dust in the air.
13. Do not take chances with your back. Use lifting and moving devices to help you with your work. Always lift with your legs, not with your back.

WORK AREA SAFETY

1. Keep the general work area clean and free of debris. Avoid stone or other material build-ups on walkways, platforms, ladders and under conveyors.
2. Do not allow unauthorised personnel in or around the work area. Keep a check on who is in your work area at all the times. If necessary, keep a list.
3. Keep equipment surfaces that will be touched by hands and feet clean, dry and free of oil or grease.
4. Keep hand grips, guard rails, ladders and platforms clean, dry and free of oil or grease. Store parts and tools in the designated places when not in use.
5. Keep safety equipment in a designated place and ensure that work area personnel know the location and the proper use of the safety equipment.
6. Make a daily check of starting alarms and warning devices in the work area, and ensure that each device is working properly before starting or operating the equipment.
7. Do not stand under or allow anyone else to stand under equipment that is being hoisted or suspended. Use a safety hook or hook with a safety latch when hoisting equipment and use spreader bars when necessary.
8. Learn the weight limitations and clearances in and around your work area and for the equipment in use.
9. Do not overload walkways. They are intended for personnel, not for storing parts or tools!
10. Be alert to conditions that may obscure vision in and around your work area.

EQUIPMENT SAFETY

1. Do not alter, deface or remove warning and information signs.
2. Before setting up portable equipment, be sure that the ground surface is firm and level. Make sure that all supporting and locking devices are securely in place. Follow manufacturers' recommended procedures for supporting and locking the equipment when applicable.
3. Before moving portable equipment, check that the brakes and running lights operate properly. Ensure that supporting legs are raised high enough off the ground to provide sufficient clearance for safe transport. Check that there are no loose items that could fall off during transport.
4. Never climb aboard equipment while it is in transit or being hoisted, or allow anyone else to do so.
5. Inspect all equipment components before each operating shift to ensure that no parts are damaged or suspected of being damaged. Repair or replace damaged parts before starting or operating the equipment. Use only original parts.
6. Before starting or operating equipment, walk around the work area and the equipment to check that no personnel, animals, tools, parts or foreign objects are in, on, under or around equipment. Make sure that all guards and safety devices are properly installed and in good working condition.
7. Before starting equipment, make sure that all work area personnel and visitors know the equipment is going to be started. Use appropriate devices such as sirens or flashing lights to warn personnel and visitors.
8. When starting equipment, follow the manufacturer's recommended starting sequence. Do not allow unskilled persons to start or operate any equipment without the proper supervision of a skilled operator.
9. Never leave equipment controls unattended. Always have a qualified operator relieve you if you must leave.

Continued ►

SAFETY

GENERAL SAFETY PRECAUTIONS

10. During start-up and while equipment is operating be alert for improper readings, visual defects, odours or unusual sounds that could be a warning of a potential hazard. Shut down equipment immediately, following established shutdown procedures, if any unsafe condition should arise.
11. Use extreme caution whenever any equipment is required to be operating during an inspection, maintenance, lubrication or adjustment procedure. This may only be permitted if it is absolutely essential. Under normal circumstances the machine must be stopped and safety switches locked out before any work is carried out.
12. Perform all inspections, maintenance, lubrication and adjustment procedures with caution and in accordance with the manufacturer's recommended procedures.

ELECTRICAL SAFETY

1. Permit only trained and competent personnel to work on electrical components in the plant or on any equipment.
2. Always assume that an electrical circuit is live until it is proven dead by proper testing procedures.
3. Lock out and tag electrical controls before performing any inspection and maintenance. See details of the door safety interlock system recommended by Svedala, section 1 - 5.
4. Repair or replace electrical wires, cables and connectors that are broken or damaged in any way.
5. Check the electrical ground wires, motor plugs and power cable connections are properly and securely connected before starting any equipment.
6. Know the location of all power lines and underground cables. Use extreme caution when working around these areas. Know the location of all main electrical isolating switches.
7. Never work on electrical equipment while it is raining or while standing in water or on wet surfaces unless you know the power is disconnected.
8. Be alert when working around or with electricity. Report any electrical hazard immediately to your supervisor.

FLAMMABLE & HAZARDOUS MATERIALS SAFETY

1. Store flammable, combustible or hazardous materials in a safe place and in containers specifically designed for the purpose and clearly marked in accordance with the relevant regulations.
2. Store used and oily cleaning rags in a properly designed container as required by national or local rules and regulations, and away from flammable and combustible materials.
3. Do not store flammable or combustible materials in, or around the equipment, electrical installations or personnel facilities.
4. Do not permit smoking or an open flame around fuel tanks or other storage facilities for combustible materials.
5. Keep several fully charged fire extinguishers located throughout the work area. Make sure that all personnel know their location and how to operate them. Have them readily available during fuelling operations or when other fire hazards are present. Check the charge on each fire extinguisher at least once a month or when otherwise specified.
6. Shut down all engines and motors when fuelling or transferring flammable, combustible or hazardous materials. Follow the recommended fuelling and transfer procedures for the substance or material being worked with.
7. Fill fuel storage tanks and other combustible materials storage facilities in a well ventilated area, well away from equipment which can cause sparks and thus ignite flammable materials.
8. When refuelling or transferring flammable or combustible materials, ground the nozzle or spout to prevent sparks caused by static electricity.
9. Never start a diesel or gasoline engine in an enclosed area unless there is adequate ventilation.
10. Do not use flammable or combustible substances such as gasoline, kerosene or diesel fuel for cleaning parts. Always use a non-flammable solvent for cleaning.

Continued ►

1

SAFETY

GENERAL SAFETY PRECAUTIONS

11. When using epoxy-resin based materials, follow the manufacturer's recommended procedures and precautions. Mix and pour epoxy materials in an open or well ventilated area. Do not burn cured resin without adequate ventilation. Avoid skin contact with uncured epoxy-resin materials.
 12. Always inspect and charge batteries in an open or well ventilated area. Do not permit smoking or open flames near batteries. Remember that batteries can contain explosive gas.
 13. Properly dispose of waste, drain fluids and hazardous materials with due regard to and in full accordance with all national and local environmental, safety, transportation, and other regulations and ordinances. Make sure that all personnel are familiar with these regulations.
 14. Wear the appropriate clothing and protection devices, and follow the recommended procedures when working with hazardous, flammable and combustible materials.
6. Do not attempt to disassemble air or hydraulic cylinders unless you have been trained and authorised for such maintenance.
 7. Never adjust pressure relief valves beyond the recommended values.
 8. Follow the manufacturer's recommended inspection and maintenance procedures for pressurised systems to ensure that safe operating conditions exist at all times.
 9. Take extreme care when working with hydraulic accumulators. They must never be heated or subjected to welding or mechanical damage.

PRESSURISED SYSTEMS SAFETY (AIR & HYDRAULIC)

1. Do not perform maintenance on pressurised system components without first relieving all pressure in the system.
 2. Do not make internal checks on pressurised oil or fluid systems reservoir or levels until all pressure in the system has been relieved. Pressurised oil and air are dangerous if released incorrectly. Oil and air pressure equipment can get very hot; use extreme caution and allow the system to cool before working on it.
 3. Do not attempt to remove an air line or hydraulic line from a cylinder or other component unless all pressure to the system has been relieved.
 4. Do not attempt to remove an air or hydraulic cylinder clevis from its attachment unless all pressure in the system has been relieved.
 5. Do not operate pressurised systems with worn or damaged hoses, valves or fittings. Replace defective components before pressurising the system.
1. All welding or cutting operations should only be performed by experienced welders who are familiar with the welding equipment and the material to be welded.
 2. Take all necessary precautions to avoid dropping sparks or welding splatter on belts, hoses, tanks or other parts of equipment, or on personnel in the work area. Always keep the risk of fire in mind.
 3. Attach the welding ground cable as close as possible to the piece being welded to avoid damage to the equipment and potential injury to personnel.
 4. Always consult with the manufacturers of the equipment to be welded before any welding operation.
 5. Never weld vessels or pipework which is pressurised.
- Caution: Do not attempt to weld on rotor while it is in the machine or arcing damage will cause premature failure of the bearings.

WELDING SAFETY


SAFETY

DOOR SAFETY INTERLOCK SYSTEM OPERATION

Svedala recommend and provide for the fitting of a Door Safety Interlock System which is designed to prevent the crushing chamber service door from being opened while the machine is in operation or on shut-down before sufficient time has elapsed to allow the rotor to stop rotating.

The interlock also prevents accidental start-up while the crusher is being serviced, or when the door is left open.

SEQUENCE OF OPERATION



- ① Turn Shutout Key in Deadlock and remove key.
- ② Put Shutout Key in Shutout Lock and turn.
- ③ After time delay has elapsed, turn and remove Access Key.
- ④ Put Access Key in Access Lock and turn.
- ⑤ Release Bolt and open door.

To close door, engage bolt and transfer keys through reverse sequence.
(Time delay will not activate in reverse sequence).

• For further information See Door Safety Interlock Installation, Operation and Service Manual.

SAFETY

VIBRATION PROTECTION


A vibration protection system protects the machine from the effects of severe vibration. With this installed the machine will be shut down and/or an alarm sounded if vibration becomes excessive.

In normal operation, the Barmac has a slight vibration which varies from time to time, due to the wear and replacement of material within the rotor. As material wears away it is continually replaced.


Consistent or excessive vibration should always be investigated. A likely cause is breakage of a rotor tip or uneven build-up within the rotor. High pitched vibration may be caused by poor rotor taper lock seating or a bent shaft.

Your Barmac dealer will set the vibration switch when commissioning the machine.

RECOMMENDED VIBRATION SWITCH POSITION



B9000, B8000, B7000 and B6000 machines.



B5000 and B3000 machines.

ALL MACHINES MUST HAVE A VIBRATION PROTECTION SYSTEM PROPERLY FITTED AND CONNECTED.

Full wiring instructions are supplied with the vibration protection system.

Machines without a vibration protection system will not be covered by warranty.

- For further information see Vibration Control Kit Installation, Operation and Service Manual.

SAFETY

TEN COMMANDMENTS OF SAFETY

1. Support all efforts to make your workplace safe and healthful.
2. Act responsibly and with concern for the safety of others, as well as yourself.
3. Check all tools and protective equipment frequently, to make sure they are in safe working order.
4. Educate yourself and others in the hazards associated with your job so that they can be avoided in a safe manner.
5. To avoid injury and damage, familiarise yourself in advance with the risk and safety aspects of procedures which are new to you.
6. Think over accident and injury possibilities before starting on any project. Take appropriate precautions to protect yourself and others. Revise and improve working procedures regularly.
7. Warn others of the possibility of accidents and injuries if you see them working unsafely or creating potential hazards.
8. Stay alert for changes in work conditions and the work process.
9. Report unsafe acts and conditions immediately to your supervisor.
Don't assume that someone else will do it.
10. Keep your work area and your tools clean. Pick up tools and materials after use and return to the appropriate storage place.




Principles of Operation

The Barmac rock-on-rock crusher uses a field proven rock lined rotor that acts as a high velocity dry stone pump hurling a continuous rock stream into a stone lined crushing chamber.

Material fed into the top of the machine is accelerated in the Barmac patented rock lined rotor, achieving exit velocities of up to 85 metres (275 feet) per second. The rotor continuously discharges into the crushing chamber. This process replenishes the rock lining, while at the same time maintains a rock-on-rock chain reaction of crushing and grinding.

A second stream of material in a controlled quantity can be cascaded into the crushing chamber turbulence causing a supercharging of the particle population within the chamber, improving the energy transfer. This, in combination with other variables of rotor diameter and speed and the crushing chamber profile, enhances power efficiency, reduces wear, plus provides an efficient means of controlling the grinding and crushing action, to either maximise or minimise fines.




PRINCIPLES OF OPERATION

CONTROL OF CRUSHED PRODUCT SIZES

The Barmac offers a number of controllable variables which affect the final product grading.


ROTOR SPEED

Increasing rotor speed increases the particles kinetic energy and increases the reduction achieved.




CASCADE

Increasing the cascade flow decreases the reduction ratio achieved whilst increasing the capacity of the crusher.




FEED GRADATION

Changing the size distribution of the feed to the Barmac will affect the size distribution of the crushed product.



SCREEN APERTURE

When operating in closed circuit the final product size produced by the Barmac is controlled by the screen aperture.



Crushing Chamber Profile: In some models, coarse and fine cavity rings are offered. The fine cavity ring increases particle retention time with the crushing chamber increasing the reduction achieved.

Rotor Diameter: Different rotor diameters are available for some models. Changing to a larger diameter rotor effectively increases the tip speed and the effect is similar to increasing the rotor speed with the addition that the longer grinding arm in the rotor produces more fines than a smaller diameter rotor with the same tip speed.


Know Your Barmac

This section has been included to introduce you to your Barmac. It will also serve to introduce you to the terms used to describe the various components and parts of your Barmac. These terms will be constantly used throughout the manual and parts listings that are provided.

VISUAL INDEX

The numbers that appear in brackets refer to the section of the manual that details the inspection and service instructions for each part or component.


General Description



Continued ►

KNOW YOUR BARMAC


EXTERIOR OF THE CRUSHER



Continued ►

KNOW YOUR BARMAC

INTERIOR OF THE CRUSHER





Continued ►



KNOW YOUR BARMAC

THE ROTOR AND WEAR PARTS



Start-up Procedure

This section describes the full start-up procedure, including the initial commissioning start-up. The start-up procedure should be used after a major repair such as bearing cartridge replacement or crushing chamber refurbishment has taken place.

BEFORE START-UP

1. Be completely familiar with the Barmac, take the time to read this manual.
2. Have all electrical connections checked, including the operation of the vibration switch.
3. Check pulley alignment and V-belt tensions. (See Belt Tensioning 6-60).
4. Check rotor rotation – it must be counter-clockwise when viewed from above. Severe damage to the rotor will result if the rotation is incorrect.
5. Check that a safety interlock device is connected and functioning.
6. Make sure all bolts in the rotor, crusher and main support frame are tightened to the correct torque. See installation book for correct torque details.
7. Ensure that the cascade assembly is centralised. (See section 6-48).
8. Check that all wear parts are correctly fitted in the rotor. (See section 6-6).
9. Remove all tools from on or within the crusher.
10. Ensure that all guards, doors, hatches and safety pins are in place.

INITIAL START-UP

1. Confirm ammeter is operating.
2. Run without load for 30 minutes. Grease bearing cartridge until grease flows from the grease discharge chute while the machine is running. (See greasing procedure section 6-2).
3. After 30 minutes running, stop the Barmac, remove belt guards and check bearing cartridge temperature. (Use a magnetic thermometer). The temperature should not exceed 70°C (160°F). If temperature exceeds this, continue to run Barmac with no load for a further 30 minutes and check again. If high temperatures continue contact your Barmac service centre for advice. If temperature is within normal range (see section 4-3), replace guards.
4. Inspect rotor and cascade assembly. Ensure that all rotor parts are in place. Ensure that the feed tube is still centralised in the feed eye ring. (See section 6-48).
5. Test vibration switch. (See Vibration Control System instruction manual).

Continued ►

START-UP PROCEDURE

INITIAL FEEDING OF CRUSHER

1. The machine can now be run with a load. Feed material should be no larger than the maximum allowable feed size for the Barmac model being commissioned.
2. Feed a small sized chip or all-in product, preferably 5mm (¼ in.) for the first half minute or so. A few cubic metres/yards of material is enough. This allows an even build-up of stone in the rotor and promotes good balance.
3. If coarse feed must be used at the start, some vibration can be expected for several hours until fines are able to work their way through the voids in the initial rotor build-up and bring the density of each rotor build-up into equilibrium.
4. When first feeding the rotor there will usually be an 'out of balance' stage for about 30-60 seconds. Do not stop the feed to the rotor at this point but feed it as much as possible until the vibration settles down.

In normal operation there is intermittent detectable vibration about 30% of the time. This can be felt when standing on the machine and is most noticeable with largest feed sizes. This is due to stone lodging by one rotor tip, causing a build-up and then being worn away. The condition is normal and no cause for concern provided the machine returns to normal running after a few seconds.

AFTER 10 MINUTES

1. Centre the spreader plate under conveyor discharge so feed falls in an even curtain around the spreader. The feed should fall squarely through the control plate feed opening (i.e. not at an angle). This stabilises rotor feed. Watch for involuntary cascading through material being directed towards the cascade ports in the feed hopper.
2. Check motor power draw. If motor(s) are overloaded, reduce feed volume or adjust cascade control until ammeter reading is corrected. If dual drive motors are running at different amps see belt tensioning (section 6-60).

AFTER 30 MINUTES

1. Stop machine and check build-up in rotor. For ideal build-up see rotor tuning (section 6-28).
2. Check crushing chamber build-up. (See section 6-43 for ideal build-up).
3. Make sure feed tube is in correct position in rotor, i.e. central in rotor feed hole and extending into rotor. (See section 6-20).
4. Check that rotor tip assemblies are intact and tight.
5. Check feed eye ring has not turned or lifted.
6. Check belt tensions. (See section 6-60).

Continued ►

START-UP PROCEDURE

AFTER 4 HOURS


1. Check build-up in rotor, crushing chamber and base.
2. Check bearing temperatures. (See below).
3. Check belt tensions.
4. Grease at the end of the shift, and perform daily inspections as listed.
5. Once the machine has settled down to normal running, adjustment of the cascade can be undertaken. (See section 5-2).

BEARING OPERATING TEMPERATURE

Normal bearing temperature is 30° to 40°C (54° to 72°F) above feed material or ambient temperature. A short duration temperature rise of approximately 10°C (18°F) can be experienced when bearings are lubricated.

The maximum permissible bearing temperature for continuous running is:

- 70°C (160°F) - Normal temperature service.
- 150°C (300°F) - High temperature service.



Operation

During operation it is important that the operator pays attention to the following:

1. AMMETER READING – watch for major fluctuations.

High amps could indicate high feed rates, extreme build-up in the chamber or the base, blocked discharge chutes, incorrect cascade adjustment, mechanical or electrical problems.

Low amps could indicate low feed rates, incorrect cascade adjustment, V-belt slippage, electrical problems.

Unbalanced amps in a dual drive unit could indicate incorrectly tensioned V-belts, electrical or mechanical problems.

2. NOISE LEVELS

An increase in noise level could indicate bearing failure, V-belt slippage, scouring of build-up in crushing chamber, feed tube rubbing on feed eye ring.

3. VIBRATION

An increase in vibration could indicate uneven wear on wear parts or rotor, unbalanced rotor due to uneven build-up in rotor, failure of anti-vibration pads, loose rotor or pulley taper lock.

THE VIBRATION SWITCH FITTED TO THE BARMAC WILL, IF CORRECTLY ADJUSTED, SENSE OUT-OF-BALANCE VIBRATION AND SHUT DOWN THE CRUSHER BEFORE ANY DAMAGE OR DANGER TO PERSONNEL OCCURS.

4. FLOW OF MATERIAL

Changes in feed conditions could require adjustment of the feed plate and control choke in the feed hopper. Increases in moisture content may increase build-up in the rotor, crushing chamber and base. Observing the discharge of the Barmac will often warn an operator of build-up problems.

5. DUST EMISSION

The Barmac should not emit dust while being fed material. If the crusher is emitting dust the following points should be checked:

Feed rate – Very low feed rates may cause the Barmac to discharge dust from the discharge chutes.

Blocked air transfer – Moist feeds may promote the blocking off of the air transfer.

OPERATION

FEED CONTROL

The aim of feed control is to govern the rotor feed volume so that the motor(s) run at full load current. This is done by restricting the rotor feed with the cascade control unit. Any excess feed which does not go through the rotor will cascade.

Product grading can also be controlled by varying the percentage of cascade feed to rotor feed. As the volume of cascading material increases, the product grading will become coarser.

The cascade volume is varied by adjustment of the control plate feed opening choke, to increase or decrease the feed opening size.

The basic principles of cascade control are:


1. Increasing the opening size decreases or eliminates material flow to the cascade and results in more reduction.
2. Decreasing the opening size commences or increases material flow to the cascade and results in less reduction.

NOTE: The feed opening should not be reduced to a point where bridging of the feed opening may occur.

Use the feed spreader plate in the feed hopper by positioning it under the conveyor discharge so that feed material drops directly down the feed opening. If feed enters the hopper at an angle it may enter the cascade involuntarily.

The maximum feed opening size is determined by two adjustable feed opening liners. The control plate end liner and control plate side liner have an adjustment using the slots in the control plate, shown below.

The choke is adjusted by a two-way ram or thread adjuster in the small models.




OPERATION

DUST CONTROL

When in operation, the rotor acts as a powerful fan. To control dust emissions from the crusher, the air transfer, which is incorporated in the hopper assembly, recycles air within the machine, minimising air being sucked in and discharged with the material.

The basic rule is that any air sucked in with the feed will be blown out with the product, so to minimise dust, the air transfer system has been developed to strike a balance, so that no air is sucked in and therefore little dust is blown out.

Under some conditions it may be necessary to tune the dust control system. For example, at high rpm and with very fine-grained materials the system may suck air in from the product discharge chutes and blow it out of the cascade ports to the atmosphere. By removing some of the air transfer blades, it is possible to achieve a satisfactory balance. (See section 6-48).



If dust is blowing out from the bottom of the machine, this indicates that the unit is being under-fed. If the feed rate cannot be increased, close off the control plate feed opening to minimise the rush of air.

While it is not generally necessary to suppress dust within a Barmac (either by dry dust collection or mist spray suppression), the turbulent activity within the Barmac crushing chamber makes it an ideal environment for the addition of small quantities of water by means of mist sprays to effectively control dust in other parts of the process plant downstream of the Barmac.


OPERATION

SHUT DOWN PROCEDURE

Extended periods of running out the circuit with low feed rates to the Barmac can result in undue wear to the crushing chamber and rotor body. If the crushing circuit and weather conditions permit, stop all conveyors before the Barmac fully loaded. At the very least be aware of the excessive wear that takes place and minimise the run-out time.

SHUT-DOWN

1. Shut down feed device (conveyor or feeder) before the Barmac.
2. Observe ammeter unload prior to disconnecting power from the Barmac.
3. Time run-down time of rotor and record in Daily Log Book. Measuring the run-down time of the rotor will provide a good guide to the condition of the bearing cartridge. The commissioning records for your unit will have the rotor run-down time recorded. This will be located in the owners manual. If you cannot locate this contact your Barmac Service Engineer.
4. Prior to any servicing or maintenance ensure that a safety interlock system provides you with control over the power supply to the crusher.



Inspection and Servicing

The Barmac is a rugged machine which is mechanically simple and extremely easy to maintain. The machine does however require ROUTINE and REGULAR inspections and attention.

The machine should not be ignored for lengthy periods, during which potentially serious damage to wear parts may remain undetected.

Long service and consistent trouble-free operation are the rewards of regular inspection.

IMPORTANT NOTE: Barmac rotor wear parts are designed to protect the rotor body from wear. They are not involved in the crushing action of the machine. Consequently it is not possible to determine the state of wear of these parts from the product discharging from the crusher.

To ensure trouble-free operation of the Barmac it is necessary to inspect the condition of the rotor wear parts and the rock build-up within the machine on a regular basis.

Any wear parts that are unable to complete another shift should be replaced.

Svedala recommend that you should carry out the following every 8 to 10 hours of operation:

1. GREASE BEARING CARTRIDGE.
2. INSPECT EXTERIOR OF CRUSHER.
3. INSPECT INTERIOR OF CRUSHER.
4. INSPECT ROTOR


Svedala recommends the use of a Barmac Daily Log Book to record inspection and replacement of parts. Service personnel will find the log book extremely helpful in assisting you to maximise the life of the wear components in your Barmac.

LUBRICATION

BEARING CARTRIDGE

THE BEARING CARTRIDGE MUST BE GREASED EVERY 8 TO 10 HOURS OF OPERATION

The best practice is to grease the bearings when the bearing cartridge is at operating temperature while the machine is running at the end of each production shift.



GREASE REQUIREMENT

The following amounts are recommended for every 8-10 hours of operation:

Barmac Dupactor Model	Each Nipple
B3000	5g (0.18 oz)
B5000	8g (0.28 oz)
B6000	10g (0.35 oz)
B7000	15g (0.53 oz) 3 Barmac
B8000	15g (0.53 oz)
B9000	15g (0.53 oz)

Continued ►

LUBRICATION**BEARING CARTRIDGE****RECOMMENDED GREASES**

Feed Material Temperature °C (°F)	Barmac Model	Rotor Speed (RPM)	Grease Brand and Type
-20 to 65 (-4 to 149) Normal Service Bearing Cartridge (Low Speed)	3000	3000 to 4200	Shell Alvania EP2 Mobil Mobilux EP2 BP Energrease LS-EP2 Mobil Mobilith SHC100 Arcanol LI35V Castrol Optimol Longtime PD2
	5000	2100 to 2800	
	6000	1400 to 2000	
	7000	1300 to 1700	
	8000	1100 to 1700	
	9000	1100 to 1400	
-20 to 65 (-4 to 149) Normal Service Bearing Cartridge (High Speed)	3000	4200 to 5300	Mobil Mobilith SHC46 Castrol Optimol Longtime PD2 ✓ Arcanol LI35V Kluber Isoflex Topas NB152 *
	5000	2800 to 3600	
	6000	2000 to 2500	
	7000	1700 to 2200	
	8000	1700 to 2000	
	9000	1400 to 1800	
60 to 100 (140 to 212) High Temp. Bearing Cartridge (All Speeds)	3000	3000 to 5300	Mobil Mobilith SHC220 ✓ Shell Stamina U2 * BP Synthetic HT-XP *
	5000	2100 to 3600	
	6000	1400 to 2500	
	7000	1300 to 2200	
	8000	1100 to 2000	
	9000	1100 to 1800	

✓ Indicates preferred grease. Bearing cartridges are pre-lubricated with this grease type.

* Indicates that this type of grease is not compatible with any of the others. If this grease is used, the cartridge must first be completely stripped, cleaned and reassembled to ensure maximum bearing service life.

Continued ►



LUBRICATION

BEARING CARTRIDGE

Please note that the bearing cartridge in the Barmac presents a very unique set of operating conditions for the bearings and for this reason, selection of alternative grease types is not a straight forward task. Grease properties to consider include thickener type, base oil viscosity and the inclusion of tackiness additives. Consideration must also be given to mixability of any new grease with the grease already in the bearing cartridge. Mixing (especially of different thickener types) causes unpredictable lubrication conditions and possibly premature failure of the bearing cartridge.

If you wish to use a grease that is not on the list, please consult your Barmac dealer to confirm its suitability for the specific application in question. This will be determined based on your particular application. It is not recommended that you use an equivalent grease as promoted by various oil companies and organisations without first consulting Svedala Barmac, New Zealand.

OPERATING TEMPERATURE

Normal bearing temperature is 30° to 40°C (54° to 72°F) above feed material or ambient temperature. A short duration temperature rise of approximately 10°C (18°F) can be experienced when bearings are lubricated.

The maximum permissible bearing temperature for continuous running is:

- 70°C (160°F) - Normal temperature service.
- 150°C (300°F) - High temperature service.

GREASE DISCHARGE

Ensure that the grease discharge is away from the V-belts and grease hoses are undamaged.

It is also a good practice to perform a weekly inspection of the grease discharge to ensure that it is not blocked, which may lead to pressure build-up inside the cartridge; breakdown of grease inside, etc.

Continued ►

LUBRICATION

BEARING CARTRIDGE

AUTOMATIC LUBRICATION


Whilst Svedala make no particular recommendations for automatic lubrication, these systems can be used on the Barmac.

The total quantity of lubrication applied over an 8-10 hour operating period should not exceed the total quantity as for manual lubrication (page 6-2) over this same period.


The top seal plate may benefit from a more frequent/higher quantity grease application. If contamination of the top seal is known to be a problem, an increase in quantity over the above that listed in the table can safely be applied.

NOTE: It is essential that the grease points are properly identified so that grease directed at the top seal is not mistakenly applied to the bearings.


The grease points can be identified on the bearing housing as follows:




B9000



B8000, B7000, B6000



B5000



B3000

ROTOR SERVICING

Please observe the correct shut-down procedures. (See section 5-4 of this manual). Prior to any internal inspection/service ensure that a safety interlock system provides you with control over the power supply to the crusher.

The rotor assembly is the main wearing component of the Barmac, and regular and timely inspection of wear parts will extend the life of the rotor. If wear parts are not replaced when required, severe damage or even total destruction of the rotor body may result.

ACCESS

While wear patterns and wear rates can be observed with the rotor in place, it may be necessary or desirable to remove the rotor from the crusher to replace any worn wear parts.

In this manual we have assumed that the parts are being replaced with the rotor in the machine. The major problem with this can be the removal of the build-up of material in the rotor around the wear parts.


CLEANING OUT ROTOR

The most successful method of removing the build-up is by using water. If a hose pipe is available at the crusher it is quite in order to "wash out" the build-up by inserting the hose pipe into the hopper, directing the water into the rotor while the crusher is running.

WARNING: Do not insert the hose pipe into the rotor, direct the water flow only into the rotor.


The use of water into the rotor may scour out the build-up in the crushing chamber. This in itself is not a problem but if the feed size is at the maximum, chamber gusset wear will result until the build-up in the crushing chamber is replaced on start-up.

If a hose pipe is not available near the crusher it may be possible to remove build-up with a podger bar. If this is not possible or too time consuming, then it will be necessary to remove the rotor from the crusher for the removal of the upper and lower wear plates, distributor plate and feed eye ring.



ROTOR SERVICING

ROTOR TIP ASSEMBLY




* The smaller rotors do not have a back-up tip and the bolting arrangement is different but the assembly is similar.

ROTOR TIPS

Rotor tips must be checked to determine the amount of wear on the inserts. Tips need to be replaced once 95% of the insert has been removed at the centre of the wear. The back-up tip assembly will protect the rotor body from damage, therefore a tip in this condition could be run for another shift. Experience will help the operator understand the wear performance of the tip.

Ensure that the rotor tips are tightly held and not broken, cracked or badly chipped.



This rotor tip profile has been used as an example only. Different models with different rotor designs will vary but the principles are the same.

Continued ►


ROTOR SERVICING

ROTOR TIP ASSEMBLY

ROTOR TIPS


Normal Wear

The rotor tips are wearing normally. Replace when less than 3mm (1/8 in.) of insert remains at the centre of the wear, or if tip will not last another shift.




Cracked or Chipped Inserts

Tramp iron in feed. Remove tramp iron. Oversize feed material. Investigate cause of oversize. Reduce maximum feed size.



Off Centre Wear

The rotor tips are wearing at the top or bottom not in the centre. Trail plate angle may require altering (refer to rotor tuning section 6-28).



SELECTION OF ROTOR TIPS

A range of rotor tips is available to suit differing feed material characteristics and operating conditions. The rotor tips supplied with your machine have been carefully chosen to suit your requirements. However, changing feed material can require the re-selection of the rotor tips.

For information regarding rotor tip options, contact your Barmac representative.

Continued ►



ROTOR SERVICING

ROTOR TIP ASSEMBLY

TIP CARRIER WEAR PLATES

Initially, the tip carrier wear plates may wear quickly until they reach a certain profile governed by the application. This is quite normal and should not cause concern.

Tip carrier wear plates must be inspected for wear and be replaced when there is doubt they will last another shift, or as soon as wear appears on the top of the bolt head. Replace tip carrier wear plates which have cracked. Check that tip carrier wear plates are not loose.




Maximum permitted wear is to the top of the bolt head

This tip carrier wear profile has been used as an example only. Different rotor designs have different tip carrier wear plates but the principles are the same.


Normal Wear

The tip carrier wear plates are wearing normally. Replace when wear just starts to show on bolt head.




Cracked Tip Carrier Wear Plates

Caused by tramp iron, oversize feed, excess build-up with damp/sticky material or uneven mating surface. Remove tramp iron. Reduce feed size. Ensure that mating surfaces are flat, i.e. there is no spatter or grit between tip carrier wear plate and back-up tip. (See Rotor Tip Assembly Removal/Installation section 6-11).



Uneven Wear

Tip carrier wear plates are wearing at the top or bottom not in the centre. Adjust trail plate angle. (See rotor tuning, section 6-28).



Uneven wear can also be caused by excessive crushing chamber build-up.

Premature top wear can be indicative of a worn cavity ring and/or cascade wear skirt.

Premature bottom wear can be indicative of excessive build-up in the base.

Continued ►

ROTOR SERVICING

ROTOR TIP ASSEMBLY



BACK-UP TIPS

In normal operation the back-up tip should be unused and in many cases is not visible (depending on rotor tip and tip carrier wear plate style used).

Normal Wear

The back-up tip is only exposed to wear when the rotor tip has failed or worn out. In the event of emergency use of the back-up tips, they should be replaced once there is only 3-5 mm ($\frac{1}{8}$ - $\frac{3}{16}$ in.) of insert remaining at the centre of the wear path.

Back-up tips should also be replaced if the insert is cracked or badly chipped.



Irregular Wear

Rotor tips being left in place too long and wearing out.



Back-up Tips Breaking

Rotor tip failed, exposing back-up tip, usually caused by tramp iron or oversize feed or having been worn too thin.



WARNING:

If the back-up tip fails or is worn out the flow of material will severely damage or even destroy the rotor body.

Continued ►


ROTOR SERVICING

ROTOR TIP ASSEMBLY

REMOVAL/INSTALLATION

Removal

Remove taper bolts. Tap rotor tip inward to break away build-up that will hold tip and back-up tip in place. It may be necessary to use a bar to chisel away very tightly compacted build-up. If this condition persists it is advisable to wash out build-up with water. (See 6-6).



Installation

Ensure that all mating surfaces on rotor tip, tip carrier wear plates and back up tips are free of any high spots (dirt, weld spatter, burrs).

Position back up tip, rotor tip and tip carrier wear plate in rotor port. Insert taper bolts, ensure that copper washer is in place, and tighten. (Applying anti-lock compound to thread will make removal easier). Ensure that tip assembly is pulled up tight and that there is no movement in the parts. (See torque settings 6-64).



NOTE: ROTOR TIPS, TIP CARRIER WEAR PLATES AND BACK-UP TIPS MUST BE CHANGED AS SETS. DO NOT REPLACE SINGLE PARTS OR A ROTOR OUT-OF-BALANCE CONDITION MAY RESULT.

ROTOR SERVICING

UPPER AND LOWER WEAR PLATES

Replace upper and lower wear plates when it is obvious that they will not last another shift. Replace once there is less than 3-5 mm. ($\frac{1}{8}$ - $\frac{3}{16}$ in.) of plate remaining at the centre of the wearpath at the discharge edge or inside edge.

3-5mm ($\frac{1}{8}$ - $\frac{3}{16}$ in.)



Upper Wear Plate

Rapid upper wear plate wear is an indication that the feed tube and feed eye ring are worn. Replace worn parts.


Upper wear plate wear accompanied by rotor tip top end wear is an indication that the trail plates are incorrectly shaped. Adjust trail plates as described in rotor tuning, section 6-28.

Lower Wear Plate

Lower wear plate wear accompanied by rotor tip bottom end wear is an indication that the trail plates are incorrectly shaped. Adjust trail plates as described in rotor tuning, section 6-28.

Other Influences

As the feed eye ring wears the leading edge of the upper wear plate is progressively exposed to wear.



The upper and lower wear plate profiles shown above have been used as examples only. There are different profiles for different rotors, but the principle is the same.



Continued ►

ROTOR SERVICING

UPPER AND LOWER WEAR PLATES

REMOVAL/INSTALLATION

It is possible to remove and install the upper and lower wear plates while the rotor is in place, however it is necessary to clean out the build-up thoroughly. This can be done by using water as described in rotor servicing 6-6.



Removal

Upper Wear Plates

1. Remove hopper, crusher top and cascade assembly in one lift.
2. Remove rotor tips and tip carrier wear plates.
3. Remove feed eye ring.
4. Tap the wear plate towards the centre of the rotor to release it from the keepers.
5. Withdraw the plate through the feed hole.
6. Thoroughly scrub out the remaining build-up with a wire brush or hose pipe.

Lower Wear Plates

1. Remove rotor tips and tip carrier wear plates.
2. Remove the distributor plate.
3. Tap the wear plate towards the centre of the rotor to release it from the keepers.
4. Withdraw the plate through the feed hole.
5. Thoroughly scrub out the remaining build-up with a wire brush or hose pipe.

Installation

1. Ensure mating surfaces are clean and free of snags.
2. Insert new wear plate through the feed opening and slide into place.
3. Ensure the new plates are wedged under the keepers.


• See over for 300mm rotor instructions.

ROTOR SERVICING

300mm ROTOR UPPER AND LOWER WEAR PLATES

ADJUSTING / REPLACING UPPER WEAR PLATE

The 300mm rotor upper wear plate can be re-positioned three times for three lives before it is worn out. When worn as shown below:



1. Remove rotor from crusher.
2. Thoroughly clean wear plate and build-up in rotor, especially the bolting face of the wear plate.
3. Check the wear paths on the underside of the wear plate (fig. 1), they should be of even width, depth and position. If so, plate can be re-fitted. Uneven wear paths are caused by uneven trail plates. These should be checked. See rotor tuning 6-28.
4. Balance rotor with plates positioned so a new unworn area is next to the rotor tip.
5. Mark position of plate to rotor when balanced and remove plate.
6. When rotor body is refitted to shaft, position wear plate in correct balanced position as marked earlier, lubricate screw threads, fit aluminium taper washers and screws and torque to 30 Nm (15 lb ft).
7. If after re-starting and feeding a small amount of material, the rotor runs heavily out of balance, the wear plate is probably unbalanced and will have to be checked.

ROTOR SERVICING

300mm ROTOR UPPER AND LOWER WEAR PLATES

ADJUSTING / REPLACING LOWER WEAR PLATE




FIG. 1

As with the upper wear plate, the 300mm rotor lower wear plate can be re-positioned three times for three lives before it is worn out. To rotate or replace:

1. Remove rotor from crusher.
2. Remove upper wear plate, rotor tips and trail plates and clean out rotor (see changing upper wear plate).
3. Lift out lower wear plate and clean thoroughly. Check that wear paths on the wear plate are of even width, depth and position. If so, plate can be re-fitted. Uneven wear paths are caused by uneven trail plates. These should be checked.
4. Re-fit plate, positioned so a new unworn area is next to the rotor tip. Make sure the wear plate is sitting down flat and not resting on any grit, etc.
5. Rebalance rotor. (See section 6-36).


ROTOR SERVICING

DISTRIBUTOR PLATE

The distributor plate wears in three places, opposite each rotor port.

Turn the distributor plate 1/6th of a turn when partly worn to ensure maximum usage.

Replace distributor plate once the bolt head starts to wear or once there is only 3-5mm ($\frac{1}{8}$ - $\frac{3}{16}$ ") of casting left at the thinnest point.



Premature Wear

Generally caused by oversize feed or material dropping from a conveyor or screen chute directly onto the distributor plate.

Reduce feed size. Install or centralise spreader plate in feed hopper. Change distributor plate type.

SELECTION OF DISTRIBUTOR PLATE


Different types and shapes of distributor plate are available. Please contact your dealer for more information.

Continued ►

ROTOR SERVICING

DISTRIBUTOR PLATE

REMOVAL/INSTALLATION




Removal

1. Remove hopper, crusher top and cascade assembly in one lift.
2. Remove feed eye ring. (See 6-19).
3. Remove stones and protective rag from distributor bolt hole.
4. Remove distributor plate bolt.
5. Distributor plate lifts out.

Refitting

1. Ensure the top plate surface is clear of obstructions before fitting the distributor plate to protect the distributor plate from breakage.
2. Place distributor plate in centre of rotor. Insert distributor plate bolt and tighten. (Refer to bolt torque table section 6-60 for correct torque).
 - The use of large impact wrenches should be avoided when tightening bolt.

Reassembly is a straight reversal of removal.




Insert a piece of rag into the distributor plate bolt hole and tamp firmly around bolt head. This will keep dirt from getting around the bolt head and will make removal much easier.

ROTOR SERVICING

FEED EYE RING

Wear on the feed eye ring is largely determined by the material flow from the feed tube. Thus as the feed tube wears the feed eye ring will be exposed to more wear.

To minimise the wear of the feed eye ring it is essential to maintain the feed tube in the correct position. (Refer to feed tube section 6-20).



The feed eye ring wears in three places opposite the rotor ports.

Replace the feed eye ring when the upper wear plate is worn to a thickness of 3-5mm ($\frac{1}{8}$ - $\frac{3}{16}$ in.) at the inside edge.

The standard feed eye ring cannot be rotated. A two-life turnable feed eye ring is available for some models.

Premature Wear

Check feed tube is correctly positioned.

Feed Eye Ring Breakage

Material lodging between the feed tube and the feed eye ring. Check rotor build-up.

Feed Eye Ring Coming Loose


Check feed eye ring is correctly installed.

Continued ►

ROTOR SERVICING

FEED EYE RING

REMOVAL/INSTALLATION



Removal

1. Remove hopper, crusher top and cascade assembly in one lift.
2. With a hammer hit the top of the rotor (not the feed eye ring) above the wear plates to loosen the build-up.
3. Turn the feed eye ring counter-clockwise until the locking tabs line up with the slots in the rotor top. If material build-up stops the worn feed eye ring from turning use a soft blow hammer to tap the feed eye ring counter-clockwise.
4. Lift the feed eye ring out.


Installation

1. Ensure mating surfaces are clean and free of snags. If refitting upper and lower wear plates ensure these are in position.
2. Position feed eye ring so locking tabs and slots line up.
3. Lower feed eye ring and turn clockwise to lock in place.


ROTOR SERVICING

FEED TUBE

Replace feed tube just before the bottom lip is exposed above the feed eye ring.
The feed tube should wear evenly up the casting.




Maintaining the correct position of the feed tube in the rotor will result in increased life for the feed eye ring and upper wear plates.



Uneven Wear

Feed tube wearing on one side - feed tube not centralised.

Check feed tube and cascade assembly. (To centralise cascade assembly see section 6-48).




Cracking and Breakage

Feed tube cracking on bottom edge - excessive rotor build-up is rubbing on feed tube and causing overheating.

Adjust trail plates to reduce build-up.

Feed tube breaks - can be caused by excessive build-up in rotor, stones wedging between feed tube and feed eye ring, feed eye ring coming loose or the feed tube coming loose (check clamp sleeve).




Continued ►

ROTOR SERVICING


FEED TUBE

REMOVAL/INSTALLATION




Removal

1. Remove the hopper from the crushing chamber assembly.



2. Clear stones from around feed tube, clamp sleeve and retaining wedge.
3. Remove retaining wedge and knock the clamp sleeve clockwise to release.
4. Lift clamp sleeve out.
5. Lift feed tube out.



Installation


1. Ensure feed tube holder is free from stones, etc.
2. Lower feed tube into place.
3. Ensure it is centralised and level.
4. Refit clamp sleeve.
5. Turn clamp sleeve into locked position and insert retaining wedge.

ROTOR SERVICING

TRAIL PLATES

Check trail plates for wear. Replace if badly worn or rotor build-up needs adjusting.

In some applications, trail plates are changed at the same time as the rotor tips – just to keep the stone bed profile constant. Regular change of trail plates maximises rotor tip life and is often very cost effective.



SELECTION OF TRAIL PLATES

The trail plates are the heart of the rotor. The size, position and angle of the trail plate controls the size of the rotor build-up and the flow of material through the rotor.

Incorrectly sized or shaped trail plates can result in premature wear on every rotor wear part. (See rotor tuning 6-28).

A number of trail plate profiles are available. For information regarding trail plate options, contact your Barmac representative.


CAUTION: The use of different sized trail plates can create uneven build-up which may cause severe vibration. Ensure that trail plates are matched in size and shape. Differently positioned trail plates in each port may create uneven build-up which may cause vibration.

Continued ►

ROTOR SERVICING


TRAIL PLATE

REMOVAL/INSTALLATION



Removal

1. Remove hopper, crusher top and cascade assembly in one lift.
2. Remove trail plate retaining bolts. Bolts will be covered with build-up and will have to be knocked out with a hammer and punch. Care should be taken not to damage threads.
3. If trail plate is held in by the build-up, a sharp blow with a hammer will break away the build-up and allow the trail plate to fall free.




Installation

1. Clean out any remaining build-up.
2. Position trail plate and insert bolts.
3. Insert bolt from the inside of the rotor.
4. Tighten bolt to hand tight.

ROTOR SERVICING


ROTOR BODY

The following areas are subject to normal wear – the comments provide a guide to causes of unusual rapid wear.



Top Wear Plate

Feed tube too short and material is discharging over the top of the rotor or dust has accumulated on the air transfer blades and is rubbing on the rotor. Replace feed tube or remove dust build-up. If the top wear plate continues to wear it may be necessary to replace the mild steel top wear plate with a more wear resistant material. Please contact your Barmac representative.




Continued ►

ROTOR SERVICING

ROTOR BODY


Top Edge Worn

Cascade wear skirt and/or cavity ring is worn. Replace worn parts. See section 6-49.




Streaming Wear

This is more prevalent in very abrasive fine applications, and is caused by dust streamlining around the tip carrier wear plate. Effects can be reduced by sealing the gap between the top and bottom edges of the tip carrier wear plate and the rotor with a silicone rubber or urethane sealant.




Cavity Wear

In very abrasive fine applications, this area can be subject to light wear. If it becomes a problem, wear resistant plates can be fitted to the base plate of the cavity. Please contact your Barmac representative.



Bottom Edge Worn

Can be a feature of high tonnage operation or indicative of excessive buildup in the base that is rubbing on the rotor. Reduce build-up by reducing moisture content of feed or introducing water spray system. See section 6-51.




ROTOR SERVICING

ROTOR WEAR PROTECTION PLATES


TOP WEAR PLATE

The top wear plate, although only mild steel, should not wear rapidly, but it should be inspected and replaced before the rotor body is damaged. If rapid wear occurs, wear resistant plates may be required. Contact your Barmac representative for details.



CAVITY WEAR PLATES

The cavity wear plates should be replaced before wear progresses to the body of the rotor. Remove the bolts and nuts holding the wear plate to the rotor body and replace. Always replace all three cavity wear plates with a matched set to maintain balance.




ROTOR SERVICING

ROTOR BUILD-UP

PRIMARY FUNCTION

The build-up in the rotor needs to protect the internal walls of the rotor and most importantly protect the rotor tip from direct wear and impact.



SECONDARY FUNCTION

The build-up in the rotor can influence the wear patterns of the wear parts in order of importance:

- ROTOR TIPS
- TIP CARRIER WEAR PLATES
- UPPER AND LOWER WEAR PLATES
- DISTRIBUTOR PLATE
- FEED EYE RING

While large build-ups tend to assist in the protection of the above wear parts – particularly the rotor tips – they can greatly increase feed tube wear.

- See rotor tuning section 6-28.

ROTOR SERVICING

ROTOR TUNING

The success of the Barmac is centred around its rotor. If the rock build-up within the rotor is ideal, then wear on the upper and lower wear plates will be even, the rotor tips fully utilised, and the lowest consumables cost per tonne of product will be achieved.

DIFFERENT MATERIAL CHARACTERISTICS

Unfortunately, the build-up characteristics are never the same for any two materials, indeed the nature of the build-up will vary with rotor speeds, rotor sizes, feed rates, feed sizes, and feed moisture.

TUNING ON SITE

A factory delivered rotor will rarely work at optimum efficiency without some degree of tuning. It is normal that some tuning will be required as each rotor is placed into service. Tuning relates to controlling the build-up of material within the rotor. This is done by altering the size, position, shape, or style of the trail plates.

PRIMARY FUNCTION

The main purpose of tuning is to ensure that the build-up within the rotor extends from the trail plate to the inserts in the rotor tip, and that the wear is centralised across the rotor tips.

Insufficient build-up will result in tip exposure. This will lead to early failure of the rotor tips through the chipping of the inserts by direct contact with the larger stones in the feed. Insufficient build-up of material will expose the supporting metal of the rotor tips. This will also lead to premature failure of the inserts by direct abrasion from the stone flow through the rotor. This can also result in the rotor tips wearing in front of the inserts which will eventually lead to their falling out of the carrier plate.

BASIC PRINCIPLES

In tuning the rotor one should try to maximise the build-up within the rotor to achieve:

- A build-up of rock within the rotor to protect the wear parts and not restrict the feedpath through the crusher.
- A build-up that clears the side and bottom of the feed tube, preventing premature feed tube wear.
- An equal flow through each rotor port, equalising the wear on the rotor tips.

Continued ►

ROTOR SERVICING

ROTOR TUNING

ADJUSTMENT OF ROTOR BUILD-UP


The width and position of the trail plates will control the amount and characteristics of the build-up in the rotor.

The following is meant only as a guide, as rotor build-up is dependent on many factors: material type, moisture content, rotor speed, etc., and trial and error will have to be employed to determine the correct trail plate position for each application.


Generally -

- Wide trail plates make the material build-up deeper.
- Narrow trail plates make the material build-up shallower.
- Moving the trail plate away from the rotor tip makes the build-up shallower and moves the peak away from the tip.
- Moving the trail plate toward the rotor tip makes the build-up deeper and moves the peak toward the tip.

Lack Of Build-up




If build-up is not up to rotor tip — Increase trail plate width until build-up approaches rotor tip.




If build-up starts to encroach on feed tube — Pack trail plate toward tip. This will move the peak of the build-up past the feed tube without reducing rotor tip build-up.

Too Much Build-up



If build-up is rubbing on feed tube — Reduce trail plate width until build-up starts to pull back from rotor tip.




If build-up is still encroaching on feed tube, packing the trail plate forward will again move the build-up peak past feed tube without reducing tip build-up.

Continued ►

ROTOR SERVICING


ROTOR TUNING

ADJUSTMENT OF ROTOR BUILD-UP




If wear path is too high—

1. Shorten bottom of trail plate by gradual increments.
- OR
2. Extend top of trail plate by gradual increments.
- Ensure that rock build-up depth is maintained.



If wear path is too low—

1. Extend bottom of trail plate by gradual increments.
- OR
2. Shorten top of trail plate by gradual increments.



Increasing the width of the trail plate increases the depth of the rotor build-up. Decreasing the width of the trail plate decreases the depth of the rotor build-up. Increasing the trail plate thickness at the top increases the rotor build-up at the top and encourages material to move lower when leaving the rotor.

Increasing the trail plate thickness at the bottom increases the rotor build-up at the bottom and encourages material to move higher when leaving the rotor. The rotor build-up cross section will reflect the trail plate shape.

Adjustment of the trail plates should be made by cutting thin (6mm [$\frac{1}{4}$ "]) slices off. Large adjustments should not be made as the problem may simply move to the opposite extreme, i.e. top end tip wear may become bottom end tip wear.

NOTE: ALL TRAIL PLATES SHOULD BE THE SAME SIZE AND SHAPE OR AN OUT-OF-BALANCE SITUATION MAY RESULT.


ROTOR SERVICING

ROTOR REBUILDING



WARNING: Do not attempt to weld on rotor while it is in the machine or arcing damage will cause premature failure of the bearings.

1. Remove rotor (see 6-32).
2. Clean out all wear parts and build-up.
3. Do not weld on balance machine.
4. Spin rotor on balance machine to check for low spots on periphery. Mark them.
5. Build-up top edge to original diameter and roundness.
6. Build-up bottom edge to original diameter and roundness.
7. Replace top plate as required.
8. Effect any internal repairs.
9. Balance rotor.




NOTE:

- Use electrodes with a hardness of 400-500 Brinell such as Vidalloy-30. For submerged arc machine welding use Lincoln 550 flux with L60 wire or equivalent. Use Low Hydrogen rods for structural repairs.
- Frequent minor rebuilding is cheaper than infrequent major rebuilding work.

ROTOR SERVICING


ROTOR REMOVAL



- ① Remove hopper, crusher top and cascade assembly in one lift.
- ② Pick out material from the centre of the distributor plate and remove the rag or paper from around the distributor bolt. Remove the distributor bolt and take out the distributor plate.

NOTE: Prevent any material falling down the threaded distributor bolt hole. Use a rag or put the distributor bolt back in.

- ③ Remove the top plate bolts and the top plate.
- ④ Attach the rotor lifting plate. Bolt down with four bolts and tighten bolts in series until fully screwed in to force rotor off taper lock.
- ⑤ Lift out rotor using eyebolt in rotor lifting plate.



ROTOR SERVICING

ROTOR INSTALLATION

The life of a Barmac bearing cartridge is greatly reduced when the rotor is running with excessive vibration for long periods. When this vibration is extreme, there is potential for catastrophic failure, i.e. shaft breakage.

One factor which has a direct influence on the smooth running of a Barmac is the fit between bearing cartridge and rotor. The correct procedure for securing a rotor to a bearing cartridge is as follows:-

1. PREPARATION


Thoroughly clean the shaft, key, taper lock and rotor boss. Coat these surfaces with light oil or dewatering fluid and wipe down prior to assembly. Ensure the key screw is not proud of the outer face of the key.

2. TAPER LOCK FITTING

Place a small wedge or screwdriver in the split on the TOP of the taper lock to expand it slightly. Place the taper lock, large end downward, on the shaft so that it sits hard down on the top seat plate.

Remove the wedge or screwdriver and remove any burrs on the taper lock left behind.

NOTE: Do not expand the taper lock any more than necessary to achieve a snug sliding fit onto the shaft. Excessive expansion of the taper lock can break it.




ROTOR SERVICING

ROTOR INSTALLATION

3. ROTOR TAPER CHECK

If the rotor being fitted has just been repaired and/or reconditioned around the taper area (i.e. has undergone extensive welding that may cause distortion), it is recommended that the fit between rotor and taper lock be checked prior to final fitting.

To do this, blue the bore of the rotor boss and lower onto the taper lock on the shaft. (Use the rotor lifting plate or, for the 300 rotor, the lifting sling supplied with the crusher). Ensure the taper is properly seated under the weight of the rotor and then remove. You should see a blue mark on the taper lock indicating contact with the rotor boss. This mark should cover at least 80% of the circumference and 80% of the length of the taper. Any less contact than this will require replacement of the rotor boss. If this is not practical (e.g. the boss is welded in), consult your Barmac representative for further advice.





4. ROTOR FITTING

Fit the rotor lifting plate to the rotor boss and lower the rotor onto the taper lock. Before removing lifting plate, line up two spare holes in lifting plate with any holes in the taper lock.

Remove the lifting plate bolts evenly, allowing the rotor to slide onto the taper lock under its own weight. With the rotor firm on the taper lock there must be at least 2mm ($\frac{1}{16}$ in.) between the top of the taper lock and the top of the rotor boss.

NOTE: The rotor must be lowered square to the shaft onto the taper lock. Failure to do so may result in a poor mating of the tapered surfaces and hence vibration problems.



ROTOR SERVICING


ROTOR INSTALLATION

5. SECURING BOLTS

Insert the bolts through the top plate into the taper lock and tighten evenly. This pulls the taper lock up tight on the shaft and rotor boss.

Model	Torque Nm (ft lbs)
B3000	34 (26)
B5000	60 (45)
B6000, B7000, B8000, B9000	250 (190)


For the larger rotors, fit the additional 8 outer bolts through the top plate into the rotor boss and tighten. This fills the holes that are necessary for removal and provides positive drive between the taper lock and rotor boss in addition to the friction fit of the taper. Torque to 250 Nm (190 ft lbs).



6. FINAL CHECK

Stand on top of the rotor (if possible) and try to rock it from side to side. If there is excessive movement or if you feel the rotor "settle" at all, recheck the torque on all bolts.

Note that there will be a small movement of the shaft within the bearings. This is normal. This check simply confirms that the rotor is properly seated on the taper lock.



7. DISTRIBUTOR PLATE FITTING

The distributor plate must now be fitted to protect the taper assembly. Note that the centre bolt of the distributor plate cannot be relied upon alone to secure the rotor to the shaft. (See 6-17).

ROTOR SERVICING

ROTOR BALANCING


It is important that the Barmac rotor is properly balanced in order to provide the maximum trouble-free life of the bearing assembly in the crusher. Svedala manufactured rotor balance machines are designed specifically, and only, for this job.

To get the best results from the balance machine, it must be properly set up and in good mechanical order.

ASSEMBLY - SMALL ROTOR BALANCE MACHINES (300 and 500 rotors only)

The bearing assembly of these machines is supplied fully assembled. All that remains is to:

1. Assemble the RHS support to the base with the bolts provided.
2. Assemble the bearing assembly to the RHS support with the nyloc nut provided.



Continued ►


ROTOR SERVICING

ROTOR BALANCING

ASSEMBLY – LARGE ROTOR BALANCE MACHINES (690mm, 760mm, 840mm and 990mm rotors only)

These machines require full assembly as follows:

1. Assemble the two side plates of the frame with the joining plates, threaded rod and nuts supplied.
2. For 840mm and 990mm rotors only, fit the adapter sleeve to the balance shaft.
3. Clean the bearings in solvent to remove all traces of dirt, grease, oil, etc. Fit the bearings to the balance shaft and tighten the grub screws.
4. Rest the shaft assembly on the frame. The shaft should rotate freely.



Continued ►

ROTOR SERVICING

ROTOR BALANCING

WHEN TO BALANCE

- The rotor must be balanced after any repair work has been carried out, e.g. hardfacing.
- In the case of 300mm rotors, the rotor must be balanced after turning or changing the upper or lower wear plates.
- It is advisable to check the balance if the vibration switch trips out repeatedly and the wear plates appear to be in good condition.


OPERATION

In all cases, remove rock build-up, dirt, old wear parts, etc. before attempting to rebalance the rotor.

- For 300mm rotors, re-fit clean wear parts in the new position ready for next period of operation.
- Make sure the taper in the rotor and on the rotor balancer are clean and free from damage.

SMALL ROTOR BALANCE MACHINES

1. Lay the rotor balance machine on its back and lower the rotor onto the taper.
2. In the case of 500mm rotors, assemble the adapter washer onto the the balancer housing.
3. Lock the rotor on with the locknut.
4. Tilt the rotor upright.
5. Make sure the balancer is level.



Proceed to BALANCING PROCEDURE.


Continued ►

ROTOR SERVICING

ROTOR BALANCING

LARGE ROTOR BALANCE MACHINES

1. Ensure the balance frame is level.
2. Remove bearing from the end of shaft that passes through the rotor.
3. Insert the balance shaft through the rotor.
4. Locate rotor on taper, ensure that the two tapers fit evenly, fit rotor balance washer and rotor balance locknut and tighten with hammer.
5. Fit bearing back onto shaft and tighten grub screw.
6. Using suitable lifting apparatus, position the rotor and balance shaft on the support frame.



Proceed to **BALANCING PROCEDURE.**

Continued ►

ROTOR SERVICING

ROTOR BALANCING

BALANCING PROCEDURE

1. Thoroughly clean out rotor of all rock, dirt, old wear parts and any old welded on weights from a previous balance (see fig. 3). Check for perforations in the inner and outer walls.
2. Check taper in rotor boss is clean and free from damage.
3. Remove weights from previous balance and set rotor up level in rotor balancing frame.
4. Gently rotate the rotor and allow it to wind down to a stop. The heaviest point on the rotor is now at the bottom.
5. With chalk mark the blades A, B, and C (see fig. 1).
6. Add weights to the blade A (fig. 1) until blade B is at top dead centre. Each time a weight is added give the rotor a gentle push in the direction you are working and allow the rotor to settle to the new balance point. This helps overcome bearing friction.
7. When blade B has settled at Top Dead Centre, pull it around 90° and hold it steady there by hand (fig. 2).
8. Add weights to the blade you are holding down (B) until it doesn't try to go up or down.
9. Sometimes the blade B won't take enough weights to balance the rotor. If this is the case cut a piece of 50mm x 12mm (2 in. x ½ in.) flat bar 200mm (8 in.) long and weld it onto the B section where indicated (fig. 3). Use a small tack weld so the weight is easy to remove for the next balance. Repeat the whole balancing exercise.
10. When you think the rotor is balanced, rotate the rotor in 90° steps four times. If the rotor does not move from each stop, it is balanced.
11. Tighten the balance bolts.
12. Keep spare weights in a safe place.


NOTE: To check that the rotor is now properly balanced, remove one balance weight and confirm that the rotor is out-of-balance.

IF SO: Replace the weight. The rotor is now balanced.

IF NOT: There may be a fault with the balance machine. The balance machine should be sensitive enough to detect an out-of-balance condition less than the effect of one balance weight.


- Refer to Troubleshooting 6-40.

Continued ►

ROTOR SERVICING**ROTOR BALANCING**


Typical rotor position after step 4. Add weights to 'A' until 'B' moves to T.D.C.

FIG. 1



Step 6: 'B' is pulled around 90° from T.D.C. Add weights to 'B' until rotor does not try to turn.

FIG. 2



Step 8: If you can't get enough weights into position B, weld flat weight inside rotor as shown and start again.

FIG. 3

Continued ➤

6

ROTOR SERVICING

ROTOR BALANCING

TROUBLESHOOTING

If the rotor fails to balance properly, check the following:

- Make sure there is no loose material in the rotor that could be moving as the rotor is turned.
- Make sure the rotor balance machine is level and the bearings are totally clean.
- Make sure the tapers are in good condition.
- Make sure the bearings are not damaged or worn.

After all checks have been made, attempt to balance the rotor again from stage 1.

MAINTENANCE

The rotor balance machine is designed to give many years of trouble-free operation. However, as with any precision machinery, proper care must be taken to ensure this is the case.


- Wrap a cloth around the taper on the balance machine when not in use.
- For the large balance machine, remove the bearings from the shaft and store in a container of light machine oil.
- Store all components in a clean environment.

CRUSHER SERVICING

CRUSHING CHAMBER


BUILD-UP

- The chamber should have a full rock lining covering all items of the structure except for the faces of the radial gussets (see below).
- The outer wall must not be exposed.
- The feed areas must be free of fines build-up and debris.
- Build-up should not be excessive, i.e. blocking material flow routes or encroaching on moving parts.



Initially, the bottom crushing chamber gussets may protrude through the build-up. These will soon wear to their Ideal level. This is quite normal.


On stopping the crusher, if the time between shutting off the feed and the rotor stopping is more than 5 minutes, air movement in the crusher may blow away much of the lighter material from the stone bed, giving the impression of insufficient build-up. In these cases, stone beds will be re-instated shortly after starting to feed material again. This can be confirmed by 'crash-stopping' the plant, to minimise the chance of air blowing material away.



Chamber Wall Exposed

Caused by bony feed, very dry feed, or rounded feed. The addition of fines to a rounded or bony feed and or adding some water will enable the build-up to form.

Normally a good build-up is held but occasionally it erodes - caused by running with intermittent feed or by running empty for a period of time and blowing the build-up out.



Excessive Buildup

Feed moisture content too high and/or high fines content. Remove moisture and/or reduce fines content. Where this is not practicable a water spray system may be required.

In some instances, removal of some of the radial gussets is recommended. Please contact your Barmac dealer for advice.


Continued ►

Frequent operation of the crusher running light/empty may reduce stability of the build-up and increase the likelihood of gusset and/or casing wear.




CRUSHER SERVICING**CRUSHING CHAMBER****CAVITY RING**


When the cavity ring becomes worn it must be replaced.

**COARSE**


Replace when 5mm (1/4 in.)
left as shown.

**FINE (B9000 model only)**

Replace when 40mm (1 1/2 in.)
left as shown.

Removal


1. Remove hopper, crusher top and cascade assembly in one lift.
2. Open the door.
3. Weld an eye to the cavity ring on each side of the door opening.
4. Using a riggers hoist, pull the ring in until there is about 12mm (1/2 in.) gap all the way around.
5. Lift the ring off with a crane, or
6. Cut the old cavity ring up with a gas torch and remove it in sections.



CRUSHER SERVICING

CASCADE CHOKE

If the edges of the feed hole are excessively worn, it is necessary to replace these edges.




Continued ►


CRUSHER SERVICING

CASCADE CHOKE

REMOVAL/INSTALLATION



If cylinder requires service, unhitch from the back of the choke and refer to Cylinder Servicing on the following page.




Continued ►



CRUSHER SERVICING

CASCADE CHOKE

CYLINDER



Disassembly

(Refer to drawing above).

All repair work should be carried out in a clean, dust free environment.

1. Fully clean outside of cylinder prior to disassembly.
2. Remove the gland nut and slide the spear and piston assembly from the cylinder.
3. Unscrew the piston and slide the gland nut off the spear.
4. Remove all the old seals.


Assembly

(Refer to drawing above).


1. Clean all cylinder components.
2. Refit the internal seals into the gland nut.
3. Slide the gland nut over the spear.
4. Fit the o-ring onto the end of the spear and refit the piston.
5. Fit the piston seal and slide the piston into the cylinder.
6. Fit the external gland nut o-ring and refit into the cylinder.

CRUSHER SERVICING

AIR TRANSFER





This area should be cleaned to avoid build-up causing dust emission.



CASCADE CENTRALISATION

Every time the cascade assembly is removed from the crusher it is important to check that the feed tube is centrally located in the feed eye ring.

The position of the cascade assembly can be adjusted by the adjustment screws located on the arms of the cascade assembly.



CRUSHER SERVICING


CASCADE WEAR SKIRT

Like the cavity ring, this is a secondary wear part and under normal conditions wears little, but needs checking. High cascade wear skirt wear rates could indicate low feed rates or a worn cavity ring.


The cascade wear skirt should be replaced when wear on rotor top edge increases.



Removal



Installation




CRUSHER SERVICING

FEED HOPPER

It is important to check the general condition of the hopper. Material flow from the conveyor, feeder and/or chute work may create wear in the hopper structure. Adjust flow of material to correct.

FEED SPREADER PLATE

Changes in material flow may necessitate changing the position of the feed spreader plate. It is important that the material flow is centralised but not allowed to flow involuntarily through the cascade ports. The feed spreader plate will be subject to secondary wear. Replace or build-up with hardface welding in areas indicated.



CASCADE PORTS


Check rubber skirt for damage or wear. Replace as required. Check edges of cascade ports for wear. Build-up with hardface weld as required.

SWING BOLTS

Check swing bolt threads and hinge action. Replace damaged swing bolts and/or swing bolt roll pins as required.

INSPECTION DOORS AND HATCHES

Ensure all inspection hatches, doors, guards and locks are secure. Ensure safety pin is in inspection door.



DOOR SAFETY INTERLOCK

Regularly check that the safety interlock device is offering the operator or maintenance staff adequate protection. If your Barmac has been fitted with a Door Safety Interlock, refer to the separate manual supplied with the machine for additional service information.


VIBRATION SWITCH

It is very important to check regularly that the vibration switch is operating. For detailed information refer to the Vibration Switch Manual provided with the machine for full testing and service instructions.

CRUSHER SERVICING

CRUSHER BASE

It is very important that material does not build-up under the rotor. This can cause severe wear and possibly damage bearings and/or the main shaft. Build-up should not impede flow of material to the discharge chutes.



Excessive Build-up

Excessive build-up can be caused by:

- (1) Moisture content of feed too high
- (2) High percentage of fine material in feed
- (3) A combination of 1 and 2


If the moisture or fines content cannot be lowered, please contact your Barmac dealer for advice. This problem can be overcome by fitting a water spray system and/or low friction liners in the base of the crusher. In extreme cases air cannons are recommended. Your Barmac dealer has access to recommended systems.

DISCHARGE CHUTES

Discharge chutes must be clear. In moist feed applications the discharge chutes need to be checked for possible build-up.

Check if the discharge chutes design restricts the flow, i.e. size or angle.

If moist material is creating a problem, consider lining with low friction material.




Check for
build-up

CRUSHER SERVICING

BASE STAY CASTINGS

Check wear castings on bearing cartridge gusset.
Replace as required.



GREASE DISCHARGE CHUTE

Check regularly that the grease discharge chute is not building up with grease. Clean out as required. See 6-2.



WARNING: Excessive build-up of grease may cause an overflow of grease onto the V-belts, causing premature failure of the V-belts.

BELT GUARDS

Ensure that all guards are in place and secure.

MOTORS

Check for missing bolts, bearing noise, excessive shaft float or damage and obstruction to fan cover. Grease according to manufacturer's instructions.

CRUSHER SERVICING

BEARING CARTRIDGE

BEARING CARTRIDGE SEALS


Many premature bearing cartridge failures can be attributed to failure of the upper seals within the cartridge. It is recommended these upper seals be inspected at least annually and replaced if found to be worn or broken. This inspection/replacement can be done with the bearing cartridge installed in the base of the crusher and with the rotor removed.

The lower seals cannot be inspected or replaced while the cartridge is installed in the base but are very unlikely to cause a premature failure of the cartridge. These seals are always replaced during the repair/reconditioning process.

To inspect/replace upper seals:

1. Remove the top key and slide top seal plate off shaft.
2. Remove the o-ring from within the top seal plate. This is a static seal and may have a flat surface from contact against the shaft. If the seal is not broken or obviously damaged in any other way, it can be re-used.
3. Inspect the labyrinth between the bearing and the outermost seal. This should always be fully packed with clean grease. If the grease is not clean, the v-ring seals are not effective and must be replaced.


If the labyrinth is not completely packed with grease, there could be a problem with the grease supply to the Barmac (check hoses, etc) or with the lubrication schedule. (See 6-2).



Continued ►

CRUSHER SERVICING

BEARING CARTRIDGE



The bearing cartridge is a grease filled, sealed bearing assembly which can be removed in one piece (shaft, bearings, seals and housing) for overhaul and inspection.

When the new bearing cartridge has run between 100 and 150 hours, begin a series of routine checks on the run down time of the rotor (time from power being cut to rotor stops turning).

A significant decrease in the run down time over a period will indicate that the bearings (crusher or motor) are deteriorating. Once the time falls below two minutes the bearings should be checked at the next routine service time.

Operators should become familiar with the sound of the bearings running. If this noise changes, especially if it begins rumbling, this will also indicate that the bearings are deteriorating.

If, when standing on top of the rotor during servicing, the shaft can be rocked from side to side with excessive float, then the radial bearings are worn.

If no-load current begins to increase slowly over a period of time, this is an indication that the crusher bearings are worn.


Upper seals should be replaced and labyrinth repacked with grease at yearly intervals.

Continued ►


CRUSHER SERVICING

BEARING CARTRIDGE


4. Remove the one or two v-ring seals (depending on the Barmac model) from the upper bearing retaining ring. These should not be worn, cracked or broken.




Normal Condition



Worn



Cracked





Broken

5. Refit/replace seals as necessary, pack the labyrinth with grease, refit top seal plate and key.
6. Refit the rotor and start the Barmac. Apply twice the normal amount of grease to each nipple and continue with normal operation.



DO NOT RUN THE BARMAC WITHOUT ROTOR FITTED.

CRUSHER SERVICING**BEARING CARTRIDGE****REMOVAL FROM BASE**

1. Remove hopper, crusher top and cascade assembly in one lift.
2. Remove the rotor. (See 6-56).
3. Loosen off belt tension and remove V-belts.
4. Remove Barmac pulley. In larger models, use a threaded rod (in the threaded hole in shaft) and support to assist in lowering pulley.



5. Remove grease hoses and grease chute.
6. Release the bottom taper ring by removing the taper ring bolts.
7. Screw half of these back into the top of the tapered extractor holes to force the outer taper ring off.
8. Remove the bottom inner taper ring.





Continued ►

CRUSHER SERVICING

BEARING CARTRIDGE

REMOVAL FROM BASE

- 9. Remove the top taper ring bolts.
- 10. Use extractor grub screws to remove top taper ring.
- 11. Insert lifting eye bolt into the top of the shaft.
- 12. Lift out bearing cartridge.




CRUSHER SERVICING

BEARING CARTRIDGE

REFITTING CARTRIDGE IN BASE

1. Remove all traces of grease, protectant, dust, etc, from machined surfaces using thinners or similar solvent.
2. Ensure all mating surfaces are free from rust, dents, scratches, etc.
4. Apply a thin layer of heavy machine oil to the mating surfaces of the bearing housing, cartridge housing and taper rings.
5. Lower bearing cartridge into top of cartridge housing and check to see that the three plastic grommets are still in place. This will ensure the grommets are not lodged in the cartridge housing.
6. Check orientation of cartridge. The grease discharge slot must align with the grease discharge chute.
7. Locate bearing cartridge centrally with top taper ring.
8. Fit bottom taper rings (inner and outer) and lightly screw in bottom taper ring bolts.
9. Fit grub screws in until just below flush with top of taper rings and secure in place with silicone.
10. Refer to Bearing Cartridge Bolt Torque Settings (6-59).



Continued ►

CRUSHER SERVICING

BEARING CARTRIDGE

REFITTING CARTRIDGE IN BASE

- Starting on top taper ring, torque down bolts top and bottom in a "star" sequence (Fig.1) in two stages. Torque bolts in order from 1 to 8. Repeat for bottom taper ring.

Torque settings are as follows:

B3000, B5000

Stage 1 - 15Nm (11 ft lb)

Stage 2 - 30Nm (22 ft lb)

B6000, B7000, B8000, B9000

Stage 1 - 70Nm (55 ft lb)

Stage 2 - 130Nm (100 ft lb)




Fig.1

- Refit grease hoses, making sure they are not twisted or blocked. See 6-5 for identification of grease points on bearing housing. Ensure that grease hoses are not able to fall onto V-belts during operation. Note: Some models have a bar to rest the grease hoses on.
- Refit pulley and drive belts.
- Refit rotor.

BELT TENSIONING


Correct belt tensioning is the most important factor necessary for long, satisfactory V-belt operation. Too little tension will result in slippage, causing rapid belt and sheave wear, and poor efficiency. Too much tension results in excessive strain on belts, bearings (especially motor bearings), and shafts.

PROCEDURE

Measuring

1. Select the second V-belt from the bottom.
2. Measure the force required to deflect the V-belt the distance as set out below:

Apply force on belt through V-belt inspection hatch towards centre of belt span



Force and deflection for each model and V-belt type can be found on the *Belt Tension/Deflection Chart*, overleaf.

3. For measuring the force and deflection, Svedala recommend the use of a tension gauge similar to the one represented.

Using the belt tension gauge at the centre of the belt span, follow these instructions:

- (a) Set the large 'O' ring on the designated deflection as per the *Belt Tension/Deflection Chart*.
- (b) Push the belt tension gauge against the second to bottom belt until the large 'O' ring is even with the top of the next belt. Ensure that the gauge is in the centre of the belt section, and always test the belts on the tight (or driven) side of the belts.
- (c) Remove the gauge and observe that the small 'O' ring has moved from its original setting at zero to the number of kg (lb) required to deflect the belt.

Adjustment

1. Slightly loosen off motor mount bolts.
2. Tighten (or loosen) tension by adjusting belt tension adjuster nuts.
3. Adjust belt tension as per the *Belt Tension/Deflection Chart*. (For dual drive, adjust both exactly the same).



Continued ►

BELT TENSIONING

BELT TENSION/DEFLECTION CHART

Machine	Initial Installation Tension kg (lb)	Normal Running Tension kg (lb)	Deflection Distance mm (in.)
B3000	4 (8.75)	2.5 - 3 (5.50 - 6.50)	10 (3/8)
B5000	10 (22.00)	8 - 9 (17.50 - 19.75)	16 (5/8)
B6000	11 (24.25)	8 - 9 (17.50 - 19.75)	19 (3/4)
B7000	16 (35.25)	12 - 14 (26.50 - 30.75)	27 (1)
B8000	16 (35.25)	12 - 14 (26.50 - 30.75)	27 (1)
B9000	16 (35.25)	12 - 14 (26.50 - 30.75)	27 (1)

NOTE: The above belt tension/deflection values relate to SP, SPX, V and VX belt sections, and have been formulated to accommodate the various centre distances that motor frame sizes or sheave diameters will provide on each model. If V-belt life, tensioned to the above values, is not satisfactory, please contact your Barmac representative.

NEW BELTS (This includes the initial commissioning of the crusher).

New belts will take a little time to settle into the grooves, and will naturally stretch in the first days of operation. To accommodate this settling in process, it is recommended that the V-belts are tensioned some 20% above the optimum. Refer to the *Belt Tension/Deflection Chart* under **Initial Installation Tension** column for the recommended tension for the standard deflection for new belts.

Tension Range

Belt tension should be monitored regularly (at least weekly), but does not need adjustment unless it falls outside the range indicated in the **Normal Running Tension** column

RUNNING IN NEW BELTS (This includes the initial commissioning of the crusher).

After 30 Minutes

After thirty minutes running it is recommended that the tension should be checked and retensioned to the **Initial Installation Tension** values.

After 4 Hours

Re-tension to the **Initial Installation Tension** values.

Next 5 Days

Check tension at least once daily and you should observe a "settling", requiring minimum adjustment to maintain the tension as per the **Normal Running Tension**.

Continued ►

BELT TENSIONING

LOOSE BELTS

In the event of there being one or two belts being looser than the others, tension the belts normally, and measure the deflection force required on the loose belt. If this is 10% or more below the low range tension, then there is a danger that the loose belt could turn, or even jump off, taking the rest of the set with it. If the belt is one of a new set, then initially add an extra 1kg (2 lb) of pressure relative to tension to that particular side of the drive, to see if the belt will "settle in" on its own. If this has not happened within 5 days or if the loose belt does not tension up to the minimum, then the loose belt must be replaced.

DUAL DRIVE

Belt Tension/Balanced Motor Amps

On dual drive Barmacs, one motor may draw less current than the other, i.e. it appears lazy. For the motors to do equal work the V-belt drives must be set up with equal tension.

On dual drive Barmacs, a small difference in belt tension between drives can make a big difference in motor amps. For example, a dual drive 185 kW (250 hp) Duopactor under full load with 0.5% slip in one drive and 1.0% in the other will show a current draw of 170 amps in one motor and 120 in the other – a 50 amp difference.

Adjustment

Static

Follow normal static adjustment procedure as explained above, but make special effort to adjust the two drives to exactly the same values.

Dynamic

1. With the Barmac operating under load, prepare the low current motor for adjustment, ensuring that when the four motor mount bolts are loosened, the motor mount is held in place by the belt tension adjuster nuts. This is done by loosening off the two motor mount bolts that pass through the adjuster rods. (See Important Note below). Apply tension to these adjuster rods by turning the adjuster nuts approximately half a turn from hand tight.
2. Then loosen off the other two motor mount bolts. **Important Note:** Loosen only enough to permit the motor mount to be adjusted by means of the adjuster nuts.
3. Turn the adjuster nuts clockwise by one turn to tighten the belts. Retighten the four motor mount bolts and observe the current drawn by both motors for ten minutes.
4. Repeat until the currents drawn by the motors are within approximately 10 amps of each other.
5. After balancing amps in this way, belt tensions should be checked as soon as possible to ensure correct balanced belt tensions. If balanced amps are achieved with unbalanced tension, the cause should be investigated.

Continued ►

BELT TENSIONING

Other Causes Of Unbalanced Motor Amps

If the motors will not draw similar amps by altering belt tension, check—

1. The motor or starter electric terminals. Have a qualified electrician check motor or starter terminals. If dirty they will need cleaning and re-fitting.
2. The starter has a fault. To confirm starter fault exists, have a qualified electrician check the following:

With the machine under load:

- (a) Read both ammeters and record amps on ammeter 1 and ammeter 2.
 - (b) Stop the machine.
 - (c) Swap motor wiring over at starter contactors.
 - (d) Restart the machine. The ammeter readings should have swapped, i.e. No. 1 should read what No. 2 used to, and vice versa. If this doesn't happen, the electrician must check the function of the starter componentry.
3. **Belt alignment** – Make sure sheaves are in line using a straight edge or string line.
 4. **Motors** – They should be of the same brand and type and preferably be manufactured in the same batch (check with motor manufacturer or agent). Different manufacturers and sometimes different batches of motors have different winding specifications.
 5. **Belts** – The belts should be matched, i.e. all the same brand at least, and a matched set if possible.
 6. **Sheaves** –
 - (a) Check sheave axes are parallel and grooves are properly aligned with one another – any dust build-up entering under the motor mount will cause the sheaves to be out of parallel, with higher tension on belts at one end of the sheave.



- (b) Check sheave diameters. For equal power transmission, the pitch diameters of the driving sheaves must be within 0.5mm (0.02") of each other. This can be checked by measurement as shown. Check grooves at each end of the sheave – any taper in sheave length will cause problems.



- (c) If after a period of satisfactory running the motors become difficult to match, check the sheaves for wear.

BOLT TORQUE SETTINGS**BARMAC BOLT TORQUE SETTINGS Nm (ft lbs)**

Model	Rotor Size	Tip Assembly	Top Plate Bolts	Dist. Plate Bolt	Top Taper Ring Bolts	Bottom Taper Ring Bolts
B3000	300	100 (75)	34 (26)	40 (30)	30 (22)	30 (22)
B5000	500	100 (75)	60 (45)	40 (30)	30 (22)	30 (22)
B6000	690	130 (100)	250 (190)	200 (150)	130 (100)	130 (100)
B7000	760	130 (100)	250 (190)	200 (150)	130 (100)	130 (100)
B8000	840	130 (100)	250 (190)	200 (150)	130 (100)	130 (100)
B9000	990	130 (100)	250 (190)	200 (150)	130 (100)	130 (100)

NOTE: All threads must be lightly lubricated before assembly.