


This document is best viewed at a screen resolution of 1024 X 768.

To set your screen resolution do the following:
RIGHT CLICK on the **DESKTOP**.
Select **PROPERTIES**.
CLICK the **SETTINGS TAB**.
MOVE THE SLIDER under **SCREEN RESOLUTION** until it shows **1024 X 768**.
CLICK OK to apply the resolution.

The Bookmarks panel will allow you to quickly navigate to points of interest.



Click on any text that is BLUE and underlined. These are hyperlinks that can be used to navigate the schematic and machine views.

VIEW ALL CALLOUTS

When only one callout is showing on a machine view this button will make all of the callouts visible. This button is located in the top right corner of every machine view page.

HOTKEYS (Keyboard Shortcuts)		
	FUNCTION	KEYS
	Zoom In	"CTRL" / "+"
	Zoom Out	"CTRL" / "-"
	Fit to Page	"CTRL" / "0" (zero)
	Hand Tool	"SPACEBAR" (hold down)
	Find	"CTRL" / "F"



Schematic

416D, 420D, 424D, 428D, 430D, 432D, 438D, and 442D Backhoe Loaders Electrical System

416D:
BKG1-3499
BGJ1-1049
BFP1-12899
CXP1-939

420D:
BKC1-919
BMC1-1059
BLN1-10299
FDP1-18399

424D:
BGP1-UP
BKR1-UP

428D:
BNB1-UP
BLL1-UP
BNS1-UP
BMT1-UP

430D:
BNK1-5899
BML1-4800

432D:
BLD1-UP

438D:
BPE1-UP
BPN1-UP

442D:
BRG1-UP
BRY1-UP

Volume 1 of 2: ENGINE AND CHASSIS

Volume 2 of 2: CAB

COMPONENT LOCATION

Volume 1 of 2 - ENGINE AND CHASSIS

Page 1 of 2



Component	Schematic Location	Machine Location	Component	Schematic Location	Machine Location
Alarm - Backup	I-14	4	Gauge - Fuel Level	F-12	A
Alternator	E-1	5	Gauge - Tachometer	F-12	A
Arc Suppressor - All Wheel Drive	F-4	24	Gauge - Tachometer with A/C Shutoff	I-8	A
Arc Suppressor - HVAC	H-1	25	Gauge - Voltmeter	F-14	A
Battery #1	D-4	6	Ground - Cab	D-4	87
Battery #2	D-4	6	Ground - Engine #1	D-1	12
Block - Lighting Diode	D-12	A	Ground - Engine #2	D-3	89
Coil - Thermal Starting Aid	F-1	86	Ground - Frame	D-4	90
Control - Shuttle Handle	H-6	24	Ground - Right Cab 1	F-7	A
Flasher	G-9	A	Ground - Right Cab 2	E-7	A
Fuse - Air Conditioning	D-7	C	Ground - Top of Cab	C-12	1
Fuse - Air Suspension Seat	A-7	B	Group - Basic Lamp	H-15	A
Fuse - All Wheel Drive	B-7	B	Group - Fault Lamp	F-15	A
Fuse - All Wheel Steer	C-7	C	Group - Function Lamp	E-4	D
Fuse - Atch Front Flood	B-7	B	Horn - Backup Alarm	H-13	4
Fuse - Atch Rear Flood	B-7	B	Horn - Forward	G-1	26
Fuse - Aux Hydraulics	C-7	C	Horn - Rear	I-14	4
Fuse - Beacon	D-7	C	Lamp - Left Headlight	H-2	95
Fuse - Bucket Position	B-7	B	Lamp - Right Headlight	G-3	96
Fuse - Engine	B-7	B	Meter - Service	D-3	24
Fuse - Front Wiper	D-7	C	Motor - Air Suspension Seat	I-11	29
Fuse - Horn	A-7	B	Motor - Front Washer Pump	I-3	10
Fuse - Key Start	A-7	B	Motor - Front Wiper	C-10	2
Fuse - Left Tail Lamp	D-7	C	Motor - HVAC Blower	H-8	30
Fuse - Monitor	C-7	B	Motor - Rear Washer Pump	I-3	10
Fuse - Power Port	B-7	B	Motor - Rear Wiper	C-15	8
Fuse - Radio	A-7	B	Motor - Starter	D-2	7
Fuse - Rear Hydraulics	B-7	B	Power Port	G-9	C
Fuse - Rear Std Floods	D-7	C	Relay - A/C Shutoff	I-8	A
Fuse - Rear Wiper	D-7	C	Relay - All Wheel Drive Braking	E-6	C
Fuse - Ride Control	C-7	C	Relay - Attachment	D-6	C
Fuse - Right Tail Lamp	D-7	C	Relay - Aux Lighting	B-7	B
Fuse - Signal Lamp	A-7	B	Relay - Aux Flood	D-10	B
Fuse - Spare 1	A-7	B	Relay - Cab	C-6	C
Fuse - Spare 2	D-7	C	Relay - High Speed	H-9	A
Fuse - Start	B-7	B	Relay - HVAC	D-6	C
Fuse - Start Aid	C-7	C	Relay - Main	B-7	B
Fuse - Transmission	B-7	B	Relay - Pressure Switch Timer	G-13	A
Gauge - Converter Temperature	F-13	A	Relay - Start	B-7	B
Gauge - Coolant Temperature	F-13	A	Relay - Std Flood	D-10	A

Machine locations are repeated for components located close together.

A = Located inside/on right console.

B = Located in machine electrical center 1.

C = Located in machine electrical center 2.

D = Located inside/on front console.

COMPONENT LOCATION

Volume 1 of 2 - ENGINE AND CHASSIS

Page 2 of 2



Component	Schematic Location	Machine Location	Component	Schematic Location	Machine Location
Relay - Std Lighting	A-7	B	Switch - Brake Fluid Level	I-3	10
Resistor - Motor Speed	H-9	15	Switch - Cold Start Temperature	F-1	5
Sender - Converter Temperature	F-1	12	Switch - Coolant Temperature	H-1	3
Sender - Coolant Temperature	H-1	13	Switch - Engine Oil Pressure	H-1	20
Sender - Fuel Level	G-1	11	Switch - Front Horn	D-3	D
Sensor - Bucket Position	I-15	16	Switch - Front Roading Lamps	F-3	3
Solenoid - Bucket Position	F-2	17	Switch - Hazard	E-3	D
Solenoid - Cold Start Advance	F-1	31	Switch - Heater / Air Conditioning	G-10	A
Solenoid - Forward Transmission	I-1	18	Switch - Heater Vent	H-7	A
Solenoid - Front Drive	G-1	19	Switch - Hydraulic Filter Pressure	G-1	32
Solenoid - Fuel Shutoff	E-1	20	Switch - Key Start	F-14	A
Solenoid - Hydraulic Shutoff	H-12	91	Switch - Loader Neutralizer	C-8	85
Solenoid - Pilot Shutoff	H-12	92	Switch - Neutral Lock	G-3	D
Solenoid - Pilot Hydraulics Shutoff	H-13	91	Switch - Park Brake	C-8	42
Solenoid - Reverse Transmission	I-1	18	Switch - Rear Horn	D-14	A
Solenoid - Side Shift Lock	H-12	93	Switch - Rear Washer / Wiper	E-14	A
Switch - Air Filter Pressure	I-3	10	Switch - Refrigerant Pressure	I-1	25
Switch - All Wheel Drive	F-3	D	Switch - Return To Dig	I-15	26
Switch - Atch Front Flood	D-13	A	Switch - Side Shift Lock	E-15	A
Switch - Atch Rear Flood	D-13	A	Switch - Stalk	H-6	24
Switch - Backhoe Handle Pushbutton	H-13	85	Switch - Start Aid	E-13	A
Switch - Backhoe Handle Pushbutton	I-13	85	Switch - Std Front Flood	G-11	A
Switch - Backhoe Hydraulic Shutoff	D-15	A	Switch - Std Rear Flood	G-11	A
Switch - Beacon	E-13	A	Switch - Thermostat	I-7	97
Switch - Blower Speed	H-10	A	Switch - Transmission Neutralizer	E-5	56
Switch - Brake A	I-6	22	Switch - Water Separator	G-1	36
Switch - Brake B	I-6	22			

Machine locations are repeated for components located close together.

A = Located inside/on right console.

B = Located in machine electrical center 1.

C = Located in machine electrical center 2.

D = Located inside/on front console.

COMPONENT LOCATION

Volume 2 of 2 - CAB



Component	Schematic Location	Machine Location	Component	Schematic Location	Machine Location
Antenna - Radio	I-3	1	Solenoid - Circle Steer (AWS)	B-10	80
Arc Suppressor - All Wheel Steer	A-11	80	Solenoid - Forward High Transmission (Gp A)	C-6	18
Arc Suppressor - Dead Engine Lower	B-6	A	Solenoid - Forward Low Transmission (Gp A)	C-6	18
Arc Suppressor - Ride Control	G-4	A	Solenoid - Left Hand Steer (AWS)	A-10	80
Coil - Machine Security Exciter	F-13	A	Solenoid - Left Loader Lock Valve	B-2	36
Control - Autoshift	D-3	6	Solenoid - Loader Detent Gp	I-13	83
Control - Aux Hydraulics	H-14	A	Solenoid - Lock Valve (AWS)	B-10	80
Control - Machine Security	E-14	A	Solenoid - Quick Coupler	H-9	48
Control - Pilot Hydraulics Loader Handle	G-12	38	Solenoid - Ride Control	G-3	49
Control - Shift Handle	F-6	24	Solenoid - Right Hand Steer (AWS)	A-10	80
Diode - Autoshift 1	D-4	6	Solenoid - Right Loader Lock Valve	B-2	45
Diode - Autoshift 2	D-4	6	Solenoid - Shutoff (AWS)	A-10	80
Dome Lamp	I-6	41	Solenoid - Speed Clutch 1	C-7	18
Horn - Backup Alarm	E-9	4	Solenoid - Speed Clutch 2 (Gp B)	C-7	18
Lamp - Indicator	C-11	A	Solenoid - Speed Clutch 3 (Gp B)	C-7	18
Lamp - License	G-8	81	Speaker - Left	I-4	46
LED - Diagnostic	D-3	6	Speaker - Right	I-4	47
LED - Machine Security	D-13	A	Switch - A Shift Ride Cont	H-4	D
Radio	I-3	2	Switch - All Wheel Steer Mode Select	B-11	D
Relay - Dead Eng Lower Command	A-7	A	Switch - Auto / Manual	E-3	D
Relay - Dead Eng Lower Enable	B-7	A	Switch - AWS Pressure	C-14	84
Relay - Left Broom Angle	G-9	A	Switch - Continuous Flow	I-7	D
Relay - Left Steer	A-15	A	Switch - COSA Ride Cont	H-4	D
Relay - Machine Security Engine	E-13	A	Switch - Dead Engine Lower	A-4	D
Relay - Quick Coupler (AWS)	B-15	A	Switch - Dual Function Ride Control	A-3	D
Relay - Quick Coupler Interlock	G-9	A	Switch - Float Detent Limit	B-2	32
Relay - Ride Control	G-4	A	Switch - Loader Rod End Pressure	G-3	52
Relay - Right Broom Angle	G-9	A	Switch - OROPS Turn Signal	G-8	53
Relay - Right Steer	A-14	A	Switch - Quick Coupler Pins	I-9	D
Relay - Park Brake Alarm	E-6	A	Switch - Rear Fog	F-11	A
Sensor - Rear Steer Position	A-10	82	Switch - Rear Steer	B-15	85
Sensor - Speed	C-7	18	Switch - Std Ride Control	H-5	D
Solenoid - Aux Hydraulics 1	G-11	42	Switch - Washer Atch	I-7	D
Solenoid - Aux Hydraulics 2	G-11	42			

Machine locations are repeated for components located close together.

A = Located inside/on right console.

B = Located in machine electrical center 1.

C = Located in machine electrical center 2.

D = Located inside/on front console.

CONNECTOR LOCATION

Volume 1 of 2 - ENGINE AND CHASSIS



Connector Number	Schematic Location	Machine Location
CONN 1	A-15, C-14, B-13	34
CONN 2	F-15	57
CONN 3	C-13, I-12	59NA, 60COS
CONN 4	C-13	57
CONN 5	H-12, I-12	62
CONN 6	H-12, I-12	62
CONN 7	G-12	63
CONN 8	D-11, B-14	64
CONN 9	D-11	63
CONN 10	G-11	A
CONN 11	H-11	A
CONN 12	H-11	A
CONN 13	I-10	63
CONN 14	I-10	63
CONN 15	F-10	A
CONN 16	F-10	A
CONN 17	F-10	A
CONN 18	I-8	A
CONN 19	D-8	A
CONN 20	I-4	18
CONN 21	H-4	18
CONN 22	H-4	D
CONN 23	G-4	D
CONN 24	F-4	D
CONN 25	I-3	10
CONN 26	H-2	25
CONN 27	H-2	25
CONN 28	E-1	25
CONN 29	I-15, F-1	45
CONN 30	F-1	12
CONN 33	E-10	A
CONN 37	F-2	18
CONN 50	C-8	42
CONN 54	H-6	D
CONN 60	C-10	2
CONN 62	C-15	8
CONN 64	H-6	24

The connectors shown in this chart are for harness to harness connectors. Connectors that join a harness to a component are generally located at or near the component. See the Component Location Chart.

CONNECTOR LOCATION

Volume 2 of 2 - CAB



Connector Number	Schematic Location	Machine Location
CONN 4	I-6	57
CONN 9	I-6	63
CONN 10	E-10	A
CONN 11	I-12, C-14	A
CONN 12	C-9, A-7, G-6	A
CONN 15	I-13	A
CONN 17	E-8	A
CONN 19	E-13, F-7, B-7, B-6	A
CONN 31	B-15, G-10	A
CONN 32	D-14, D-11	A
CONN 33	F-13	A
CONN 34	C-12	D
CONN 35 Cat Data Link	I-12, D-11	A
CONN 36	H-11	18
CONN 37	H-11	18
CONN 38	E-11	17
CONN 39	E-11, F-7	17
CONN 40	A-12	17
CONN 41 Cat Data Link	E-10	A
CONN 42	F-10	A
CONN 43	F-10	A
CONN 44	G-10	A
CONN 45	H-10	10
CONN 46	I-10	D
CONN 47	H-9, H-6	D
CONN 48	D-8, F-8	A
CONN 49	H-8	48
CONN 50	G-10	42
CONN 51	I-8	D
CONN 52	H-7	48
CONN 53	H-7	48
CONN 54	G-7	D
CONN 55	E-7, H-4	D
CONN 56	A-5	D
CONN 57	B-5	42
CONN 58	C-5	56
CONN 59	D-5	42
CONN 60	I-4	2
CONN 61	G-4	42
CONN 62	I-6	8
CONN 63	G-6	D
CONN 64	F-4	24
CONN 65	D-4	42
CONN 66	E-3	D
CONN 67 Harness Code	B-3	6

The connectors shown in this chart are for harness to harness connectors. Connectors that join a harness to a component are generally located at or near the component. See the Component Location Chart.

Component Identifiers (CID) ¹ and Module Identifier	
CID	Component
Autoshift Transmission Control (MID² No. 81)	
0168	Battery Voltage Above Normal
0168	Battery Voltage Below Normal
0268	Erratic programmed parameter fault
0346	Ride Control Relay Open Circuit
0346	Ride Control Relay Short to Ground
0346	Ride Control Relay Short to Battery
0367	Invalid Ride Control Switch Input
0368	Transmission auto/man open circuit
0368	Transmission auto/man grounded
0520	Trans Configuration Incorrect
0621	Invalid Downshift Switch
0641	Trans Solenoid 1 Open Circuit
0641	Trans Solenoid 1 Short to Ground
0641	Trans Solenoid 1 Short to Battery
0642	Trans Solenoid 2 Open Circuit
0642	Trans Solenoid 2 Short to Ground
0642	Trans Solenoid 2 Short to Battery
0643	Trans Solenoid 3 Open Circuit
0643	Trans Solenoid 3 Short to Ground
0643	Trans Solenoid 3 Short to Battery
0644	Trans Solenoid 4 Open Circuit
0644	Trans Solenoid 4 Short to Ground
0644	Trans Solenoid 4 Short to Battery
0645	Trans Solenoid 5 Open Circuit
0645	Trans Solenoid 5 Short to Ground
0645	Trans Solenoid 5 Short to Battery
0646	Trans Solenoid 6 Open Circuit
0646	Trans Solenoid 6 Short to Ground
0646	Trans Solenoid 6 Short to Battery
0650	Harness Code Unknown
0668	Shift Lever Not Responding
0668	Invalid Shift Lever Input
0683	In-Gear Relay Open Circuit
0683	In-Gear Relay Short to Ground
0683	In-Gear Relay Short to Battery

¹ The CID is a diagnostic code that indicates which component is faulty.

² The MID is a diagnostic code that indicates which electronic control module diagnosed the fault.

Component Identifiers (CID) ¹ and Module Identifier	
CID	Component
Shift Handle Control (MID² No. 117)	
0168	Battery Voltage Above Normal
0168	Battery Voltage Below Normal
0668	Shift Lever Bad Device or Component
Machine Security Control (MID² No. 124)	
0168	Battery Voltage
0248	Cat Data Link Error
0254	ECM
0817	Backup Battery
1391	MSS Output Driver #1
1392	MSS Output Driver #2
Auxiliary Hydraulic Control (MID² No. 106)	
1180	Auxiliary Hydraulic Solenoid #1
1181	Auxiliary Hydraulic Solenoid #2
1184	Auxiliary Hydraulic Solenoid Supply
1187	Continuous Flow Switch
1189	Auxiliary Proportional Lever Switch
1529	Quick Coupler Switch
1530	Quick Coupler Solenoid

¹ The CID is a diagnostic code that indicates which component is faulty.

² The MID is a diagnostic code that indicates which electronic control module diagnosed the fault.

Failure Mode Identifiers (FMI) ¹	
FMI No.	Failure Description
0	Data valid but above normal operational range.
1	Data valid but below normal operational range.
2	Data erratic, intermittent, or incorrect.
3	Voltage above normal or shorted high.
4	Voltage below normal or shorted low.
5	Current below normal or open circuit.
6	Current above normal or grounded circuit.
7	Mechanical system not responding properly.
8	Abnormal frequency, pulse width, or period.
9	Abnormal update.
10	Abnormal rate of change.
11	Failure mode not identifiable.
12	Bad device or component.
13	Out of calibration.
14	Parameter failures.
15	Parameter failures.
16	Parameter not available.
17	Module not responding.
18	Sensor supply fault.
19	Condition not met.
20	Parameter failures.

¹ The FMI is a diagnostic code that indicates what type of failure has occurred.

CID	Component
Autoshift Transmission Control (MID² No. 81)	
0168	Battery Voltage Above Normal
0168	Battery Voltage Below Normal
0268	Erratic programmed parameter fault
0346	Ride Control Relay Open Circuit
0346	Ride Control Relay Short to Ground
0346	Ride Control Relay Short to Battery
0367	Invalid Ride Control Switch Input
0368	Transmission auto/man open circuit
0368	Transmission auto/man grounded
0520	Trans Configuration Incorrect
0621	Invalid Downshift Switch
0641	Trans Solenoid 1 Open Circuit
0641	Trans Solenoid 1 Short to Ground
0641	Trans Solenoid 1 Short to Battery
0642	Trans Solenoid 2 Open Circuit
0642	Trans Solenoid 2 Short to Ground
0642	Trans Solenoid 2 Short to Battery
0643	Trans Solenoid 3 Open Circuit
0643	Trans Solenoid 3 Short to Ground
0643	Trans Solenoid 3 Short to Battery
0644	Trans Solenoid 4 Open Circuit
0644	Trans Solenoid 4 Short to Ground
0644	Trans Solenoid 4 Short to Battery
0645	Trans Solenoid 5 Open Circuit
0645	Trans Solenoid 5 Short to Ground
0645	Trans Solenoid 5 Short to Battery
0646	Trans Solenoid 6 Open Circuit
0646	Trans Solenoid 6 Short to Ground
0646	Trans Solenoid 6 Short to Battery
0650	Harness Code Unknown
0668	Shift Lever Not Responding
0668	Invalid Shift Lever Input
0683	In-Gear Relay Open Circuit
0683	In-Gear Relay Short to Ground
0683	In-Gear Relay Short to Battery

CID	Component
Shift Handle Control (MID² No. 117)	
0168	Battery Voltage Above Normal
0168	Battery Voltage Below Normal
0668	Shift Lever Bad Device or Component
Machine Security Control (MID² No. 124)	
0168	Battery Voltage
0248	Cat Data Link Error
0254	ECM
0817	Backup Battery
1391	MSS Output Driver #1
1392	MSS Output Driver #2
Auxiliary Hydraulic Control (MID² No. 106)	
1180	Auxiliary Hydraulic Solenoid #1
1181	Auxiliary Hydraulic Solenoid #2
1184	Auxiliary Hydraulic Solenoid Supply
1187	Continuous Flow Switch
1189	Auxiliary Proportional Lever Switch
1529	Quick Coupler Switch
1530	Quick Coupler Solenoid

¹ The CID is a diagnostic code that indicates which component is faulty.

² The MID is a diagnostic code that indicates which electronic control module diagnosed the fault.

Failure Mode Identifiers (FMI)¹	
FMI No.	Failure Description
0	Data valid but above normal operational range.
1	Data valid but below normal operational range.
2	Data erratic, intermittent, or incorrect.
3	Voltage above normal or shorted high.
4	Voltage below normal or shorted low.
5	Current below normal or open circuit.
6	Current above normal or grounded circuit.
7	Mechanical system not responding properly.
8	Abnormal frequency, pulse width, or period.
9	Abnormal update.
10	Abnormal rate of change.
11	Failure mode not identifiable.
12	Bad device or component.
13	Out of calibration.
14	Parameter failures.
15	Parameter failures.
16	Parameter not available.
17	Module not responding.
18	Sensor supply fault.
19	Condition not met.
20	Parameter failures.

¹ The FMI is a diagnostic code that indicates what type of failure has occurred.

SPECIFICATIONS AND RELATED MANUALS

Volume 1 of 2 - ENGINE AND CHASSIS



Related Electrical Service Manuals	
Title	Form Number
Alternator: 105-2812	SENR5841
Optional (90A): 105-2813	SENR5841
Electric Starting Motor: 143-0539	SENR3828
Autoshift Control:	REN2869
Aux Hydraulic Control:	REN3588
Machine Security:	REN2462

Off Machine Switch Specification				
Part No.	Function	Actuate	Deactuate	Contact Position
6T-2665	Engine Coolant Temperature	107.2 ± 2.8°C (225 ± 5°F)	93°C MIN (196°F MIN)	Normally Open
7W-1238	Engine Oil Pressure	62.1 to 95.1 kPa (9 to 13.8 psi)	62.1 to 95.1 kPa (9 to 13.8 psi)	Normally Closed
7X-8549	Hyd. Filter Pressure	110.3 to 138 kPa (16 to 20 psi)	86.2 to 103.4 kPa (12.5 to 15 psi)	Normally Open
114-5333	Refrigerant Pressure	275 to 1750 kPa ¹ (40 to 255 psi)	-- --	Normally ² Open
119-9631	Thermostat	-0.6 ± 1.4°C (31 ± 2.5°F)	4.2 ± 1.4°C (39.5 ± 2.5°F)	Normally Closed
128-5091	All Wheel Steer Pressure	551 kPa Max (80 psi)	344 ± 20 kPa (50 ± 3 psi)	SPDT
131-9203	Loader Cylinder Pressure	3500 kPa Max (507.6 psi)	3000 ± 150 kPa (435.1 ± 21.8 psi)	SPDT
173-7527	Cold Start Temperature	47 to 53°C (117 to 127°F)	37 to 43°C (99 to 109°F)	Normally Open
194-2553	Pilot Hydraulic Pressure	2200 kPa Max (319.1 psi)	1800 ± 175 kPa (261.1 ± 25.4 psi)	Normally Closed

¹ With increasing pressure the closed condition can be maintained up to 2800 kPa (405 psi), with decreasing pressure the closed condition can be maintained down to 170 kPa (25 psi).

² Contact position at the contacts of the harness connector.

Sender and Solenoid Specifications		
Part No.	Component Description	Resistance (Ohms) ¹
3E-1908	Solenoid: A/C Clutch	17.6 ± 0.6
4W-9972	Sender: Converter Temp	54°C (130°F) - 560 to 716 110°C (230°F) - 72 to 82
121-4036	Solenoid: Front Drive	10.5
171-8775	Solenoid: Pilot Hyd. Shutoff	10.5
175-3070	Sender: Coolant Temp	54°C (130°F) - 560 to 716 110°C (230°F) - 72 to 82
187-8936	Sender: Fuel Level Full: Empty:	240 - 260 27.5 - 39.5

¹ At room temperature unless otherwise noted.

SPECIFICATIONS AND RELATED MANUALS

Volume 2 of 2 - CAB



Related Electrical Service Manuals	
Title	Form Number
Alternator: 105-2812	SENR5841
Optional (90A): 105-2813	SENR5841
Electric Starting Motor: 143-0539	SENR3828
Autoshift Control:	RENR2869
Aux Hydraulic Control:	RENR3588
Machine Security:	RENR2462

Off Machine Switch Specification				
Part No.	Function	Actuate	Deactuate	Contact Position
6T-2665	Engine Coolant Temperature	107.2 ± 2.8°C (225 ± 5°F)	93°C MIN (196°F MIN)	Normally Open
7W-1238	Engine Oil Pressure	62.1 to 95.1 kPa (9 to 13.8 psi)	62.1 to 95.1 kPa (9 to 13.8 psi)	Normally Closed
7X-8549	Hyd. Filter Pressure	110.3 to 138 kPa (16 to 20 psi)	86.2 to 103.4 kPa (12.5 to 15 psi)	Normally Open
114-5333	Refrigerant Pressure	275 to 1750 kPa ¹ (40 to 255 psi)	-- --	Normally ² Open
119-9631	Thermostat	-0.6 ± 1.4°C (31 ± 2.5°F)	4.2 ± 1.4°C (39.5 ± 2.5°F)	Normally Closed
128-5091	All Wheel Steer Pressure	551 kPa Max (80 psi)	344 ± 20 kPa (50 ± 3 psi)	SPDT
131-9203	Loader Cylinder Pressure	3500 kPa Max (507.6 psi)	3000 ± 150 kPa (435.1 ± 21.8 psi)	SPDT
173-7527	Cold Start Temperature	47 to 53°C (117 to 127°F)	37 to 43°C (99 to 109°F)	Normally Open
194-2553	Pilot Hydraulic Pressure	2200 kPa Max (319.1 psi)	1800 ± 175 kPa (261.1 ± 25.4 psi)	Normally Closed

¹ With increasing pressure the closed condition can be maintained up to 2800 kPa (405 psi), with decreasing pressure the closed condition can be maintained down to 170 kPa (25 psi).

² Contact position at the contacts of the harness connector.

Sender and Solenoid Specifications		
Part No.	Component Description	Resistance (Ohms) ¹
3E-1908	Solenoid: A/C Clutch	17.6 ± 0.6
4W-9972	Sender: Converter Temp	54°C (130°F) - 560 to 716 110°C (230°F) - 72 to 82
121-4036	Solenoid: Front Drive	10.5
171-8775	Solenoid: Pilot Hyd. Shutoff	10.5
175-3070	Sender: Coolant Temp	54°C (130°F) - 560 to 716 110°C (230°F) - 72 to 82
187-8936	Sender: Fuel Level	Full: 240 - 260 Empty: 27.5 - 39.5






¹ At room temperature unless otherwise noted.

HARNESS and WIRE

Electrical Schematic Symbols




Symbols




Symbols and Definitions




Fuse: A component in an electrical circuit that will open the circuit if too much current flows through it.




Switch (Normally Open): A switch that will close at a specified point (temp, press, etc.). The circle indicates that the component has screw terminals and a wire can be disconnected from it.



Switch (Normally Closed): A switch that will open at a specified point (temp, press, etc.). No circle indicates that the wire cannot be disconnected from the component.




Ground (Wired): This indicates that the component is connected to a grounded wire. The grounded wire is fastened to the machine.




Ground (Case): This indicates that the component does not have a wire connected to ground. It is grounded by being fastened to the machine.




Reed Switch: A switch whose contacts are controlled by a magnet. A magnet closes the contacts of a normally open reed switch; it opens the contacts of a normally closed reed switch.




Sender: A component that is used with a temperature or pressure gauge. The sender measures the temperature or pressure. Its resistance changes to give an indication to the gauge of the temperature or pressure.



Relay (Magnetic Switch): A relay is an electrical component that is activated by electricity. It has a coil that makes an electromagnet when current flows through it. The electromagnet can open or close the switch part of the relay.





Solenoid: A solenoid is an electrical component that is activated by electricity. It has a coil that makes an electromagnet when current flows through it. The electromagnet can open or close a valve or move a piece of metal that can do work.




Magnetic Latch Solenoid: A magnetic latch solenoid is an electrical component that is activated by electricity and held latched by a permanent magnet. It has two coils (latch and unlatch) that make electromagnet when current flows through them. It also has an internal switch that places the latch coil circuit open at the time the coil latches.

Harness and Wire Symbols


Wire, Cable, or Harness Assembly Identification: Includes Harness Identification Letters and Harness Connector Serialization Codes (see sample).




Deutsch connector: Typical representation of a Deutsch connector. The plug contains all sockets and the receptacle contains all pins.




Sure-Seal connector: Typical representation of a Sure-Seal connector. The plug and receptacle contain both pins and sockets.





THIS SCHEMATIC IS FOR THE 4160, 4300, 4240, 4300, 4320, 4380, AND 4420
 BACKHOE LOADER ELECTRICAL SYSTEM
 VOLUME 1 of 2: ENGINE AND CHASSIS
 MEDIA NUMBER: PE190357-04
 SCHEMATIC PART NUMBER: 176-0006, CHANGE 01, VERSION -
 Copyright © 2008 Caterpillar Inc. All rights reserved. This document is the property of Caterpillar Inc. and is not to be distributed, copied, or reproduced in any form without the express written permission of Caterpillar Inc.





WIRE GROUP COLOR DESCRIPTION	
Blue	Ground
Red	Battery (+)
Black	Battery (-)
Green	Ignition
Yellow	Lighting
Purple	Wiper/Washer
Orange	Other

OTHER COLOR DESCRIPTION	
White	Neutral
Grey	Chassis
Light Blue	Signal
Light Green	Control
Light Red	Power
Light Yellow	Lighting
Light Purple	Wiper/Washer
Light Orange	Other

THIS SCHEMATIC IS FOR THE 418D, 428D, 434D, 428D, 438D, 432D, 438D, AND 442D BACKHOE LOADER ELECTRICAL SYSTEM
 VOLUME 2 of 2, CAB
 MEDIA NUMBER: REW5567-04
 SCHEMATIC PART NUMBER: 178-0281, CHANGE 01, VERSION 1
 Copyright © 2004 Caterpillar Inc. All rights reserved. This document is the property of Caterpillar Inc. and is not to be distributed outside the United States without the written permission of Caterpillar Inc.
 Caterpillar Inc., Peoria, IL 61656-6401
 Caterpillar Inc., London, England

MACHINE HARNESS CONNECTOR AND COMPONENT LOCATIONS - ENGINE AND CHASSIS



MACHINE HARNESS CONNECTOR AND COMPONENT LOCATIONS - CAB

