2003/02/01


-000890C4

## **SMCS** - 1059

## Remove Exhaust Manifold (Water Cooled)

Start By:

a. remove oil filter base.




**1.** Remove the tube from breather cap (1).

2. Remove elbow (6) and adapter (4). Remove elbow (2) and adapter.

3. Fasten a hoist to exhaust manifold (3). Remove nut, and spacers (5). Remove manifold (3). The weight of the exhaust manifold is 27 kg. (60 lb.).


## Install Exhaust Manifold (Water Cooled)



## A33747P1

**1.** Put gaskets (1) and manifold (3) into position on studs (2). Put **5P3931 Anti-Seize Compound** on the studs and install spacers, washers and nuts. Tighten the nuts in the sequence shown to  $45 \pm 7 \text{ N} \cdot \text{m}$  ( $35 \pm 15 \text{ lb ft}$ ). Tighten the nuts again in the same sequence to  $45 \pm 7 \text{ N} \cdot \text{m}$  ( $35 \pm 15 \text{ lb ft}$ ). Tighten the nuts again in the same sequence to  $45 \pm 7 \text{ N} \cdot \text{m}$  ( $35 \pm 15 \text{ lb ft}$ ).


NOTE: If the studs for manifold (3) were removed, install new studs and tighten to 25 ± 4 N·m (20 ± 3 lb ft).



SENR74100039

2. Install the gasket in location (4). Install bolts (6).

3. Put clean engine oil on the O-rings for adapter (5). Install adapter (5) and elbow (7).



4. Put clean engine oil on the O-rings for adapter (8). Install adapter (8) and elbow (9).

https://sis2.cat.com/#/print-preview/service/%257B%2522title%2522%253A%2522Exhaust%2520Manifold%2520(Water%2520Cooled)%2520(SENR7410-04)%2522%252C%2522formattedPublicationDate%2522%2... 1/2

**5.** Install the tube on the valve cover breather cap.

End By:

a. install oil filter base

PSP-000890C4 2022/11/30 16:11:32-03:00 SENR74100039 © 2022 Caterpillar Inc. Caterpillar: Confidential Green

PSp

https://sis2.cat.com/#/print-preview/service/%257B%2522title%2522%253A%2522Exhaust%2520Manifold%2520(Water%2520Cooled)%2520(SENR7410-04)%2522%252C%2522formattedPublicationDate%2522%2... 2/2