

FOREWORD

When ordering a part, please specify the model number, the engine serial number and the reading of the service meter.

For complete understanding, the parts list is written as follows:

Fig. number	Figure numbers are not continuous.
Description	"•" is put in front of the name of an assembly component and the item is entered next to the assembly. If a part marked with "•" is an assembly, its component is marked with "••".
Quantity	The number of pieces per set used for assembly is specified. For assembly or part group components, the number of pieces per assembly is specified.
Serial number	The engine or machine serial number in which the part is used.
Machine code	The codes in parentheses shown in the table of contents or figure represent models as follows.

Codes	<p>The codes and part numbers specified in the "Part No." and "Part Name" columns represent the following:</p> <ul style="list-style-type: none"> <input type="checkbox"/> The part specified in the line above is applicable instead of this part. <input checked="" type="checkbox"/> This part is applicable instead of the part specified in the line immediately above. ◆ This part and the part specified in the line immediately above are interchangeable. ⊗ This part is not supplied anymore. The part specified in the above line is supplied instead. ■ The part specified in the "Part Name" column is applicable instead of this part if it is used as a set. ▼ This part is not supplied anymore. The part specified in the "Part Name" column is supplied instead as a set. △ Part supplied as semi-finished. It must be reworked before use.
-------	--

Codes

☆	Supplied as a set rather than singly.
★	Supplied as a set rather than singly. It is supplied singly by specific dealers only.
⊙	Part group. This part is not considered a supply part.
====	The parts surrounded by this line are components of the part group specified above.
G-1, G-2	Part group numbers.
KIT	Kit components. For kit components, please refer to the service kit table.
PAINT (1)	Parts shipped painted with undercoat.
PAINT (2)	Parts shipped with different colors.
(A)	Cold weather (A) spec. (-30°C)
(B)	Cold weather (B) spec. (-50°C)

This parts list specifies not only standard accessories but also optional parts and attachments.

To order a part, please contact your nearest Komatsu dealer.