

	FIG NO.	PAGE		FIG NO.	PAGE
FLOOR FRAME (2/2).....	K1110-02A0	K- 16	TRAVEL AND LOWER PIPING		
TRAVEL CONTROL LEVER.....	K1111-01A0	K- 18	LOWER PIPING.....	P1110-01A0	P- 2
TRAVEL CONTROL LEVER (2WAY).....	K1111-01A1	K- 20	FINAL DRIVE.....	P1210-01A0	P- 4
WORK EQUIPMENT CONTROL LEVER.....	K1111-02A0	K- 22	SPROCKET.....	P1211-01A0	P- 6
BOOM SWING PEDAL AND LINKAGE.....	K1111-03A0	K- 24	UNDER CARRIAGE		
BLADE CONTROL LEVER AND LINKAGE.....	K1111-04A0	K- 26	FRONT IDLER (FOR RUBBER SHOE).....	R0110-01A0	R- 2
SECOND CONTROL PEDAL AND LINKAGE.....	K1111-05A0	K- 28	FRONT IDLER (FOR STEEL SHOE).....	R0110-01A1	R- 4
WORK EQUIPMENT LOCK LEVER.....	K1111-06A0	K- 30	IDLER CUSHION (FOR RUBBER SHOE).....	R0120-01A0	R- 6
P.P.C. VALVE.....	K1111-07A0	K- 32	IDLER CUSHION (FOR STEEL SHOE).....	R0120-01A1	R- 8
P.P.C. VALVE LINE (1/2).....	K1111-08A0	K- 34	TRACK ROLLER (FOR RUBBER SHOE).....	R0200-01A0	R- 10
P.P.C. VALVE LINE (2/2).....	K1111-09A0	K- 36	CARRIER PLATE.....	R0300-01A0	R- 12
MAIN VALVE RELATED PARTS.....	K1111-10A0	K- 38	TRACK SHOE (RUBBER SHOE).....	R0500-01A0	R- 14
MAIN VALVE RELATED PARTS (2WAY).....	K1111-10A1	K- 40	TRACK SHOE (STEEL SHOE).....	R0500-01A1	R- 16
FLOOR COVER.....	K1120-01A0	K- 42	TRACK FRAME.....	R1100-01A0	R- 18
ATTACHMENT CONTROL PEDAL AND LINKAGE.....	K1530-01A0	K- 44	TRACK FRAME COVER.....	R1130-01A0	R- 20
ATTACHMENT CONTROL PEDAL AND LINKAGE (2-WAY).....	K1530-01A1	K- 46	TRACK GUARD.....	R1200-01A0	R- 22
HANDRAIL.....	K1810-01A0	K- 48			
			TO WORK EQUIPMENT		
M0 GUARD			BOOM.....	T1110-01A0	T- 2
ENGINE HOOD.....	M1110-01A0	M- 2	BOOM (QUICK BREAKER ARM SPEC.).....	T1110-01A1	T- 4
ENGINE HOOD (QUICK BREKER SPEC.).....	M1110-01A1	M- 4	BOOM CYLINDER COVER.....	T1120-01A0	T- 6
LEFT SIDE COVER.....	M1130-01A0	M- 6	ARM.....	T1210-01A0	T- 8
RIGHT SIDE COVER.....	M1140-01A0	M- 8	ARM (QUICK BREAKER ARM SPEC.).....	T1210-01A1	T- 10
COUNTER WEIGHT.....	M1510-01A0	M- 10	LONG ARM (1/2) (ARM).....	T1210-01A2	T- 12
COUNTER WEIGHT (QUICK BREAKER ARM SPEC.).....	M1510-01A1	M- 12	LONG ARM (2/2) (BUCKET CYLINDER TUBE).....	T1210-02A2	T- 14
SIDE PROTECTOR.....	M1620-01A0	M- 14	HYDRAULIC BREAKER (INNER PARTS).....	T1210-51A0	T- 16
			BUCKET LINK.....	T1230-01A0	T- 18
N0 SWING CIRCLE AND RELATED PARTS			BUCKET LINK (FOR ATTACHMENT).....	T1230-01A1	T- 20
SWING CIRCLE.....	N1110-01A0	N- 2	BUCKET PIN.....	T1235-01A0	T- 22
SWING MOTOR.....	N1200-01A0	N- 4	BUCKET PIN (QUICK BREAKER ARM SPEC.).....	T1235-01A1	T- 24
SWIVEL JOINT AND RELATED PARTS.....	N1310-01A0	N- 6	BREA(ER PIPING (BOOM).....	T1240-01A0	T- 26