


Quality Changes the World



SANY

Tandem Roller

STR130C-8C



Parts Book

Parts Book

STR130C-8C

Roller

Equipment No. YZ2113CC2309

Overview

This book provides illustrations and parts listings required to properly identify and order replaceable parts on your Sany machine.

If this book becomes damaged, lost or illegible, request a replacement copy from your Sany distributor.

In case you sell this machine, be sure to give this parts book to the new owner.

Improvements in the design may lead to changes in detail which may not be indicated in this book. Always consult your Sany distributor for the latest available information on your equipment or if you have questions regarding information in this book.

Storing this parts book

This publication applies only to this specific machine and should not be used with any other machines.

Always keep this book available for reference.

Contact Details

SANY Industry Town, Economic and Technological Development Zone, Changsha, Hunan China 410100

Tel: 0731-84031888

Fax: 0731-84031999

Service Hotline: 4008 87 8318

Complaint Hotline: 4008 87 9318


Email: Sanyservice@sany.com.cn

Website: www.sanyglobal.com

Sany Group Service Information System

<http://sis.sanygroup.com>

Page header with parts code, and parts description



Line-art illustration with callout numbers

Page footer with page number, chapter title, machine model and product name

Page header with parts code, and parts description

INDEX: that matches
callout numbers on previous
illustration page

SEE PAGE: for page information
of the part or assembly

INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	B220401000459	Valve Assembly, Solenoid	1	
2	A820103010415	Change Valve Block, Cooling Oil Motor	1	
3	B220400000083	Relief Valve	1	

PART NO.: to be used along
with DESCRIPTION to identify
the part or assembly

DESCRIPTION: to be used
along with PART NO. to
identify the part or assembly

QTY: it indicates the
number of each part
used in this assembly

Page footer with page number, chapter title, machine model and product name




Table of Contents

Group 1 STR130C-8S Sany Tandem Roller	1-1
YLJ100000041 STR130C-8S Sany Tandem Roller	1-2
Group 2 vibration drum assem	2-1
YLJ005563219 vibration drum assem	2-2
14385045 Travel supporting in vibration end.....	2-6
12844503 Modulator, amplitude	2-8
12844646 Modulator, amplitude	2-10
61005880 Reducer	2-12
12744699 Bearing seat component	2-16
Group 3 Front carriage	3-1
YLJ005417704 Front carriage	3-2
YLJ004954617 Diesel box assembly component	3-6
YLJ004677594 Rearview mirror bracket.....	3-8
13685018 Hose clip unit	3-10
YLJ004895853 The Maintenance Door.....	3-12
13445924 Battery component.....	3-14
13892932 Hose clip unit	3-16
Group 4 controlling system assembly	4-1
YLJ006656466 controlling system assembly	4-2
13352079 Display Mounting Rack	4-4
14155306 Steering Control System	4-6
14352067 Console bracket assembly	4-8
13175451 Electrical control panel component	4-12
YLJ004680731 side box	4-14
Group 5 air	5-1
YLJ005602041 air.....	5-2
Group 6 Center hinge frame	6-1
YLJ004859632 Center hinge frame	6-2
12364147 Steering Cylinder.....	6-6
14160181 Cylinder Assembly, Steering	6-8
12955991 Lock pin	6-10
Group 7 Dynamical system.....	7-1
YLJ005110467 Dynamical system.....	7-2
13920410 engine installation	7-4

14506058 pump connection	7-8
YLJ005110427 Cooling assembly	7-10
YLJ005110623 Exhaust System.....	7-14
YLJ005105952 Oil road and nearby installation	7-18

Group 8 Hydraulic system assembly8-1

14511191 Hydraulic system assembly.....	8-2
14511380 Traveling motor	8-6
13686364 Steering component	8-8
13448213 Crablike valve mounting	8-10
13686363 Priority valve assembly	8-12
14511533 Vibratory motor	8-14
13917318 Return Block assembly	8-16
14511708 Steering Pump	8-18
13686274 Fan valve mounting	8-20
14511747 Fan motor component.....	8-22
13916302 BLOCK OF collecting assembly	8-24
13918399 filter assembly.....	8-26
14512102 Triple Pump	8-28
60277744 External-meshing Gear Pump.....	8-30
A810201060027 Vibration switch valve installation.....	8-32
14513076 Radiator of vibratory system.....	8-34
14513087 Pipeline layout of brake and steering systems	8-36
14513010 Piping diagram of vibratory system	8-38
14512830 Piping diagram of traveling system	8-40
13989791 Braking valve mounting.....	8-42
YLJ005720436 Traveling motor	8-44

Group 9 covering parts9-1

YLJ005110634 covering parts	9-2
-----------------------------------	-----

Group 10 rear frame10-1

YLJ005103971 rear frame.....	10-2
14510385 oil tank.....	10-6

Group 11 Bridging BeamComponent.....11-1

YLJ005651966 Bridging BeamComponent	11-2
13687649 Under scraper assem	11-4
YLJ005652578 Upper scraper assem.....	11-6

Group 12 water12-1

YLJ005639941 water	12-2
--------------------------	------


Group 13 Electrical system of roller13-1

14511035 Electrical system of roller	13-2
--	------

13455256 Power assembly	13-4
14512008 Electrical Control Box Assembly	13-6
14514219 Electric system assembly of Control box	13-8
14173552 Electrical system , rear carriage.....	13-10
14388807 Electrical system , front carriage.....	13-14
YLJ005348321 Electrical harness assembly basic diagram	13-22


Group 14 Driver's Cab Assy..... 14-1

YLJ005573749 Driver's Cab Assy	14-2
130901000268B Cab(JRTR07A)	14-4
130901000269B JRTR07 double steel roller cab console body.....	14-6
JSS005361405 Cab body	14-8
JSS005364030 JRTR07A inner&outer-decoration assembly.....	14-10




Group 1

STR130C-8S Sany Tandem Roller




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	YLJ005563219	vibration drum assem		2	2-2
2	YLJ005417704	Front carriage		1	3-2
3	YLJ006656466	controlling system assembly		1	4-2
4	YLJ005602041	air		1	5-2
5	YLJ004859632	Center hinge frame		1	6-2
6	YLJ005110467	Dynamical system		1	7-2
7	14511191	Hydraulic system assembly		1	8-2
8	YLJ005110634	covering parts		1	9-2
9	YLJ005103971	rear frame		1	10-2
11	YLJ005651966	Bridging BeamComponent		2	11-2
12	YLJ005639941	water		1	12-2
13	14511035	Electrical system of roller		1	13-2
14	YLJ005573749	Driver's Cab Assy		1	14-2




Group 2


vibration drum assem




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	14385045	Travel supporting in vibration end		1	2-6
2	14160284	Roller Wheel		1	
3	14321843	vibration dummy club welding		1	
4	14321909	Fork leg		1	
5	14395896	Clamp		1	
6	14009225	Fixing plate		2	
7	14545154	Clamp		1	
8	60034012	Damp block		12	
9	13818666	Support plate welding		1	
10	A210204000131	Screw		4	
11	11405879	Retaining disc		1	
12	A210414000028	Retainer Ring		1	
13	61016820	Flexible Coupling		1	
14	A210609000284	O-ring		1	
15	A210509000037	Key		1	
16	A210416000006	Retainer Ring		4	
18	12844503	Modulator, amplitude		1	2-8
34	A210111000026	Bolt		8	
35	14380664	Fixing plate		4	
36	14395968	Clamp		1	
37	14321920	Fork leg		1	
38	14321864	driving dummy club welding		1	
43	A210110000331	Bolt		20	
44	A210204000342	Screw		4	
45	A210111000062	Bolt		8	
46	A210405000011	Washer		12	
47	A210204000346	Screw		12	
48	A210315000005	Nut		24	
49	A210491000132	Washer		52	
50	A210491000118	Washer		58	
51	A210111000054	Bolt		20	
52	13867303	Shim		20	
54	A210114000007	Bolt		29	
60	60109047	Breather		1	
61	A210434000010	Washer		1	
62	13403379	Spacer		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
17	24002383	O-ring		2	
19	13311381	Scraper welding		6	
20	A210114000001	Bolt		12	
21	A210491000121	Washer		12	
22	60244891	Flexible Coupling		1	
23	A210204000356	Screw		8	
24	13309251	Intermediate bearing seat		2	
25	60231763	Rolling Bearing		4	
26	12844646	Modulator, amplitude		1	2-10
27	A210414000065	Retainer Ring		4	
28	61005880	Reducer		1	2-12
29	12744699	Bearing seat component		1	2-16
30	12984281	Cover plate		2	
31	13817935	Support plate welding		1	
32	A210401000007	Washer		10	
33	14545153	Clamp		1	
39	A210111000090	Bolt		8	
40	A210405000007	Washer		8	
41	A210401000017	Washer		8	
42	A210114000012	Bolt		24	
53	14000982	Supporting Plate		4	
55	A210401000004	Washer		17	
56	A210111000053	Bolt		2	
57	14000983	Pedal		1	
58	A210333000007	Screw Plug		2	
59	A210434000020	Washer		2	
63	60082193	Screw		10	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	13977278	Vibratory end bearing holder		1	
2	A210628000009	Rolling bearing		1	
3	13309621	Connection sleeve		1	
4	A820201000779	Pressure cover		1	
5	13309783	End plate		1	
6	A210453000007	Washer		2	
7	13208018	Oil Cup Base		2	
8	A210804000002	Fitting, Grease		1	
9	A210491000118	Washer		12	
10	A210114000007	Bolt		12	
11	151402030066A	Oil seal		1	
12	A210609000013	O-ring		1	
13	A210609000035	O-ring		1	
14	A210204000221	Screw		12	
15	60035082	Felt Seal Ring		1	
16	A210434000011	Washer		3	
17	60033283	Magnetic screw plug		3	
18	A210434000007	Washer		3	
19	A210333000001	Plug, Screw		3	
20	A230101000302	FB Oil Seal		1	
21	12278981	Cover		1	
22	A210405000007	Washer		6	
23	A210111000088	Bolt		6	
24	A210453000004	Washer		1	
25	A210332000004	Screw Plug		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	12844446	Movable block chamber welding		1	
2	13201312	Vibratory shaft		1	
3	12844477	Fixed eccentric block		2	
4	A880804040007	Retainer Ring		2	
5	A210509000088	Key		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	12844446	Movable block chamber welding		1	
2	13201192	Vibratory shaft		1	
3	12844477	Fixed eccentric block		2	
4	A880804040007	Retainer Ring		2	
5	A210509000088	Key		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	130103000286B007	Screw		1	
2	130103000367A012	Rear Cover Pad		1	
3	130103000367A013	Cylindrical Roller		1	
4	130103000367A014	O-ring		1	
5	130103000367A015	Axle		1	
6	130103000367A016	Cushion		1	
7	130103000286B001	Circlips for Shaft		1	
8	130103000367A017	Ring, Snap		1	
9	130103000367A018	Ring, Retainer		1	
10	130103000367A009	Cylinder Roller Bearing		1	
11	130103000367A001	Planetary Gear		1	
12	130103000367A019	Type-A elastic Ring for Axle		1	
13	130103000367A020	Elastic Ring For Large Axle		1	
14	130103000367A006	Sun Gear		1	
15	130103000367A021	ring gear		1	
16	130103000367A022	o-ring		1	
17	130103000367A011	Locknut		1	
18	130103000367A008	Taper Roller Bearing		1	
19	130103000367A010	Bearing Holder		1	
20	130103000367A037	Screw		1	
21	130103000367A005	Floating Seal		1	
22	130103000367A023	Circlips for Shaft		1	
23	130103000367A002	Cylinder Roller Bearing		1	
24	130103000367A007	Planetary Gear		1	
25	130103000367A024	Ring, Snap		1	
26	130103000367A025	carrier		1	
27	130103000367A004	Holder		1	
28	130103000367A026	Screw		1	
29	130103000367A027	Screw		1	
30	130103000174B006	Sealing ring		1	
31	130103000367A028	Sealing Ring		1	
32	130103000175B001	Movable friction plate		1	
33	130103000367A029	Double-side Static Friction Plate		1	
34	130103000367A030	Ring, Snap		1	
35	130103000367A031	Spline Shaft		1	
36	130103000367A032	Piston		1	
37	130103000174B008	sealing ring		1	
38	130103000367A033	Sealing Ring		1	
39	130103000367A034	Spring Sleeve		1	
40	130103000367A003	Retainer		1	



INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
41	130103000367A035	Ring, Snap		1	
42	130103000367A036	Spring		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	12732056	Bearing seat welding		1	
2	10891721	Threaded Cover		2	
3	12281495	Cover		1	
4	A210405000007	Washer		6	
5	A210111000088	Bolt		6	
6	13021799	End cover of bearing seat		1	
7	A210609000174	O-ring		1	
8	A210405000011	Washer		6	
9	A210111000011	Bolt		6	




Group 3


Front carriage




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	YLJ004954617	Diesel box assembly component		1	3-6
2	A820606030474	Protecting Ring		2	
3	YLJ007366684	Rubber tie-plate		1	
4	YLJ005417572	Front carriage weld assem.		1	
5	A210204000019	Screw		4	
6	A210404000008	Washer		2	
7	YLJ004687645	Mounting plate of rearview mirror braket		2	
8	YLJ004677594	Rearview mirror bracket		2	3-8
9	13449188	Pressure plate		2	
10	13449189	Rubber Cushion		2	
11	A210307000001	Nut		7	
12	A210405000001	Washer		14	
13	A210401000002	Washer		16	
14	A210111000037	Bolt		12	
17	YLJ004857847	The left stairs		1	
22	14130377	Rubber retainer (3)		4	
23	YLJ004857866	The right stairs		1	
24	13445924	Battery component		1	3-14
25	YLJ005427066	PLATE		1	
26	YLJ005426878	plate		1	
27	YLJ005338651	Clip		1	
28	13892932	Hose clip unit		1	3-16
30	A210111000011	Bolt		4	
33	A210405000007	Washer		8	
34	14523445	Rubber retainer		2	
35	A210111000364	Bolt		2	
38	A210111000307	Bolt		2	
39	A210307000017	Nut		4	
40	YLJ005336985	Clip		1	
41	A210405000011	Washer		12	
42	A210401000001	Washer		6	
43	A210110000218	Bolt		2	
44	YLJ005336947	Clip		1	
45	A820102010065	Adjusting Spacer		4	
46	YLJ005340419	bolt		2	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
15	A820101339360	Guard		1	
16	13684348	Rubber retainer		2	
18	13685018	Hose clip unit		2	3-10
19	YLJ004895853	The Maintenance Door		1	3-12
20	A210405000006	Washer		2	
21	A210307000016	Nut		2	
29	A820301018783	Shaft, pin		1	
31	13686715	Cover plate		1	
32	A210111000089	Bolt		4	
36	YLJ005044599	ring		2	
37	14309087	Ring		1	







INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	YLJ004677591	Rearview mirror bracket welding		1	
2	A210405000007	Washer		2	
3	A210111000092	Bolt		2	
4	A210401000017	Washer		2	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	A210111000018	Bolt		4	
2	A210307000017	Nut		8	
3	A210405000011	Washer		12	
4	A210401000001	Washer		12	
5	13089922	Bushing		12	
6	13684351	Axle supporting		2	
7	13684352	Axle supporting		2	
8	13684350	Supporting plate		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	A210211000008	Screw		4	
2	A210111000080	Bolt		4	
3	60015644	Hinge		1	
4	A222200000058	Cover Latch Accessories		1	
5	YLJ004858317	The Mounting Door		1	
6	YLJ004895828	Door		1	
7	A210405000006	Washer		4	



INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	13445919	Battery cover assembly		1	
2	14159223	Screw		2	
3	A210405000011	Washer		4	
4	A210401000001	Washer		4	
5	A210307000017	Nut		4	
6	13445921	Rubber liner plates		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	13892899	Supporting plate		2	
2	13836405	Axle supporting		4	
3	13836428	Bushing		8	
4	13892906	Bushing		8	
5	A210405000011	Washer		14	
6	A210307000017	Nut		10	
7	12844740	Support shaft		1	
8	A210204000161	Screw		4	





Group 4

controlling system assembly




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	13352079	Display Mounting Rack		1	4-4
2	14155306	Steering Control System		1	4-6
3	14352067	Console bracket assembly		1	4-8
4	14463848	U plate		1	
5	YLJ004680731	side box		1	4-14
6	14463742	L-shape plate		2	
7	14464030	U plate		1	
8	A210110000006	Bolt		1	
9	A2102100000030	Screw		4	
10	A210405000001	Washer		1	
11	A210405000004	Washer		4	
12	A229900001929	Mechanical Suspension Driver seat		1	
13	A249900000600	Cable Connector		1	
14	YLJ006552828	plate		1	







INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	61010743	Instrument panel assembly		1	
2	A210111000018	Bolt		3	
3	A210405000011	Washer		3	
4	A229900002460	Steering Gear		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	13731104	Bracket uppercover board		1	
2	13688857	Upper cover welding of control cabinet		1	
3	A210111000089	Bolt		29	
4	A210404000005	Washer		11	
5	A210401000017	Washer		29	
6	A210405000007	Washer		14	
7	14517625	Side box support plate welding		1	
8	14485553	Console bracket weldment		1	
9	14242649	Steering board weldedment		1	
10	A219900000089	Handle Ball		1	
11	A210401000016	Washer		16	
12	A210405000006	Washer		14	
13	A210891000007	Hinge		2	
14	14519482	Front cover plate weldment		1	
17	A229900003184	Slewing bearings		1	
20	A210111000078	Bolt		6	
21	A210111000283	Bolt		12	
23	A210111000081	Bolt		5	
26	10211702	Coupling bar		1	
28	14155632	Rubber pad		1	
29	A210111000080	Bolt		3	
30	A210307000012	Nut		6	
31	A210111000090	Bolt		4	
33	14354664	Lock plate		4	
34	13394536	Foot pedal		2	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
15	A222000000080	Damper		4	
16	A210307000016	Nut		12	
18	A210501000043	Pin		2	
19	10212192	Support welding		1	
22	13610941	Rock Arm		1	
24	A210508000067	Pin		2	
25	A210616000012	Spring		1	
27	13175451	Electrical control penal component		1	4-12
32	14354634	Sealing ring		1	



INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	13175440	Electrical control penal		1	
2	13175443	Fixing plate		1	
3	21005327	Bolt		2	
4	A210401000016	Washer		2	
5	A210405000006	Washer		2	





INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	14353444	Harness installation plate		2	
2	14353567	Side box base plate		1	
3	A210204000130	Screw		11	
4	A210204000131	Screw		4	
5	A210405000006	Washer		15	
6	YLJ004680167	Deputy box manipulation		1	
7	YLJ004680723	plate		1	





Group 5

air







INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
2	A210111000018	Bolt		4	
3	A210401000001	Washer		13	
4	A210404000003	Washer		4	
8	A210405000006	Washer		4	
10	11026326	Compressor bracket		1	
11	A210111000078	Bolt		4	
12	A210307000016	Nut		4	
29	60253934	Rubber Hose		1	
30	A220400000070	Ball Valve		1	
31	A820301012683	Screw Rod, U-type		2	
32	A210401000016	Washer		4	
33	A820205001582	Fitting		2	
34	A210855000066	Hole Type Hose Clamp		6	
35	60200724	Clamp		4	
36	11534382	Rubber pad		1	
37	10993801	Connector		1	
38	A229900001355	Blbow		1	
39	10993805	Connector		3	
40	120701080001A	Type A Triangular Belt		1	



INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
13	A820101319357	Crescent Shaped Plate		2	
14	A210111000026	Bolt		3	
15	A820101320930	Bent Plate		1	
16	A820101348563	Adjusting Block		1	
17	A210307000040	Nut		2	
18	A210401000004	Washer		2	
19	A820301014728	Bolt, Hinged		1	
20	A210204000197	Screw		6	
21	A210307000017	Nut		6	
22	A210111000119	Bolt		1	
23	A210405000001	Washer		1	
24	A210401000002	Washer		1	
25	A210110000304	bolt		1	
26	A210401000006	Washer		1	
27	A210307000029	Nut		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
5	21005351	Bolt		4	
6	A210401000017	Washer		8	
7	A210405000007	Washer		8	
9	A210111000090	Bolt		4	
28	14071075	cylinder		4	
41	14495199	Right plate		1	
42	14495244	Left plate		1	




Group 6


Center hinge frame




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	YLJ004856829	Hinged body		1	
2	YLJ004863424	Articulation Seat		1	
3	YLJ004846605	Rotary Support		1	
4	A229900002724	Slewing bearing		1	
5	A210111000089	Bolt		2	
6	A210401000017	Washer		2	
7	A210405000007	Washer		2	
8	YLJ004908102	Plate		1	
9	A210111000282	Bolt		12	
10	A210491000118	Washer		42	
11	YLJ004896675	Bearing cover		2	
12	A210491000003	Belleville Spring		2	
13	60082894	Joint Bearing		4	
14	YLJ004858996	Dust Ring		4	
15	A210111000291	Bolt		18	
16	60191773	Ferrule-type Straight Adapter		4	
17	60045017	Detachable Fitting		4	
18	60191772	Right-angle Joint, Clamp Sleeve-type		1	
19	YLJ004899944	Paper Washer		8	
20	YLJ004897639	Bearing cover		2	
21	A210111000281	Bolt		12	
22	13181668	Retainer Ring		2	
23	12359619	Sealing Ring		4	
24	A210416000034	Retainer Ring		2	
25	A210612000013	Joint Bearing		2	
26	A210110000201	Bolt		36	
27	A210491000132	Washer		36	
28	A210804000002	Fitting, Grease		4	
29	12359672	Retainer Ring		2	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
16	60191773	Ferrule-type Straight Adapter		4	
17	60045017	Detachable Fitting		4	
22	13181668	Retainer Ring		2	
23	12359619	Sealing Ring		4	
24	A210416000034	Retainer Ring		2	
25	A210612000013	Joint Bearing		2	
28	A210804000002	Fitting, Grease		4	
29	12359672	Retainer Ring		2	
30	A210401000002	Washer		6	
31	13297001	Retaining ring II		1	
32	A820101339360	Guard		1	
33	A210111000038	Bolt		6	
34	12364147	Steering Cylinder		1	6-6
35	14160181	Cylinder Assembly, Steering		1	6-8
36	A210405000001	Washer		6	
37	A820301018783	Shaft, pin		1	
38	12955991	Lock pin		1	6-10
39	A290000002660	Protective Cap, Nozzle		4	
40	13297012	Retainer Ring		2	
41	12360169	Lock pin		2	
42	A820101345222	Clamp Plate		2	
43	YLJ004899560	tube		2	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	12364146	Clipping key cap		1	
2	12364145	Rear clipping key		1	
3	12364143	Piston		1	
4	12364148	Cylinder assem		1	
5	12364150	Piston rod assem.		1	
6	10250742	Retainer Ring		2	
7	12364139	Guide sleeve		1	
8	11123065	Snap ring		1	
9	11122499	Stopper ring		1	
10	A210434000011	Washer		2	
11	12355725	Screw Plug		2	
12	A210414000037	Retainer Ring		1	
13	B230101000138	OK Seal Ring		1	
14	A210609000062	O-ring		2	
15	B230101001371	UP Guide Ring		2	
16	B230101001492	UP Guide Ring		2	
17	A210609000009	O-ring		2	
18	13599611	Gsj Seal Ring		1	
19	B230101002124	ZBR Seal Ring		1	
20	A210414000015	Retainer Ring		1	
21	A880808070038	PWD Dust Ring		1	






INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	11109315	Handle		1	
2	12955989	Pin		1	
3	A210405000001	Washer		1	
4	A210111000037	Bolt		1	
5	11109312	Lock pin		1	
6	A820301010152	Clamp Pin		1	




Group 7


Dynamical system




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	13920410	engine installation		1	7-4
2	14506058	pump connection		1	7-8
3	YLJ005110427	Cooling assembly		1	7-10
4	YLJ005110623	Exhaust System		1	7-14
5	YLJ005105952	Oil road and nearby installation		1	7-18




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	14217405	left outrigger welding assembly		1	
4	13589449	rear outrigger		1	
5	14217318	cushion block		6	
6	160102050024A	engine		1	
7	A210111000119	Bolt		2	
8	A210111000204	Bolt		8	
9	A210113000039	Bolt		6	
10	A210204000206	Screw		4	
11	A210204000337	Screw		12	
12	A210405000001	Washer		22	
13	A229900005421	Shock Pad		6	
14	A820202003593	Big Washer		6	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
2	14217505	Right outrigger welding assembly		1	
3	13523768	Front bearer board		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	10891719	Threaded Cover		2	
2	13520944	Connecting Disk		1	
3	A210111000202	Bolt		4	
4	A210204000215	Screw		8	
5	A210204000354	Screw		12	
6	A210401000001	Washer		14	
7	A210401000002	Washer		4	
8	A210405000011	Washer		8	
9	A210491000121	Washer		4	
10	B221701000095	Flanging Coupling		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	14184596	Weldment of watering tube		1	
2	YLJ006231480	Mounting plate of motor		1	
3	11101836	Damping Pad Of Radiator		6	
4	11558668	Hoop		1	
5	11563406	Connecting Rubber Hose		3	
6	13689958	Cushion block		6	
7	13919808	Connecting Rubber Hose		1	
16	A210111000024	Bolt		2	
17	A210111000197	Bolt		4	
18	A210111000199	Bolt		2	
19	A210111000203	Bolt		6	
20	A210111000343	Bolt		2	
21	A210204000164	Screw		1	
22	A210307000012	Nut		2	
23	A210307000016	Nut		4	
24	A210307000017	Nut		10	
25	A210401000001	Washer		12	
26	A210401000002	Washer		8	
27	A210401000017	Washer		2	
28	A210405000001	Washer		8	
29	A210405000006	Washer		4	
30	A210405000007	Washer		3	
31	A210405000011	Washer		12	
32	A210855000052	T-Type Clamp		8	
33	A229900002031	T-type Clamp		6	
34	A229900002965	Clamp		1	
35	A820202003593	Big Washer		6	
36	A820301012683	Screw Rod, U-type		2	
37	YLJ005359029	Out air		1	
38	YLJ005683988	Plate		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
8	13919828	Inter-cooler intake pipe		1	
9	13919833	Discharging tube		1	
10	14057294	water-in tube		1	
11	14057339	water-in tube		1	
12	14414864	Installation adaptor of fan		1	
13	60034933	Fan		1	
14	60134354	Hose Clamp		2	
15	60340908	Radiator		1	
39	13718118	Degassing pipe		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	YLJ004758616	Mounting Assem.		1	
2	YLJ005359967	mounting assem. for air cleaner		1	
3	11558668	Hoop		2	
5	13673659	muffler		1	
6	13688588	Exhaust Pipe Spacer		1	
7	A210111000024	Bolt		4	
8	A210111000026	Bolt		4	
9	A210111000089	Bolt		4	
10	A210111000090	Bolt		6	
11	A210307000012	Nut		10	
13	A210401000001	Washer		8	
14	A210401000017	Washer		10	
16	A210405000007	Washer		10	
17	A210405000011	Washer		8	
18	A229900002263	T-Type Clamp		3	
19	A229900002381	Rain Hat		1	
21	A229900003759	T-Type Clamp		3	
22	A229900003898	T-type Clamp		1	
23	B222100000368	Air Filter		1	
24	YLJ005358886	In air		1	
25	YLJ005358917	In air		1	
27	YLJ005359665	In air		1	
29	13921420	Exhaust hose		1	
30	A230200000026	PTFE glass fiber varnish cloth		1	
31	A239900000239	Fiberglass felt strip		1	



INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
4	13300057	Sensor Connector		1	
12	A210309000016	Nut		1	
15	A210405000001	Washer		1	
20	A229900003542	Mechanical Differential Pressure Indicator		1	
26	YLJ005358995	In air		1	
28	YLJ005359771	bracket for exhaust hose		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	B210780000344	Adapter Fitting		5	
2	B210780000245	Bulkhead Fitting		4	
3	B230103007493	Rubber Hose		1	
4	60312939	Rubber Hose		1	
5	B210780001026	Adapter Fitting		4	
6	B210780000636	Elbow Fitting		2	
7	A210111000029	Bolt		2	
8	A210405000011	Washer		4	
9	A210307000017	Nut		2	
10	14274679	prefiltration support		1	
11	B230103000129	Hose		1	
12	B210780000025	Elbow Fitting		4	
13	13922408	ecise filtration supporting board		1	
14	A210111000091	Bolt		8	
15	A210405000007	Washer		11	
16	A210401000017	Washer		11	
17	13922412	Engine oil cleaner filtration supporting board		1	
18	21017994	Screw Plug		2	
19	B230103000949	Hose		1	
20	13925123	Drainage adaptor		1	
21	B210780000040	Adapter Fitting		1	
22	B230103000043	Rubber hose		1	
23	A210405000010	Washer		2	
24	A210405000014	Washer		1	
25	13765129	Preheating Mounting Rack		1	
26	A210111000023	Bolt		2	
27	A210401000001	Washer		2	
28	A210111000094	Bolt		3	
29	A210307000012	Nut		3	
30	A210111000040	Bolt		2	
31	A210405000001	Washer		2	
32	A210307000001	Nut		2	
33	21021914	Rubber Hose		1	




Group 8


Hydraulic system assembly




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	14511380	Traveling motor		1	8-6
2	13686364	Steering component		1	8-8
3	13448213	Crablike valve mounting		1	8-10
4	13686363	Priority valve assembly		1	8-12
19	YLJ005720436	Traveling motor		1	8-44




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
5	14511533	Vibratory motor		2	8-14
6	13917318	Return Block assembly		1	8-16
7	14511708	Steering Pump		1	8-18
8	13686274	Fan valve mounting		1	8-20
9	14511747	Fan motor component		1	8-22
10	13916302	BLOCK OF collecting assembly		1	8-24
11	13918399	filter assembly		1	8-26
12	14512102	Triple Pump		1	8-28
13	A810201060027	Vibration switch valve installation		1	8-32
14	14513076	Radiator of vibratory system		1	8-34
15	14513087	Pipeline layout of brake and steering systems		1	8-36
16	14513010	Piping diagram of vibratory system		1	8-38
17	14512830	Piping diagram of traveling system		1	8-40
18	13989791	Braking valve mounting		1	8-42




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	150202040038B	Plunger Motor		1	
2	A210204000215	Screw		8	
3	A210401000001	Washer		8	
4	B210780000007	Split Flange		4	
5	B210780000025	Elbow Fitting		1	
6	B210780000587	Adapter Fitting		1	
7	B230101000461	O-ring		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	B210780000043	Fitting		4	
2	B210780000733	Adapter Fitting		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	B220401001276	Shuttle Valve		2	
2	13448212	Valve block		1	
3	B210780001286	Adapter Fitting		3	
4	B210780000040	Adapter Fitting		4	
5	60235408	Hydraulic Control One-way Valve		2	
6	B210780000131	Adapter Fitting		1	
7	60035539	Electromagnetic Reversing Valve		1	
8	60033445	Throttle Screw Plug		1	
9	A210204000122	Screw		4	
10	A210401000017	Washer		2	
11	60249822	Screw		2	
12	B210399000003	Screw Plug		8	
13	A210307000012	Nut		2	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	B210780001286	Adapter Fitting		2	
2	A210401000017	Washer		2	
3	A220401000030	Priority Valve		1	
4	A210204000179	Screw		2	
5	A820205000995	Pipe connector		2	
6	A210609000041	O-ring		2	
7	B210780000266	Adapter Fitting		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	60105336	Plunger Motor		1	
2	A210204000162	Screw		8	
3	A820203000641	Flange Straight Joint		2	
4	B230101000233	O-ring		2	
5	B230101000241	O-ring		1	
6	13308908	Pipe Connector of LINON Motor		1	
7	B210780000344	Adapter Fitting		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	60311658	Check Valve		1	
2	B210780001749	Pressure-measuring Fitting		1	
3	B210780000266	Adapter Fitting		2	
4	A210204000017	Screw		2	
5	A210405000011	Washer		2	
6	A210401000001	Washer		2	
7	B210780000054	Adapter Fitting		1	
8	B210780000049	Adapter Fitting		1	
9	13917155	Return Block		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	B210780000652	Square Flange Right-angle Joint		1	
2	B210780000438	Square Flange Right-angle Joint		1	
3	60280112	Gear Pump		1	
4	A210204000354	Screw		2	
5	A210401000001	Washer		2	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	A210401000017	Washer		2	
2	B210780000201	Screw Plug		4	
3	B210780000824	End Through Adapter		2	
4	B220400000217	Valve, Relief		1	
5	B220401000540	Check Valve		1	
6	A210204000151	Screw		2	
7	13360514	Valve block body		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	60283185	Gear Motor		1	
2	B210780000232	Adapter Fitting		1	
3	B210780000266	Adapter Fitting		2	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	B210780000054	Adapter Fitting		1	
2	B2107800000609	Screw Plug		1	
3	B2107800000131	Adapter Fitting		3	
4	B2107800000037	Adapter Fitting		1	
5	A210401000001	Washer		2	
6	A2104050000011	Washer		2	
7	23000678	Screw Plug		1	
8	B2107800000040	Adapter Fitting		1	
9	A2102040000017	Screw		2	
10	B2107800000052	Adapter Fitting		1	
11	13915464	Oil collection block		1	





INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	A210401000017	Washer		3	
2	A210405000007	Washer		3	
3	A210204000162	Screw		3	
4	B210780000413	Tee Joint		1	
5	151207000029B	Pressure-measuring Connector		1	
6	14208716	Filter supporting board		1	
7	B210780000070	Fitting, Adapter		2	
8	60229226	End straight joint		2	
9	60260271	High Pressure Filter		1	
10	A210204000161	Screw		4	
11	A210401000001	Washer		4	
12	A210405000011	Washer		4	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	150102030013A	Plunger Pump		1	
2	B210780000107	Adapter Fitting		2	
3	B210780000059	Flange Adapter		4	
4	B210780000004	Split Flange		8	
5	B210299000026	Screw		16	
6	A210609000038	O-ring		4	
7	150102030012A	Plunger Pump		1	
8	B210780000008	Square Flange Joint		1	
9	60277744	External-meshing Gear Pump		1	8-30
10	B210780000009	Square Flange Joint		1	
11	B2107800000671	End Through Adapter		2	
12	B210780001175	Pressure-measuring Connector		4	
13	A229900009970	Bolt		8	
14	B210299000005	Screw		2	
15	A210405000002	Washer		8	
16	A210405000011	Washer		2	
17	B230101000960	O-ring		1	
18	B210780000898	Adapter Fitting		2	









INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	B230103001057	Rubber Hose		1	
2	A229900003852	Cord Clamp		1	
3	21021877	Hose		1	
4	B210780000018	Tee Joint		1	
5	B230103000869	Hose		1	
6	B210780000838	Elbow Fitting		3	
7	B230103000059	Rubber Hose		1	
8	21011473	Rubber Hose		1	
9	B210780000017	Tee Joint		3	
10	B230103000137	Rubber Hose		1	
11	151207000029B	Pressure-measuring Connector		1	
12	B230103006189	Rubber Hose		1	
13	B230103006405	Rubber Hose		1	
14	B230103000066	Rubber Hose		2	
15	B230103002218	Rubber Hose		1	
16	B230103005096	Rubber Hose		1	
17	151007060002	Rubber Hose Assembly		1	
18	B210780000685	Bulkhead Fitting		1	
19	B210334000010	Nut		1	
20	21023547	Screw plug		1	
21	60332213	rubber hose		1	
22	B230103004287	Rubber Hose		1	
23	B210780001396	Pipe connector		1	
24	B230103004027	Hose		1	
25	60034759	Rubber Hose		1	
26	B230103005873	Rubber Hose		1	
27	B230103002298	Rubber hose		1	
28	60165875	Pipe Adapter		2	
29	21020350	Rubber Hose		1	
30	23001025	Rubber Hose		1	
31	B210780000028	Elbow Fitting		1	
32	B230103001113	Hose		1	
33	B210780000186	End Through Adapter		2	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	B210780000266	Adapter Fitting		4	
2	B230103001629	Hose		1	
3	21003889	Hose		2	
4	B230103000295	Hose		1	
5	B230103000779	Rubber Hose		1	
6	21032394	Rubber Hose		1	
7	B210780000017	Tee Joint		3	
8	B210780000025	Elbow Fitting		5	
9	60127341	Hose Assembly		1	
10	13112771	Hose		1	
11	151207000029B	Pressure-measuring Connector		1	
12	B230103000345	Hose Assembly		1	
13	B230103007175	Hose Assembly		1	
14	60008237	Rubber Hose		1	
15	B230103001881	Rubber Hose		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	B210780000019	Tee Joint		1	
2	151207000031B	Pressure-measuring Connector		1	
3	B230103000712	Hose		1	
4	B230103001790	Rubber Hose		1	
5	B210780000228	Adapter Fitting		1	
6	B210780000609	Screw Plug		1	
7	A210609000038	O-ring		6	
8	B210780000007	Split Flange		12	
9	A210204000215	Screw		24	
10	A229900002752	Fitting, Elbow		2	
11	B210780000029	Elbow Fitting		1	
12	B210780000056	Flange Connection		4	
13	60065473	Rubber Hose		1	
14	B210780001310	Elbow Fitting		2	
15	60345453	rubber hose		1	
16	60207510	rubber hose		1	
17	151007260304B	Hose Assembly		1	
18	60202197	Pipe connector		1	
19	B210780000025	Elbow Fitting		1	
20	B210780000040	Adapter Fitting		1	
21	60345452	rubber hose		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	B230103005108	Rubber Hose		1	
2	B210780000021	Tee Joint		2	
3	60202197	Pipe connector		1	
4	B210780000029	Elbow Fitting		3	
5	B230103007493	Rubber Hose		1	
6	151399000452A	protective sleeve		1	
7	B210780000636	Elbow Fitting		3	
8	151007260233A	Rubber Hose Assembly		2	
9	B230103006274	Rubber Hose		1	
10	B230103001352	Rubber Hose		1	
11	B210780000829	Adapter Fitting		1	
12	B210780000631	Tee Joint		1	
13	B230103005107	Rubber Hose 4SH20-DKOS-SFS90-3850		1	
14	B230103006195	Hose Assembly		1	
15	151005110049A	Rubber hose assembly		1	
16	A229900003852	Cord Clamp		4	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	60016447	Pressure-Measuring Fitting		1	
2	B210780000036	Adapter Fitting		1	
3	B220400000079	Directional Solenoid Valve		1	
4	A210204000342	Screw		2	
5	B210780000228	Adapter Fitting		2	
6	A210204000119	Screw		4	
7	B210780000201	Screw Plug		1	
8	A820101342410	Control Valve Body		1	
9	A210401000017	Washer		2	
10	60005842	Plug Screw		1	



INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	60220963	Speed Sensor		1	
2	150202040038B	Plunger Motor		1	
3	A210204000215	Screw		8	
4	A210401000001	Washer		8	
5	B210780000007	Split Flange		4	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
6	B210780000025	Elbow Fitting		1	
7	B2107800000587	Adapter Fitting		1	
8	B230101000461	O-ring		1	




Group 9

covering parts




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	A210111000125	Bolt		4	
2	A210404000003	Washer		4	
3	A210891000007	Hinge		4	
4	A210111000088	Bolt		28	
5	A210307000012	Nut		4	
6	A210307000015	Nut		6	
7	YLJ004727975	left covering parts		1	
8	YLJ004728021	Covered in a		1	
9	YLJ005110630	Corver		1	
10	A210111000071	Bolt		6	
11	A210405000005	Washer		6	
12	60031250	Tool hasp		2	
13	A210405000007	Washer		28	




Group 10


rear frame




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	11104119	Damping bearer		2	
2	A210111000079	Bolt		12	
3	A210405000006	Washer		12	
4	14309077	Rubber retainer		1	
5	14529231	Rubber retainer		1	
6	14396915	Cover plate		1	
7	14510385	oil tank		1	10-6
8	YLJ005101815	air intake hood		1	
9	14396902	Cover plate		1	
10	14523445	Rubber retainer		1	
11	YLJ005393615	hose clip unit		1	
12	YLJ005103707	rear carriage weld assem		1	
13	14524432	Rubber retainer		1	
14	14309087	Ring		1	
15	10994336	Cover Board, Tube Clamp		2	
16	12884288	Tube Clamp		4	
17	YLJ005337392	Clip		1	
18	A210405000007	Washer		12	
19	A210111000090	Bolt		12	
20	13979898	Net plate		2	
21	A210111000032	Bolt		14	
22	YLJ005337594	Clip		1	
23	YLJ005337130	Clip		2	
24	13920581	cover plate		1	
25	13689696	cover plate		1	
26	YLJ005770629	cover plate		1	
27	A210405000011	Washer		31	
28	A210111000125	Bolt		17	
29	A820205001562	Spacer Plate Joint		2	
30	YLJ005337280	Clip		1	



INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
22	YLJ005337594	Clip		1	
23	YLJ005337130	Clip		2	
31	YLJ005619004	rubber retainer		1	
32	YLJ005619017	rubber retainer		2	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	14510370	hydraulic fuel tank welding assy		1	
2	A210405000007	Washer		8	
3	A210111000088	Bolt		8	
4	A210405000001	Washer		6	
5	A210111000037	Bolt		6	
6	A250100000043	Liquid Level Meter		1	
7	A222100000044	Air Filter		1	
8	A210609000035	O-ring		1	
9	10245100	Cover Plate, Flange, Oil Tank		1	




Group 11


Bridging BeamComponent




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	YLJ006045976	Cross beam welding		1	
2	13687649	Under scraper assem		1	11-4
3	YLJ005652578	Upper scraper assem.		1	11-6
4	A210401000017	Washer		4	
5	A210405000011	Washer		4	
6	A210204000347	Screw		4	



INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	13687111	Supporting plate welding		1	
2	13687079	Scraper		1	
3	13687080	Pressure plate		1	
4	A210404000003	Washer		10	
5	A210111000027	Bolt		6	
6	A210405000011	Washer		6	
7	A210401000001	Washer		10	
8	A210307000017	Nut		6	
9	A210405000001	Washer		6	
10	A210111000040	Bolt		4	
11	A210307000001	Nut		4	
12	A210404000004	Washer		2	
13	13687570	Support plate		1	
14	13687571	Support plate		1	
15	A210111000023	Bolt		4	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	A210401000001	Washer		18	
2	A210405000011	Washer		14	
3	A210111000027	Bolt		6	
4	A210307000017	Nut		12	
5	A210404000003	Washer		14	
6	13687079	Scraper		1	
7	A210111000029	Bolt		6	
8	13687080	Pressure plate		1	
9	13687078	Support plate		1	
10	YLJ005567022	Scraper mounting plate		1	
11	YLJ005568451	mounting plate welding		1	
12	YLJ005568781	Scraper mounting plate		1	
13	YLJ005568841	mounting plate welding		1	
14	120801010021A	Spring		2	
15	151302010028A	Pipe Clip		4	
16	A2101110000297	Bolt		8	
17	YLJ005567030	Mounting plate		2	




Group 12

water




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	14323427	Outlet piping installation		1	
2	YLJ005419735	Water sprinkling tube component		2	
3	YLJ004856263	Water Tank		1	




Group 13


Electrical system of roller




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	13455256	Power assembly		1	13-4
2	14512008	Electrical Control Box Assembly		1	13-6
3	14514219	Electric system assembly of Control box		1	13-8
4	14173552	Electrical system , rear carriage		1	13-10
5	14388807	Electrical system , front carriage		1	13-14
6	YLJ005348321	Electrical harness assembly basic diagram		1	13-22




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	142507000007A	Power Supply Master Switch		1	
2	A210319000001	Nut		3	
3	60190637	Battery		2	
4	A210319000003	Nut		1	
5	60243535	Nut		1	
6	A210319000009	Nut		2	
7	13523222	Preheating System Assembly		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	60208351	Gauge Line Groove		1	
2	A810201206116	Controller Assembly		1	
3	60146855	Central Appliance Case		1	
4	B241300000020	Fuse		6	
5	B241300000021	Fuse		7	
6	B241300000024	Fuse		1	
7	B241300000022	Fuse		3	
8	B241300000026	Fuse		2	
9	60151326	Intermediate Relay		5	
10	B240700000006	Intermediate Relay		2	
11	B2407000000262	Relay		2	
12	14511713	Face film		1	
13	A210111000240	Bolt		20	
14	A210111000084	Bolt		4	
15	A210111000078	Bolt		7	
16	60200720	Fastening Clamp		1	
17	60202971	Flasher Relay		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	B241200000529	Toggle Switch		3	
2	B241200000532	Toggle Switch		3	
3	SZN007370178	Sany Intelligent Date Display		1	
4	60000164	Button Switch		1	
5	60026374	Contact Block, Normally-opened		1	
6	B240200000059	Emergency Stop Button		1	
7	B241200001124	Ignition Switch		1	
8	B241200000530	TOGGLE SWITCH		6	
9	B241200000531	TOGGLE SWITCH		2	
10	60134345	Indicator Lamp		1	
11	142601000026A	Electric Handle		1	
12	60105071	24V Cigar Lighter		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	B241200000582	2-Core Rectangular Socket		1	
2	A249900001139	Secondary Lock 2-Wire (Pin)		1	
3	B249900000288	Pin		5	
4	B241200000604	Rectangular Socket, 4-Position		1	
5	A222200000164	Lock, 4-Wire Pin		1	
6	B229900002528	Blocked Up		1	
7	146399000011A	Backup Alarm		1	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	B241200000582	2-Core Rectangular Socket		1	
2	A249900001139	Secondary Lock 2-Wire (Pin)		1	
3	B249900000288	Pin		5	
4	B241200000604	Rectangular Socket, 4-Position		1	
5	A222200000164	Lock, 4-Wire Pin		1	
6	B229900002528	Blocked Up		1	
7	146399000011A	Backup Alarm		1	




INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	60246671	Speaker		1	
2	12737754	Spacer Sleeve		1	
3	A210401000017	Washer		1	
4	A210405000007	Washer		1	
5	A210110000306	Blot		1	
6	A210307000012	Nut		1	
7	60206740	Fuel Sensor		1	
8	60282750	Level Sensor		1	
9	60203058	Proximity Switch		1	
10	B241200000582	2-Core Rectangular Socket		6	
11	A249900001139	Secondary Lock 2-Wire (Pin)		6	
12	B249900000288	Pin		12	
15	60200720	Fastening Clamp		15	
16	60200721	Clamp		20	
17	60200723	Fastening Clamp		15	
18	A229900003852	Cord Clamp		10	
19	60200725	Fastening Clamp		10	
20	60041902	90-degree Fixed Metal Accessories		2	
21	60200719	Fastening Clamp		10	
22	A229900003853	Clamp		10	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
7	60206740	Fuel Sensor		1	
8	60282750	Level Sensor		1	
9	60203058	Proximity Switch		1	
10	B241200000582	2-Core Rectangular Socket		6	
11	A249900001139	Secondary Lock 2-Wire (Pin)		6	
12	B249900000288	Pin		12	




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
13	141601010057A	Headlamp		2	
14	141601010056A	Headlamp		2	
15	60200720	Fastening Clamp		15	
16	60200721	Clamp		20	
17	60200723	Fastening Clamp		15	
18	A229900003852	Cord Clamp		10	
19	60200725	Fastening Clamp		10	
20	60041902	90-degree Fixed Metal Accessories		2	






INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	YLJ005348333	Electrical harness in Electric Control Cabinet wiring diagram		1	
2	14511690	Electrical harness of Control box		1	
3	YLJ005348359	Front Frame Electrical Harness wiring diagram		1	
4	YLJ005348340	Rear Frame Electrical Harness basic diagram		1	
5	YLJ005348415	Electrical harness of Engine wiring diagram		1	
6	13636316	Engine Ground Cable		1	
7	13636366	Battery switch connection		1	
8	13690724	Front Frame to Rear Frame Connecting Wire		1	
9	13127937	Wire connecting to battery		1	
10	13690725	Battery Motor connection Wire		1	
11	13690722	Earthing wire of power supply master switch		1	
12	13549882	Preheat Harness		1	





Group 14

Driver's Cab Assy




INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	130901000268B	Cab(JRTR07A)		1	14-4
2	130907000166A	Rearview mirror assy		2	
3	A210110000347	Bolt		4	
4	A210491000132	Washer		8	
5	A210307000005	Nut		4	
6	A210401000002	Washer		16	
7	A210111000203	Bolt		16	
8	60017650	Damperr		2	
9	13177140	Adjusting Spacer		1	
10	13177149	Adjusting Shim		1	
11	131602000090A	Shock Absorber		2	
12	60062854	Key Ring		1	







INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	JSS005361405	Cab body		1	14-8
2	JSS005364030	JRTR07A inner&outer-decoration assembly		1	14-10
3	11262101	Positioning Belt, Door		2	
4	13437990	Change-over Mechanism		1	
5	13701323	Left sliding window		1	
6	13701324	Left sliding window		1	
7	13740132	Electric assembly		1	
8	13744688	Pull rod		2	
9	13755945	Change-over Mechanism		1	
10	60024135	Handle		2	
11	60031309	Handle, Auxiliary		2	
12	60042056	Plug		2	
13	60263714	Door Lock		1	
14	60312227	Right door lock		1	
15	A229900005559	Coat Hook		1	
16	JSS006065140	Big cup holder		1	
17	YLJ004964826	Phone cup		1	
18	A820301017645	Lock Pole		2	
19	A210401000016	Washer		32	
20	A210401000017	Washer		27	
21	A210404000005	Washer		23	
22	A210405000006	Washer		32	
23	A210405000007	Washer		4	
24	A210491000001	Screw		4	
25	A210491000009	Pin		4	
26	A229900009879	Gas Spring		2	
27	A31907100070B	Axis Pin		4	



INDEX	PART NO	DESCRIPTION	Remark	QTY	SEE PAGE
1	JSS005361407	Driver's cab welding assy		1	
2	JSS005361404	Floor welding assembly		1	
3	10347509	Support Plate II		2	
4	13707111	Left door welding assy.		1	
5	13707117	Right door welding assembly		1	
6	13707120	Rear panel assembly		1	
7	13744486	Outer armrest		2	
8	A210111000053	Bolt		14	
9	A210307000012	Nut		8	
10	A210401000004	Washer		14	
11	A210405000003	Washer		14	
12	A210891000007	Hinge		4	
13	A820101362643	Installation Seat		2	
14	60040336	Nut		2	
15	JSS006345517	Bracket		1	
16	JSS006345753	support		1	
17	JSS006382136	Fan stay Welding Assy.		1	
18	JSS006467729	stiffening plate		1	



INDEX	PART NO.	DESCRIPTION	Remark	QTY	SEE PAGE
1	JSS005350459	Floor leather JRTR07A		1	
2	12332585	Overhaul, cap		1	
3	13696112	Roof guard plate		1	
4	13702460	Front window glass		1	
5	13702461	Left-front window glass		1	
6	13702462	Right-front window glass		1	
7	13702463	Left-door window glass		1	
8	13702464	Rightt-door window glass		1	
9	13702465	Rear window glass		1	
10	13702466	Left-rear window glass		1	
11	13702467	Right-rear window glass		1	
12	13705022	Right, door, sealing, strip		1	
13	13705345	Left, door, sealing, strip		1	



Index

10211702 Coupling bar.....	4-9	130103000367A001 Planetary Gear.....	2-13
10212192 Support welding.....	4-11	130103000367A002 Cylinder Roller Bearing.....	2-13
10245100 Cover Plate, Flange, Oil Tank.....	10-7	130103000367A003 Retainer.....	2-13
10250742 Retainer Ring.....	6-7	130103000367A004 Holder.....	2-13
10347509 Support Plate II.....	14-9	130103000367A005 Floating Seal.....	2-13
10891719 Threaded Cover.....	7-9	130103000367A006 Sun Gear.....	2-13
10891721 Threaded Cover.....	2-17	130103000367A007 Planetary Gear.....	2-13
10993801 Connector.....	5-5	130103000367A008 Taper Roller Bearing.....	2-13
10993805 Connector.....	5-5	130103000367A009 Cylinder Roller Bearing.....	2-13
10994336 Cover Board, Tube Clamp.....	10-3	130103000367A010 Bearing Holder.....	2-13
11026326 Compressor bracket.....	5-5	130103000367A011 Locknut.....	2-13
11101836 Damping Pad Of Radiator.....	7-11	130103000367A012 Rear Cover Pad.....	2-13
11104119 Damping bearer.....	10-3	130103000367A013 Cylindrical Roller.....	2-13
11109312 Lock pin.....	6-11	130103000367A014 O-ring.....	2-13
11109315 Handle.....	6-11	130103000367A015 Axle.....	2-13
11122499 Stopper ring.....	6-7	130103000367A016 Cushion.....	2-13
11123065 Snap ring.....	6-7	130103000367A017 Ring, Snap.....	2-13
11262101 Positioning Belt, Door.....	14-7	130103000367A018 Ring, Retainer.....	2-13
11405879 Retaining disc.....	2-3	130103000367A019 Type-A elastic Ring for Axle.....	2-13
11534382 Rubber pad.....	5-5	130103000367A020 Elastic Ring For Large Axle.....	2-13
11558668 Hoop.....	7-11, 7-15	130103000367A021 ring gear.....	2-13
11563406 Connecting Rubber Hose.....	7-11	130103000367A022 o-ring.....	2-13
120701080001A Type A Triangular Belt.....	5-5	130103000367A023 Circlips for Shaft.....	2-13
120801010021A Spring.....	11-7	130103000367A024 Ring, Snap.....	2-13
12278981 Cover.....	2-7	130103000367A025 carrier.....	2-13
12281495 Cover.....	2-17	130103000367A026 Screw.....	2-13
12332585 Overhaul, cap.....	14-11	130103000367A027 Screw.....	2-13
12355725 Screw Plug.....	6-7	130103000367A028 Sealing Ring.....	2-13
12359619 Sealing Ring.....	6-3, 6-5	130103000367A029 Double-side Static Friction Plate.....	2-13
12359672 Retainer Ring.....	6-3, 6-5	130103000367A030 Ring, Snap.....	2-13
12360169 Lock pin.....	6-5	130103000367A031 Spline Shaft.....	2-13
12364139 Guide sleeve.....	6-7	130103000367A032 Piston.....	2-13
12364143 Piston.....	6-7	130103000367A033 Sealing Ring.....	2-13
12364145 Rear clipping key.....	6-7	130103000367A034 Spring Sleeve.....	2-13
12364146 Clipping key cap.....	6-7	130103000367A035 Ring, Snap.....	2-15
12364147 Steering Cylinder.....	6-5	130103000367A036 Spring.....	2-15
12364148 Cylinder assem.....	6-7	130103000367A037 Screw.....	2-13
12364150 Piston rod assem.....	6-7	13021799 End cover of bearing seat.....	2-17
12732056 Bearing seat welding.....	2-17	13089922 Bushing.....	3-11
12737754 Spacer Sleeve.....	13-15	130901000268B Cab(JRTR07A).....	14-3
12744699 Bearing seat component.....	2-5	130901000269B JRTR07 double steel roller cab console body.....	14-5
12844446 Movable block chamber welding ..	2-9, 2-11	130907000166A Rearview mirror assy.....	14-3
12844477 Fixed eccentric block.....	2-9, 2-11	13112771 Hose.....	8-37
12844503 Modulator, amplitude.....	2-3	13127937 Wire connecting to battery.....	13-23
12844646 Modulator, amplitude.....	2-5	131602000090A Shock Absorber.....	14-3
12844740 Support shaft.....	3-17	13175440 Electrical control penal.....	4-13
12884288 Tube Clamp.....	10-3	13175443 Fixing plate.....	4-13
12955989 Pin.....	6-11	13175451 Electrical control penal component.....	4-11
12955991 Lock pin.....	6-5	13177140 Adjusting Spacer.....	14-3
12984281 Cover plate.....	2-5	13177149 Adjusting Shim.....	14-3
130103000174B006 Sealing ring.....	2-13	13181668 Retainer Ring.....	6-3, 6-5
130103000174B008 sealing ring.....	2-13		
130103000175B001 Movable friction plate.....	2-13		
130103000286B001 Circlips for Shaft.....	2-13		
130103000286B007 Screw.....	2-13		

13201192 Vibratory shaft	2-11	13696112 Roof guard plate	14-11
13201312 Vibratory shaft	2-9	13701323 Left sliding window	14-7
13208018 Oil Cup Base	2-7	13701324 Left sliding window	14-7
13297001 Retaining ring II	6-5	13702460 Front window glass	14-11
13297012 Retainer Ring	6-5	13702461 Left-front window glass	14-11
13300057 Sensor Connector	7-17	13702462 Right-front window glass	14-11
13308908 Pipe Connector of LINON Motor	8-15	13702463 Left-door window glass	14-11
13309251 Intermediate bearing seat	2-5	13702464 Rightt-door window glass	14-11
13309621 Connection sleeve	2-7	13702465 Rear window glass	14-11
13309783 End plate	2-7	13702466 Left-rear window glass	14-11
13311381 Scraper welding	2-5	13702467 Right-rear window glass	14-11
13352058 Mounting Rack Welding	4-5	13705022 Right, door, sealing, strip	14-11
13352079 Display Mounting Rack	4-3	13705345 Left, door, sealing, strip	14-11
13360514 Valve block body	8-21	13707111 Left door welding assy.	14-9
13394536 Foot pedal	4-9	13707117 Right door welding assembly	14-9
13403379 Spacer	2-3	13707120 Rear panel assembly	14-9
13437990 Change-over Mechanism	14-7	13718118 Degassing pipe	7-13
13445919 Battery cover assembly	3-15	13731104 Bracket uppercover board	4-9
13445921 Rubber liner plates	3-15	13740132 Electric assembly	14-7
13445924 Battery component	3-3	13744486 Outer armrest	14-9
13448212 Valve block	8-11	13744688 Pull rod	14-7
13448213 Crablike valve mounting	8-3	13755945 Change-over Mechanism	14-7
13449188 Pressure plate	3-3	13765129 Preheating Mounting Rack	7-19
13449189 Rubber Cushion	3-3	13817935 Support plate welding	2-5
13455256 Power assembly	13-3	13818666 Support plate welding	2-3
13520944 Connecting Disk	7-9	13836405 Axle supporting	3-17
13523222 Preheating System Assembly	13-5	13836428 Bushing	3-17
13523768 Front bearer board	7-7	13867303 Shim	2-3
13549882 Preheat Harness	13-23	13892899 Supporting plate	3-17
13589449 rear outrigger	7-5	13892906 Bushing	3-17
13599611 Gsj Seal Ring	6-7	13892932 Hose clip unit	3-3
13610941 Rock Arm	4-11	13915464 Oil collection block	8-25
13636316 Engine Ground Cable	13-23	13916302 BLOCK OF collecting assembly	8-5
13636366 Battery switch connection	13-23	13917155 Return Block	8-17
13673659 muffler	7-15	13917318 Return Block assembly	8-5
13684348 Rubber retainer	3-5	13918399 filter assembly	8-5
13684350 Supporting plate	3-11	13919808 Connecting Rubber Hose	7-11
13684351 Axle supporting	3-11	13919828 Inter-cooler intake pipe	7-13
13684352 Axle supporting	3-11	13919833 Discharging tube	7-13
13685018 Hose clip unit	3-5	13920410 engine installation	7-3
13686274 Fan valve mounting	8-5	13920581 cover plate	10-3
13686363 Priority valve assembly	8-3	13921420 Exhaust hose	7-15
13686364 Steering component	8-3	13922408 ecise filtration supporting board	7-19
13686715 Cover plate	3-5	13922412 Engine oil cleaner filtration supporting board	7-19
13687078 Support plate	11-7	13925123 Drainage adaptor	7-19
13687079 Scraper	11-5, 11-7	13977278 Vibratory end bearing holder	2-7
13687080 Pressuring plate	11-5, 11-7	13979898 Net plate	10-3
13687111 Supporting plate welding	11-5	13989791 Braking valve mounting	8-5
13687570 Support plate	11-5	14000982 Supporting Plate	2-5
13687571 Support plate	11-5	14000983 Pedal	2-5
13687649 Under scraper assem	11-3	14009225 Fixing plate	2-3
13688588 Exhaust Pipe Spacer	7-15	14057294 water-in tube	7-13
13688857 Upper cover welding of control cabinet	4-9	14057339 water-in tube	7-13
13689696 cover plate	10-3	14071075 cylinder	5-9
13689958 Cushion block	7-11	14130377 Rubber retainer (3)	3-3
13690722 Earthing wire of power supply master switch	13-23	14155306 Steering Control System	4-3
13690724 Front Frame to Rear Frame Connecting Wire	13-23	14155632 Rubber pad	4-9
13690725 Battery Motor connection Wire	13-23	14159223 Screw	3-15
		141601010056A Headlamp	13-19
		141601010057A Headlamp	13-19

14160181 Cylinder Assembly, Steering.....	6-5	14523445 Rubber retainer	3-3, 10-3
14160284 Roller Wheel	2-3	14524432 Rubber retainer	10-3
14163131 Package of process sealing parts.....	6-9	14529231 Rubber retainer	10-3
14173552 Electrical system , rear carriage	13-3	14545153 Clamp.....	2-5
14184596 Weldment of watering tube	7-11	14545154 Clamp.....	2-3
14208716 Filter supporting board	8-27	146399000011A Backup Alarm	13-11, 13-13
14217318 cushion block	7-5	150102030012A Plunger Pump.....	8-29
14217405 left outrigger welding assembly.....	7-5	150102030013A Plunger Pump.....	8-29
14217505 Right outrigger welding assembly.....	7-7	150202040038B Plunger Motor.....	8-7, 8-45
14242649 Steering board weldedment.....	4-9	150204010018A001 Oil sealer	8-31
142507000007A Power Supply Master Switch.....	13-5	151005110049A Rubber hose assembly	8-41
142601000026A Electric Handle	13-9	151007060002 Rubber Hose Assembly	8-35
14274679 prefiltration support.....	7-19	151007260233A Rubber Hose Assembly	8-41
14309077 Rubber retainer	10-3	151007260304B Hose Assembly.....	8-39
14309087 Ring	3-5, 10-3	151207000029B Pressure-measuring Connector.....	8-27, 8-35, 8-37
14321843 vibration dummy club welding.....	2-3	151207000031B Pressure-measuring Connector.....	8-39
14321864 driving dummy club welding.....	2-3	151302010028A Pipe Clip	11-7
14321909 Fork leg	2-3	151399000452A protective sleeve.....	8-41
14321920 Fork leg	2-3	151402030066A Oil seal.....	2-7
14323427 Outlet piping installation	12-3	160102050024A engine.....	7-5
14352067 Console bracket assembly	4-3	21003889 Hose.....	8-37
14353444 Harness installation plate	4-15	21005327 Bolt.....	4-13
14353567 Side box base plate	4-15	21005351 Bolt.....	5-9
14354634 Sealing ring.....	4-11	21011473 Rubber Hose	8-35
14354664 Lock plate	4-9	21017994 Screw Plug.....	7-19
14380664 Fixing plate	2-3	21020350 Rubber Hose.....	8-35
14385045 Travel supporting in vibration end.....	2-3	21021877 Hose.....	8-35
14388807 Electrical system , front carriage	13-3	21021914 Rubber Hose.....	7-19
14395896 Clamp.....	2-3	21023547 Screw plug	8-35
14395968 Clamp.....	2-3	21032394 Rubber Hose.....	8-37
14396902 Cover plate	10-3	23000678 Screw Plug.....	8-25
14396915 Cover plate	10-3	23001025 Rubber Hose.....	8-35
14414864 Installation adaptor of fan	7-13	24002383 O-ring	2-5
14463742 L-shape plate	4-3	60000164 Button Switch	13-9
14463848 U plate	4-3	60005842 Plug Screw	8-43
14464030 U plate	4-3	60008237 Rubber Hose.....	8-37
14485553 Console bracket weldment	4-9	60015644 Hinge.....	3-13
14495199 Right plate	5-9	60016447 Pressure-Measuring Fitting.....	8-43
14495244 Left plate.....	5-9	60017650 Damperr	14-3
14506058 pump connection.....	7-3	60024135 Handle.....	14-7
14510370 hydraulic fuel tank welding assy.....	10-7	60026374 Contact Block, Normally-opened.....	13-9
14510385 oil tank.....	10-3	60031250 Tool hasp	9-3
14511035 Electrical system of roller	1-3	60031309 Handle, Auxiliary	14-7
14511191 Hydraulic system assembly.....	1-3	60033283 Magnetic screw plug	2-7
14511380 Traveling motor.....	8-3	60033445 Throttle Screw Plug	8-11
14511533 Vibratory motor.....	8-5	60034012 Dump block.....	2-3
14511690 Electrical harness of Control box	13-23	60034759 Rubber Hose.....	8-35
14511708 Steering Pump.....	8-5	60034933 Fan.....	7-13
14511713 Face film	13-7	60035082 Felt Seal Ring.....	2-7
14511747 Fan motor component	8-5	60035539 Electromagnetic Reversing Valve.....	8-11
14512008 Electrical Control Box Assembly	13-3	60040336 Nut	14-9
14512102 Triple Pump.....	8-5	60041902 90-degree Fixed Metal Accessories	13-15, 13-19
14512830 Piping diagram of traveling system.....	8-5	60042056 Plug.....	14-7
14513010 Piping diagram of vibratory system.....	8-5	60045017 Detachable Fitting.....	6-3, 6-5
14513076 Radiator of vibratory system.....	8-5	60062854 Key Ring.....	14-3
14513087 Pipeline layout of brake and steering systems.....	8-5	60065473 Rubber Hose.....	8-39
14514219 Electric system assembly of Control box	13-3	60082193 Screw.....	2-5
14517625 Side box support plate welding.....	4-9	60082894 Joint Bearing.....	6-3
14519482 Front cover plate weldment	4-9		

60105071 24V Cigar Lighter.....	13-9	A210111000023 Bolt	7-19, 11-5
60105336 Plunger Motor	8-15	A210111000024 Bolt	7-11, 7-15
60109047 Breather.....	2-3	A210111000026 Bolt	2-3, 5-7, 7-15
60127341 Hose Assembly	8-37	A210111000027 Bolt	11-5, 11-7
60134345 Indicator Lamp	13-9	A210111000029 Bolt	7-19, 11-7
60134354 Hose Clamp	7-13	A210111000032 Bolt	10-3
60146855 Central Appliance Case	13-7	A210111000037 Bolt	3-3, 6-11, 10-7
60151326 Intermediate Relay	13-7	A210111000038 Bolt	6-5
60165875 Pipe Adapter	8-35	A210111000040 Bolt	7-19, 11-5
60190637 Battery.....	13-5	A210111000053 Bolt	2-5, 14-9
60191772 Right-angle Joint, Clamp Sleeve-type	6-3	A210111000054 Bolt	2-3
60191773 Ferrule-type Straight Adapter.....	6-3, 6-5	A210111000062 Bolt	2-3
60200719 Fastening Clamp	13-15, 13-21	A210111000071 Bolt	9-3
60200720 Fastening Clamp	13-7, 13-15, 13-19	A210111000078 Bolt	4-9, 5-5, 13-7
60200721 Clamp.....	13-15, 13-19	A210111000079 Bolt	10-3
60200723 Fastening Clamp	13-15, 13-19	A210111000080 Bolt	3-13, 4-9
60200724 Clamp.....	5-5	A210111000081 Bolt	4-9
60200725 Fastening Clamp	13-15, 13-19	A210111000084 Bolt	13-7
60202197 Pipe connector	8-39, 8-41	A210111000088 Bolt	2-7, 2-17, 9-3, 10-7
60202971 Flasher Relay.....	13-7	A210111000089 Bolt	3-5, 4-9, 6-3, 7-15
60203058 Proximity Switch.....	13-15, 13-17	A210111000090 Bolt	2-5, 4-9, 5-9, 7-15, 10-3
60206740 Fuel Sensor	13-15, 13-17	A210111000091 Bolt	7-19
60207510 rubber hose.....	8-39	A210111000092 Bolt	3-9
60208351 Gauge Line Groove	13-7	A210111000094 Bolt	7-19
60220963 Speed Sensor	8-45	A210111000119 Bolt	5-7, 7-5
60229226 End straight joint.....	8-27	A210111000125 Bolt	9-3, 10-3
60231763 Rolling Bearing.....	2-5	A210111000197 Bolt	7-11
60235408 Hydraulic Control One-way Valve.....	8-11	A210111000199 Bolt	7-11
60243535 Nut.....	13-5	A210111000202 Bolt	7-9
60244891 Flexible Coupling.....	2-5	A210111000203 Bolt	7-11, 14-3
60246671 Speaker.....	13-15	A210111000204 Bolt	7-5
60249822 Screw.....	8-11	A210111000240 Bolt	13-7
60253934 Rubber Hose.....	5-5	A210111000281 Bolt	6-3
60260271 High Pressure Filter.....	8-27	A210111000282 Bolt	6-3
60263714 Door Lock	14-7	A210111000283 Bolt	4-9
60277744 External-meshing Gear Pump.....	8-29	A210111000291 Bolt	6-3
60280112 Gear Pump.....	8-19	A210111000297 Bolt	11-7
60282750 Level Sensor.....	13-15, 13-17	A210111000307 Bolt	3-3
60283185 Gear Motor.....	8-23	A210111000343 Bolt	7-11
60311658 Check Valve	8-17	A210111000364 Bolt	3-3
60312227 Right door lock	14-7	A210113000039 Bolt	7-5
60312939 Rubber Hose.....	7-19	A210114000001 Bolt	2-5
60332213 rubber hose.....	8-35	A210114000007 Bolt	2-3, 2-7
60340908 Radiator.....	7-13	A210114000012 Bolt	2-5
60345452 rubber hose.....	8-39	A210204000017 Screw	8-17, 8-25, 8-33
60345453 rubber hose.....	8-39	A210204000019 Screw	3-3
61005880 Reducer.....	2-5	A210204000119 Screw	8-43
61010743 Instrument panel assembly.....	4-7	A210204000122 Screw	8-11
61016820 Flexible Coupling.....	2-3	A210204000130 Screw	4-15
61030482 Double Drum Vibratory Roller Air-condition Assy.....	5-3	A210204000131 Screw	2-3, 4-15
A210110000006 Bolt	4-3	A210204000151 Screw	8-21
A210110000201 Bolt	6-3	A210204000161 Screw	3-17, 8-27
A210110000218 Bolt	3-3	A210204000162 Screw	8-15, 8-27
A210110000304 bolt.....	5-7	A210204000164 Screw	7-11
A210110000306 Bolt	13-15	A210204000179 Screw	8-13
A210110000331 Bolt	2-3	A210204000197 Screw	5-7
A210110000347 Bolt	14-3	A210204000206 Screw	7-5
A210111000011 Bolt.....	2-17, 3-3	A210204000215 Screw	7-9, 8-7, 8-39, 8-45
A210111000018 Bolt	3-11, 4-7, 5-5	A210204000221 Screw	2-7
		A210204000337 Screw	7-5
		A210204000342 Screw	2-3, 8-43

A210204000346 Screw	2-3	A210434000007 Washer	2-7
A210204000347 Screw	11-3	A210434000010 Washer	2-3
A210204000354 Screw	7-9, 8-19	A210434000011 Washer	2-7, 6-7
A210204000356 Screw	2-5	A210434000020 Washer	2-5
A210210000003 Screw	3-7	A210453000004 Washer	2-7
A210210000030 Screw	4-3, 4-5	A210453000007 Washer	2-7
A210211000008 Screw	3-13	A210491000001 Screw	14-7
A210307000001 Nut	3-3, 7-19, 11-5	A210491000003 Belleville Spring	6-3
A210307000005 Nut	14-3	A210491000009 Pin	14-7
A210307000012 Nut	4-9, 7-11, 7-15, 7-19, 8-11, 9-3, 13-15, 14-9	A210491000118 Washer	2-3, 2-7, 6-3
A210307000015 Nut	9-3	A210491000121 Washer	2-5, 7-9
A210307000016 Nut	3-5, 4-11, 5-5, 7-11	A210491000132 Washer	2-3, 6-3, 14-3
A210307000017 Nut	3-3, 3-11, 3-15, 3-17, 5-7, 7-11, 7-19, 11-5, 11-7	A210501000043 Pin	4-11
A210307000029 Nut	5-7	A210508000067 Pin	4-11
A210307000040 Nut	5-7	A210509000037 Key	2-3
A210309000016 Nut	7-17	A210509000088 Key	2-9, 2-11
A210315000005 Nut	2-3	A210609000009 O-ring	6-7
A210319000001 Nut	13-5	A210609000013 O-ring	2-7
A210319000003 Nut	13-5	A210609000035 O-ring	2-7, 10-7
A210319000009 Nut	13-5	A210609000038 O-ring	8-29, 8-39
A210332000004 Screw Plug	2-7	A210609000041 O-ring	8-13
A210333000001 Plug, Screw	2-7	A210609000062 O-ring	6-7
A210333000007 Screw Plug	2-5	A210609000174 O-ring	2-17
A210401000001 Washer	3-3, 3-11, 3-15, 5-5, 7-9, 7-11, 7-15, 7-19, 8-7, 8-17, 8-19, 8-25, 8-27, 8-33, 8-45, 11-5, 11-7	A210609000284 O-ring	2-3
A210401000002 Washer	3-3, 5-7, 6-5, 7-9, 7-11, 14-3	A210612000013 Joint Bearing	6-3, 6-5
A210401000004 Washer	2-5, 5-7, 14-9	A210616000012 Spring	4-11
A210401000006 Washer	5-7	A210628000009 Rolling bearing	2-7
A210401000007 Washer	2-5	A210804000002 Fitting, Grease	2-7, 6-3, 6-5
A210401000016 Washer	4-9, 4-13, 5-5, 14-7	A210855000052 T-Type Clamp	7-11
A210401000017 Washer	2-5, 3-9, 4-9, 5-9, 6-3, 7-11, 7-15, 7-19, 8-11, 8-13, 8-21, 8-27, 8-43, 11-3, 13-15, 14-7	A210855000066 Hole Type Hose Clamp	5-5
A210404000003 Washer	5-5, 9-3, 11-5, 11-7	A210891000007 Hinge	4-9, 9-3, 14-9
A210404000004 Washer	11-5	A219900000089 Handle Ball	4-9
A210404000005 Washer	4-9, 14-7	A220400000070 Ball Valve	5-5
A210404000008 Washer	3-3	A220401000030 Priority Valve	8-13
A210405000001 Washer	3-3, 4-3, 5-7, 6-5, 6-11, 7-5, 7-11, 7-17, 7-19, 10-7, 11-5	A222000000080 Damper	4-11
A210405000002 Washer	8-29	A222100000044 Air Filter	10-7
A210405000003 Washer	14-9	A222200000058 Cover Latch Accessories	3-13
A210405000004 Washer	4-3	A222200000164 Lock, 4-Wire Pin	13-11, 13-13
A210405000005 Washer	3-7, 9-3	A229900001355 Blbow	5-5
A210405000006 Washer	3-5, 3-13, 4-9, 4-13, 4-15, 5-5, 7-11, 10-3, 14-7	A229900001929 Mechanical Suspension Driver seat	4-3
A210405000007 Washer	2-5, 2-7, 2-17, 3-3, 3-9, 4-9, 5-9, 6-3, 7-11, 7-15, 7-19, 8-27, 9-3, 10-3, 10-7, 13-15, 14-7	A229900002031 T-type Clamp	7-11
A210405000010 Washer	7-19	A229900002263 T-Type Clamp	7-15
A210405000011 Washer	2-3, 2-17, 3-3, 3-11, 3-15, 3-17, 4-7, 7-9, 7-11, 7-15, 7-19, 8-17, 8-25, 8-27, 8-29, 10-3, 11-3, 11-5, 11-7	A229900002381 Rain Hat	7-15
A210405000014 Washer	7-19	A229900002460 Steering Gear	4-7
A210414000015 Retainer Ring	6-7	A229900002724 Slewing bearing	6-3
A210414000028 Retainer Ring	2-3	A229900002752 Fitting, Elbow	8-39
A210414000037 Retainer Ring	6-7	A229900002965 Clamp	7-11
A210414000065 Retainer Ring	2-5	A229900003184 Slewing bearings	4-9
A210416000006 Retainer Ring	2-3	A229900003542 Mechanical Differential Pressure Indicator	7-17
A210416000034 Retainer Ring	6-3, 6-5	A229900003759 T-Type Clamp	7-15
		A229900003852 Cord Clamp	8-35, 8-41, 13-15, 13-19
		A229900003853 Clamp	13-15, 13-21
		A229900003898 T-type Clamp	7-15
		A229900005421 Shock Pad	7-5
		A229900005559 Coat Hook	14-7
		A229900009879 Gas Spring	14-7
		A229900009970 Bolt	8-29
		A230101000302 FB Oil Seal	2-7

A230200000026 PTFE glass fiber varnish cloth...	7-15	B210780000107 Adapter Fitting	8-29
A2399000000239 Fiberglass felt strip	7-15	B210780000131 Adapter Fitting	8-11, 8-25
A2499000000600 Cable Connector	4-3	B210780000186 End Through Adapter	8-35
A249900001139 Secondary Lock 2-Wire (Pin)	13-11, 13-13, 13-15, 13-17	B210780000201 Screw Plug	8-21, 8-43
A250100000043 Liquid Level Meter	10-7	B210780000228 Adapter Fitting	8-39, 8-43
A2900000002660 Protective Cap, Nozzle	6-5	B210780000232 Adapter Fitting	8-23
A31907100070B Axis Pin	14-7	B210780000245 Bulkhead Fitting	7-19
A810201060027 Vibration switch valve installation	8-5	B210780000266 Adapter Fitting	8-13, 8-17, 8-23, 8-37
A810201060028 Vibration Switch Valve	8-33	B210780000344 Adapter Fitting	7-19, 8-15
A810201206116 Controller Assembly	13-7	B210780000413 Tee Joint	8-27
A820101319357 Crescent Shaped Plate	5-7	B210780000438 Square Flange Right-angle Joint	8-19
A820101320930 Bent Plate	5-7	B210780000587 Adapter Fitting	8-7, 8-47
A820101339360 Guard	3-5, 6-5	B210780000609 Screw Plug	8-25, 8-39
A820101342410 Control Valve Body	8-43	B210780000631 Tee Joint	8-41
A820101345222 Clamp Plate	6-5	B210780000636 Elbow Fitting	7-19, 8-41
A820101348563 Adjusting Block	5-7	B210780000652 Square Flange Right-angle Joint	8-19
A820101362643 Installation Seat	14-9	B210780000671 End Through Adapter	8-29
A820102010065 Adjusting Spacer	3-3	B210780000685 Bulkhead Fitting	8-35
A820201000779 Pressure cover	2-7	B210780000733 Adapter Fitting	8-9
A820202003593 Big Washer	7-5, 7-11	B210780000824 End Through Adapter	8-21
A820203000641 Flange Straight Joint	8-15	B210780000829 Adapter Fitting	8-41
A820205000995 Pipe connector	8-13	B210780000838 Elbow Fitting	8-35
A820205001562 Spacer Plate Joint	10-3	B210780000898 Adapter Fitting	8-29
A820205001582 Fitting	5-5	B210780001026 Adapter Fitting	7-19
A820301010152 Clamp Pin	6-11	B210780001175 Pressure-measuring Connector	8-29
A820301012683 Screw Rod, U-type	5-5, 7-11	B210780001286 Adapter Fitting	8-11, 8-13
A820301014728 Bolt, Hinged	5-7	B210780001310 Elbow Fitting	8-39
A820301017645 Lock Pole	14-7	B210780001396 Pipe connector	8-35
A820301018783 Shaft, pin	3-5, 6-5	B210780001749 Pressure-measuring Fitting	8-17
A820606030474 Protecting Ring	3-3	B220400000079 Directional Solenoid Valve	8-43
A880804040007 Retainer Ring	2-9, 2-11	B220400000217 Valve, Relief	8-21
A880808070038 PWD Dust Ring	6-7	B220401000540 Check Valve	8-21
B210299000005 Screw	8-29	B220401001276 Shuttle Valve	8-11
B2102990000026 Screw	8-29	B221701000095 Flanging Coupling	7-9
B210334000010 Nut	8-35	B222100000368 Air Filter	7-15
B210399000003 Screw Plug	8-11	B2299000002528 Blocked Up	13-11, 13-13
B210780000004 Split Flange	8-29	B230101000138 OK Seal Ring	6-7
B210780000007 Split Flange	8-7, 8-39, 8-45	B230101000233 O-ring	8-15
B210780000008 Square Flange Joint	8-29	B230101000241 O-ring	8-15
B210780000009 Square Flange Joint	8-29	B230101000461 O-ring	8-7, 8-47
B210780000017 Tee Joint	8-35, 8-37	B230101000960 O-ring	8-29
B210780000018 Tee Joint	8-35	B230101001371 UP Guide Ring	6-7
B210780000019 Tee Joint	8-39	B230101001492 UP Guide Ring	6-7
B210780000021 Tee Joint	8-41	B230101002124 ZBR Seal Ring	6-7
B210780000025 Elbow Fitting	3-7, 7-19, 8-7, 8-37, 8-39, 8-47	B230103000043 Rubber hose	7-19
B210780000028 Elbow Fitting	8-35	B230103000059 Rubber Hose	8-35
B210780000029 Elbow Fitting	8-39, 8-41	B230103000066 Rubber Hose	8-35
B210780000036 Adapter Fitting	8-43	B230103000129 Hose	7-19
B210780000037 Adapter Fitting	8-25	B230103000137 Rubber Hose	8-35
B210780000040 Adapter Fitting	7-19, 8-11, 8-25, 8-39	B230103000295 Hose	8-37
B210780000043 Fitting	8-9	B230103000345 Hose Assembly	8-37
B210780000049 Adapter Fitting	8-17	B230103000712 Hose	8-39
B210780000052 Adapter Fitting	8-25	B230103000779 Rubber Hose	8-37
B210780000054 Adapter Fitting	8-17, 8-25	B230103000869 Hose	8-35
B210780000056 Flange Connection	8-39	B230103000949 Hose	7-19
B210780000059 Flange Adapter	8-29	B230103001057 Rubber Hose	8-35
B210780000070 Fitting, Adapter	8-27	B230103001113 Hose	8-35

B230103001352 Rubber Hose	8-41	YLJ004846605 Rotary Support	6-3
B230103001629 Hose	8-37	YLJ004856263 Water Tank	12-3
B230103001790 Rubber Hose	8-39	YLJ004856829 Hinged body	6-3
B230103001881 Rubber Hose	8-37	YLJ004857847 The left stairs	3-3
B230103002218 Rubber Hose	8-35	YLJ004857866 The right stairs	3-3
B230103002298 Rubber hose	8-35	YLJ004858317 The Mounting Door	3-13
B230103004027 Hose	8-35	YLJ004858996 Dust Ring	6-3
B230103004287 Rubber Hose	8-35	YLJ004859632 Center hinge frame	1-3
B230103005096 Rubber Hose	8-35	YLJ004863424 Articulation Seat	6-3
B230103005107 Rubber Hose		YLJ004895828 Door	3-13
4SH20-DKOS-SFS90-3850	8-41	YLJ004895853 The Maintenance Door	3-5
B230103005108 Rubber Hose	8-41	YLJ004896675 Bearing cover	6-3
B230103005873 Rubber Hose	8-35	YLJ004897639 Bearing cover	6-3
B230103006189 Rubber Hose	8-35	YLJ004899560 tube	6-5
B230103006195 Hose Assembly	8-41	YLJ004899944 Paper Washer	6-3
B230103006274 Rubber Hose	8-41	YLJ004908102 Plate	6-3
B230103006405 Rubber Hose	8-35	YLJ004954617 Diesel box assembly component	3-3
B230103007175 Hose Assembly	8-37	YLJ004964826 Phone cup	14-7
B230103007493 Rubber Hose	7-19, 8-41	YLJ005044599 ring	3-5
B240200000059 Emergency Stop Button	13-9	YLJ005101815 air intake hood	10-3
B240700000006 Intermediate Relay	13-7	YLJ005103707 rear carriage weld assem.	10-3
B240700000262 Relay	13-7	YLJ005103971 rear frame	1-3
B241200000529 Toggle Switch	13-9	YLJ005105952 Oil road and nearby installation	7-3
B241200000530 TOGGLE SWITCH	13-9	YLJ005110427 Cooling assembly	7-3
B241200000531 TOGGLE SWITCH	13-9	YLJ005110467 Dynamical system	1-3
B241200000532 Toggle Switch	13-9	YLJ005110623 Exhaust System	7-3
B241200000582 2-Core Rectangular Socket....	13-11, 13-13, 13-15, 13-17	YLJ005110630 Corver	9-3
B241200000604 Rectangular Socket, 4-Position	13-11, 13-13	YLJ005110634 covering parts	1-3
B241200001124 Ignition Switch	13-9	YLJ005336947 Clip	3-3
B241300000020 Fuse	13-7	YLJ005336985 Clip	3-3
B241300000021 Fuse	13-7	YLJ005337130 Clip	10-3, 10-5
B241300000022 Fuse	13-7	YLJ005337280 Clip	10-3
B241300000024 Fuse	13-7	YLJ005337392 Clip	10-3
B241300000026 Fuse	13-7	YLJ005337594 Clip	10-3, 10-5
B249900000288 Pin	13-11, 13-13, 13-15, 13-17	YLJ005338651 Clip	3-3
JSS005350459 Floor leather JRTR07A	14-11	YLJ005340419 bolt	3-3
JSS005361404 Floor welding assembly	14-9	YLJ005348321 Electrical harness assembly basic diagram	13-3
JSS005361405 Cab body	14-7	YLJ005348333 Electrical harness in Electric Control Cabinet wiring diagram	13-23
JSS005361407 Driver's cab welding assy	14-9	YLJ005348340 Rear Frame Electrical Harness basic diagram	13-23
JSS005364030 JRTR07A inner&outer-decoration assembly	14-7	YLJ005348359 Front Frame Electrical Harness wiring diagram	13-23
JSS006065140 Big cup holder	14-7	YLJ005348415 Electrical harness of Engine wiring diagram	13-23
JSS006345517 Bracket	14-9	YLJ005358886 In air	7-15
JSS006345753 support	14-9	YLJ005358917 In air	7-15
JSS006382136 Fan stay Welding Assy.	14-9	YLJ005358995 In air	7-17
JSS006467729 stiffening plate	14-9	YLJ005359029 Out air	7-11
SZN007370178 Sany Intelligent Date Display	13-9	YLJ005359665 In air	7-15
YLJ004677591 Rearview mirror bracket welding ..	3-9	YLJ005359771 bracket for exhaust hose	7-17
YLJ004677594 Rearview mirror bracket	3-3	YLJ005359967 mounting assem. for air cleaner	7-15
YLJ004680167 Deputy box manipulation	4-15	YLJ005393615 hose clip unit	10-3
YLJ004680723 plate	4-15	YLJ005417572 Front carriage weld assem.	3-3
YLJ004680731 side box	4-3	YLJ005417704 Front carriage	1-3
YLJ004687645 Mounting plate of rearview mirror braket	3-3	YLJ005419735 Water sprinkling tube component	12-3
YLJ004727975 left covering parts	9-3	YLJ005426878 plate	3-3
YLJ004728021 Covered in a	9-3		
YLJ004758616 Mounting Assem.	7-15		
YLJ004776713 Rear Cover Welding	4-5		
YLJ004797181 Oil	3-7		

YLJ005427066 PLATE	3-3	YLJ005639941 water	1-3
YLJ005563219 vibration drum assem	1-3	YLJ005651966 Bridging BeamComponent	1-3
YLJ005567022 Scraper mounting plate	11-7	YLJ005652578 Upper scraper assem.	11-3
YLJ005567030 Mounting plate	11-7	YLJ005683988 Plate	7-11
YLJ005568451 mounting plate welding	11-7	YLJ005720436 Traveling motor	8-3
YLJ005568781 Scraper mounting plate	11-7	YLJ005770629 cover plate	10-3
YLJ005568841 mounting plate welding	11-7	YLJ006045976 Cross beam welding	11-3
YLJ005573749 Driver's Cab Assy	1-3	YLJ006231480 Mounting plate of motor	7-11
YLJ005602041 air	1-3	YLJ006552828 plate	4-3
YLJ005619004 rubber retainer	10-5	YLJ006656466 controlling system assembly	1-3
YLJ005619017 rubber retainer	10-5	YLJ007366684 Rubber tie-plate	3-3

www.sanyglobal.com



Sany Automobile Manufacturing Co., Ltd.

SANY Industry Town, Economic and Technological Development Zone, Changsha,
Hunan, China 410100

Service Hotline: 0086 4006098318

E-mail: crd@sany.com.cn

