SMCS - 1403

SENR74100041

Remove Glow Plugs

Tools Needed	A
5P0127 Socket	1

Start By:

a. remove valve covers



1. Disconnect glow plug wire (1) from the glow plug.

2. Remove the glow plug with tool (A).

Install Glow Plugs

Tools Needed	A
5P0127 Socket	1

1. Put **5P3931 Anti-Seize Compound** on the threads of glow plug (1).

2. Install glow plug (1) and tighten to a torque of **14 ± 3 N·m (10 ± 2 lb ft).**

NOTICE

Be sure glow plug wire is away from the valve spring when it is installed on the glow plug.

End By:

a. install valve covers.

PSP-000890C4
2022/11/30
16:13:38-03:00
SENR74100041
© 2022 Caterpillar Inc.
Caterpillar:
Confidential Green

PSP-000890C4 2022/11/30 16:13:52-03:00 SENR7410 © 2022 Caterpillar Inc. Caterpillar: Confidential Green